



# MFR 3 Multi Function Relay



**Manual**  
Software Version 3.4xxx

**WARNING**

Read this entire manual and all other publications pertaining to the work to be performed before installing, operating, or servicing this equipment. Practice all plant and safety instructions and precautions. Failure to follow instructions can cause personal injury and/or property damage.

The engine, turbine, or other type of prime mover should be equipped with an overspeed (overtemperature, or overpressure, where applicable) shutdown device(s), that operates totally independently of the prime mover control device(s) to protect against runaway or damage to the engine, turbine, or other type of prime mover with possible personal injury or loss of life should the mechanical-hydraulic governor(s) or electric control(s), the actuator(s), fuel control(s), the driving mechanism(s), the linkage(s), or the controlled device(s) fail.

Any unauthorized modifications to or use of this equipment outside its specified mechanical, electrical, or other operating limits may cause personal injury and/or property damage, including damage to the equipment. Any such unauthorized modifications: (i) constitute "misuse" and/or "negligence" within the meaning of the product warranty thereby excluding warranty coverage for any resulting damage, and (ii) invalidate product certifications or listings.

**CAUTION**

To prevent damage to a control system that uses an alternator or battery-charging device, make sure the charging device is turned off before disconnecting the battery from the system.

Electronic controls contain static-sensitive parts. Observe the following precautions to prevent damage to these parts.

- Discharge body static before handling the control (with power to the control turned off, contact a grounded surface and maintain contact while handling the control).
- Avoid all plastic, vinyl, and Styrofoam (except antistatic versions) around printed circuit boards.
- Do not touch the components or conductors on a printed circuit board with your hands or with conductive devices.

**OUT-OF-DATE PUBLICATION**

This publication may have been revised or updated since this copy was produced. To verify that you have the latest revision, be sure to check the Woodward website:

<http://www.woodward.com/pubs/current.pdf>

The revision level is shown at the bottom of the front cover after the publication number. The latest version of most publications is available at:

<http://www.woodward.com/publications>

If your publication is not there, please contact your customer service representative to get the latest copy.

**Important definitions****WARNING**

Indicates a potentially hazardous situation that, if not avoided, could result in death or serious injury.

**CAUTION**

Indicates a potentially hazardous situation that, if not avoided, could result in damage to equipment.

**NOTE**

Provides other helpful information that does not fall under the warning or caution categories.

Woodward reserves the right to update any portion of this publication at any time. Information provided by Woodward is believed to be correct and reliable. However, Woodward assumes no responsibility unless otherwise expressly undertaken.

© Woodward  
All Rights Reserved.

# Revision History

---

Rev.	Date	Editor	Changes
NEW	04-05-05	Tr	Release
A	05-02-02	TP	Minor corrections
B	05-07-12	TP	Minor corrections, parameter numbers added, language revision
C	05-10-11	TP	Minor corrections, changes of mains monitoring, relay and analog output manager, rotation field monitoring
D	08-08-20	TP	Pulse outputs updated; power factor definition added; inverse time-overcurrent monitoring updated; receive telegram added; analog output manager corrected
E	08-10-30	TE	Minor corrections
F	08-12-02	TE	Minor corrections, power display format

# Contents

---

<b>CHAPTER 1. GENERAL INFORMATION.....</b>	<b>9</b>
Introduction .....	9
Measuring .....	11
Functional Range .....	12
<b>CHAPTER 2. ELECTROSTATIC DISCHARGE AWARENESS .....</b>	<b>14</b>
<b>CHAPTER 3. INSTALLATION.....</b>	<b>15</b>
Wiring Diagram .....	16
Power Supply .....	18
Measuring Inputs.....	18
Voltage.....	18
Current.....	20
Discrete Inputs .....	21
Control Inputs.....	21
Alarm / Control Inputs .....	22
Analog Inputs .....	23
Relay Outputs .....	24
Control Outputs.....	24
Relay Manager.....	24
Analog Outputs .....	25
Pulse Outputs.....	25
Controller Outputs .....	26
Three-Position Controllers (Standard).....	26
Multi Functional Controller Outputs .....	26
Interface .....	28
Interface Wiring.....	28
CAN Bus Shielding .....	29
CAN Bus Loop .....	29
DPC - Direct Configuration Interface .....	30

<b>CHAPTER 4. FUNCTIONAL DESCRIPTION.....</b>	<b>31</b>
Function.....	31
Operating Conditions.....	31
Direction of Power.....	34
Power Factor Definition.....	34
Activation of the Circuit Breakers.....	36
Operating Sequence for the MCB.....	36
Operating Sequence for the GCB.....	37
Analog Controller Outputs.....	38
Controller Setting.....	39
Load and/or Var Sharing.....	41
Language Manager.....	43
Alarms.....	44
Alarm Class.....	44
Internally Detected Alarms.....	44
Alarm Acknowledgement.....	45
<b>CHAPTER 5. DISPLAY AND PUSH-BUTTONS.....</b>	<b>46</b>
Brief Description of LED and Push-Buttons.....	47
LEDs.....	47
Push-Buttons.....	47
Miscellaneous.....	47
LEDs.....	48
Push-Buttons.....	49
General / Configuration.....	49
Control of the Power Circuit Breakers.....	51
Operating Mode Selector.....	51
LC Display.....	52
Automatic Mode (First Display Line: Measuring Values).....	52
Automatic Mode (Second Display Line: Measuring Values).....	53
Automatic Mode (Second Display Line: Alarm Display).....	54
<b>CHAPTER 6. CONFIGURATION.....</b>	<b>55</b>
Introduction.....	56
Basic Data.....	56
Language Manager.....	56
Version Number.....	57
Service Display.....	57
Password Protection.....	59
Event Recorder.....	60
Internal Events and Discrete Inputs.....	60
Analog Inputs.....	62
Direct Configuration.....	63
Basic Settings.....	64
Generator and Mains Environmental.....	64
Change Passwords.....	72
Controller.....	73
Constant and Interchange Real Power Controller.....	73
Frequency Controller.....	74
Voltage Controller.....	77
Power Factor Controller.....	80
Real Power Controller.....	82
Load/var Sharing.....	86
Interface.....	87

Breaker.....	88
Breaker Logic.....	88
Synchronization .....	91
Synchronization Time Monitoring .....	92
Dead Bus Start.....	93
Breaker Monitoring .....	94
Mains Decoupling .....	94
Mains Settling Time .....	94
Protection .....	95
Mains Power Monitoring .....	95
Reverse/Reduced Power Monitoring.....	96
Generator Overload Monitoring .....	97
Generator Re-active Power Monitoring .....	98
Time-Overcurrent Monitoring (TOC).....	99
Inverse Time-Overcurrent Monitoring.....	100
Inverse Time-Overcurrent Monitoring with Voltage Restraint .....	103
Earth Fault Monitoring .....	105
Generator Load Imbalance Monitoring .....	106
Generator Overfrequency Monitoring .....	107
Generator Underfrequency Monitoring .....	108
Generator Overvoltage Monitoring .....	109
Generator Undervoltage Monitoring .....	110
Mains Frequency Monitoring .....	111
Mains Voltage Monitoring .....	112
Mains $d\phi/dt$ Phase/Vector Shift Monitoring .....	114
Mains $df/dt$ Rate Of Change Of Frequency Monitoring (ROCOF).....	116
Mains Decoupling (Selection Between $d\phi/dt$ and $df/dt$ ) .....	116
Battery Voltage Monitoring .....	117
Discrete Inputs .....	118
Blocking of Operation Mode Selector [D02] .....	118
Selection of the Mains Decoupling via Discrete Input [D01].....	118
Breaker Logic via Discrete Input [D03].....	119
Discrete inputs: Setting.....	119
Discrete Inputs: Text.....	120
Analog Inputs .....	121
Analog Inputs: Setting.....	121
Outputs.....	125
Analog Outputs .....	125
Relay Manager.....	126
Pulse Outputs .....	127
Drive .....	128
Delayed Monitoring and Ignition Speed.....	129
Shutdown (Unload and Open GCB) .....	130
Counter .....	131
Maintenance Call .....	131
Operating Hours Counter.....	132
Start Counter.....	133
kWh/kvarh Counter .....	133
Resetting the Counters .....	133
Real Time Clock .....	134
Current Slave Pointer .....	134
<b>CHAPTER 7. COMMISSIONING .....</b>	<b>135</b>
<b>APPENDIX A. DIMENSIONS.....</b>	<b>137</b>
<b>APPENDIX B. TECHNICAL DATA .....</b>	<b>138</b>
<b>APPENDIX C. MEASURED QUANTITIES AND ACCURACY .....</b>	<b>140</b>

---

**APPENDIX D. ANALOG OUTPUT MANAGER ..... 141**

---

**APPENDIX E. RELAY MANAGER..... 144**

---

**APPENDIX F. INTERFACE TELEGRAM ..... 146**

Transmission Telegram ..... 146

Receiving Telegram ..... 151

CAN Bus Structure ..... 152

    CAN Bus ..... 152

    Current Direction Message ..... 152

    Power Set Point Value Message ..... 153

    CAN Bus Address Requirements ..... 153

---

**APPENDIX G. LIST OF PARAMETERS..... 154**

---

**APPENDIX H. SERVICE OPTIONS ..... 160**

Product Service Options ..... 160

Returning Equipment For Repair ..... 160

    Packing a Control ..... 161

    Return Authorization Number RAN ..... 161

Replacement Parts ..... 161

How To Contact Woodward ..... 162

Engineering Services ..... 163

Technical Assistance ..... 164

# Illustrations and Tables

---

## Illustrations

Figure 3-1: Wiring diagram MFR 31 .....	16
Figure 3-2: Wiring diagram MFR 32 .....	17
Figure 3-3: Power supply .....	18
Figure 3-4: Measuring inputs - voltage - generator .....	18
Figure 3-5: Measuring inputs - voltage - busbar .....	19
Figure 3-6: Measuring inputs - voltage - mains .....	19
Figure 3-7: Measuring inputs - current - generator .....	20
Figure 3-8: Mains current transformer measuring inputs .....	20
Figure 3-9: Discrete inputs - control inputs .....	21
Figure 3-10: Discrete inputs - alarm inputs - positive polarity .....	22
Figure 3-11: Discrete inputs - alarm inputs - negative polarity (examples) .....	22
Figure 3-12: Analog inputs .....	23
Figure 3-13: Relay outputs - control outputs - CB control .....	24
Figure 3-14: Relay outputs - relay manager .....	24
Figure 3-15: Analog outputs .....	25
Figure 3-16: Pulse outputs .....	25
Figure 3-17: Pulse output - wiring example .....	25
Figure 3-18: Controller - three-position controller .....	26
Figure 3-19: Three-position controller - external RC wiring for relay manager .....	27
Figure 3-20: Analog controller n/f/P - wiring and jumper setting .....	27
Figure 3-21: Analog controller V/Q - wiring and jumper setting .....	27
Figure 3-22: Interface - terminals .....	28
Figure 3-23: Interface - CAN bus shielding .....	29
Figure 3-24: Interface - loop the CAN bus .....	29
Figure 4-1: Direction of power .....	34
Figure 4-2: Activation of the circuit breakers - MCB .....	36
Figure 4-3: Activation of the circuit breakers - GCB .....	37
Figure 4-4: Closed loop .....	38
Figure 4-5: Step response (example) .....	38
Figure 4-6: Step response - controller setting .....	40
Figure 4-7: Load/var sharing - schematic .....	42
Figure 5-1: Front panel MFR 31 .....	46
Figure 5-2: Front panel MFR 32 .....	46
Figure 6-1: Characteristic of the time-overcurrent monitoring .....	99
Figure 6-2: Inverse time-overcurrent - characteristic "normal inverse" .....	101
Figure 6-3: Inverse time-overcurrent - characteristic "high inverse" .....	102
Figure 6-4: Inverse time-overcurrent - characteristic "extremely inverse" .....	102
Figure 6-5: Characteristic of the inverse time-overcurrent monitoring with voltage restraint (knee curve setting 20 %) .....	103
Figure 6-6: Ignition speed - delayed monitoring .....	129
Figure 7-1: Dimensions .....	137
Figure 7-2: analog outputs – power factor scaling .....	143

**Tables**

Table 3-1: Maximum CAN bus length..... 30

Table 4-1: Operating conditions - idle control and synchronization..... 31

Table 4-2: Operating conditions - idle control and synchronization - conditions..... 31

Table 4-3: Operating conditions - dead bus start..... 32

Table 4-4: Operating conditions - dead bus start - conditions..... 32

Table 4-5: Operating conditions - isolated operation..... 32

Table 4-6: Operating conditions - mains parallel operation..... 33

Table 4-7: Alarms - text messages..... 44

Table 4-8: Alarms - short acknowledgment..... 45

Table 4-9: Alarms - long acknowledgment..... 45

Table 5-1: Alarms - text messages..... 54

Table 6-1: Event recorder - messages - Part 1..... 61

Table 6-2: Event recorder - messages - Part 2..... 62




# Chapter 1. General Information

## Introduction

The MFR 3 has been designed to provide circuit breaker and load control and protection. It is possible to monitor both the generator and mains simultaneously. The MFR 3 permits two circuit breakers to be synchronized and control of the mains power.

The MFR 3 starts as a standard unit that may have additional functions added with each model. The model of the MFR 3 is designated as follows:



**Examples:**

- MFR 31S45B/PSVX+Q (standard unit with one breaker logic for synchronous generators and is flush-mounting, 400 Vac PT inputs as well as ../5 A CT measuring inputs; Option Q: analog or three-position controller functionality selectable, and an event logger, T7 analog inputs, and real-time clock)
- MFR 32S15B/PSVX+Q (standard unit with two breaker logic for synchronous generators and is flush-mounting, 100 Vac PT inputs as well as ../5 A CT measuring inputs; Option Q: analog or three-position controller functionality selectable, and an event logger, T7 analog inputs, and real-time clock)

**Intended Use:** The control unit must only be operated as described in this manual. The prerequisite for a proper and safe operation of the product is correct transportation, storage, and installation as well as careful operation and maintenance.

**NOTE**

This manual has been developed for a unit fitted with all available options. Inputs/outputs, functions, configuration screens and other details described, which do not exist on your unit may be ignored. The present manual has been prepared to enable the installation and commissioning of the unit. Because of the large variety of parameter settings, it is not possible to cover every combination. The manual is therefore only a guide. In case of incorrect entries or a total loss of functions, the default settings can be taken from the enclosed list of parameters at the rear of this manual.

## Measuring



### Voltage

The control unit performs three-phase true RMS measurement of two star or delta voltage systems (generator and mains). This unit can be delivered with the following measuring voltage ranges (rated values). The voltage measuring is specific to the part number ordered (please note chapter "Technical Data", page 138):

- [1] 66/115 Vac
- [4] 230/400 Vac

### Frequency

The measured voltages are digitally filtered for frequency measurement. The control unit performs three-phase true RMS measurement of the frequency if the measured voltages exceed the rated value (100/400 Vac) by 15 %. This ensures rapid and precise measurement of the frequency. Frequency is still measured correctly if voltage is only measured in one phase.

### Current

The control unit performs three-phase true RMS current measurement.

### Real power

The control unit performs three-phase true RMS power measurement. This is accomplished by real-time multiplication of the wye voltage and instantaneous conductor current values (three-phase measurement) or the phase voltage  $V_{L12}$  and the current  $I_{L1}$  (single-phase measurement).

### Re-active power

The control unit performs single-phase true RMS re-active power measurement, which is calculated from apparent power and active power.

### Power factor

Power factor is determined as a time measurement between the filtered measured values of the voltage  $V_{L12}$  and the conductor current  $I_{L1}$ .

### Real energy

The positive real energy is integrated with a time measurement. The counter is controlled in the non-volatile memory and has reverse counting protection. The data is saved in three-minute time frames with a resolution of 1 Watt-hour. The display automatically updates the measured units when required to go to a larger reference. This permits the control unit to count up to 4,290 GWh. The counter is not PTB-calibrated.

# Functional Range



The unit contains of the following features dependent upon the model:

<b>Function</b>	<b>Option</b>	<b>Package</b>
		PSVX+Q

Common features		
1× ready for operation relay	Standard	✓
4(2) *× control relays (N.O. contact)	Standard	✓
7× freely configurable relay outputs (N.O. contact)	Standard	✓
2× three-position controller for n/f/V/P, power factor	Standard	✓
2× three-position controller for n/f/V/P, power factor and 2 analog controller for n/f/V/P/Q and PWM outp.	Q	✓
10(8) *× discrete control inputs *	Standard	✓
12× discrete alarm inputs	Standard	✓
7× analog inputs		✓
1× analog input for mains real power (instead of current transducer)		✓
2× analog outputs	Standard	✓
1× kWh pulse output	Standard	✓
1× kvarh pulse output	Standard	✓
Password system	Standard	✓
Configuration via PC and DPC cable possible (direct configuration)	Standard	✓
CAN bus interface	Standard	✓
Event recorder with real-time clock		✓
Language manager for message texts	Standard	✓
Ignition speed relay function	Standard	✓
Running hours counter	Standard	✓
Maintenance call counter	Standard	✓
Start counter	Standard	✓
kWh- and kvarh counter	Standard	✓

Protection functions		
Over-/undervoltage protection (2step), generator	$V_{gen}>/<$	Standard ✓
Over-/undervoltage protection (1step), mains	$V_{mains}>/<$	Standard ✓
Over-/underfrequency protection	$f>/<$	Standard ✓
Voltage asymmetry protection	$V_{as}>$	Standard ✓
dφ/dt phase/vector jump protection	dφ/dt	Standard ✓
df/dt protection	df/dt	Standard ✓
Reverse/reduced power protection	$+/-P_{Gen}<$	Standard ✓
Overload protection	$P_{Gen}>$	Standard ✓
Unbalanced load protection	$\Delta P>$	Standard ✓
Reactive power protection (loss of excitation)	$Q<$	Standard ✓
Time-overcurrent protection	$I_{time}>/>>$	Standard ✓
Inverse time-overcurrent protection, IEC 255	$I_{inv-time}>$	Standard ✓
Voltage restraint time-overcurrent protection	$I_{Vtime}>$	Standard ✓
Ground fault protection	$I_{earth}>$	Standard ✓
Battery monitoring	$V_{Bat}<$	Standard ✓

\* the lower number of control relays or inputs applies for units with one circuit breaker

<b>Function</b>	<b>Option</b>	<b>Package</b>
		<b>PSVX+Q</b>

<b>Control/synchronization</b>		
Synchronization of 2 circuit breakers with V and f control	Standard	✓
Closing to a dead busbar (dead bus start)	Standard	✓
Voltage control	Standard	✓
Power factor control	Standard	✓
Speed/frequency control	Standard	✓
Real power control	Standard	✓
Mains interchange power control	Standard	✓
Load sharing	Standard	✓
var sharing	Standard	✓
Analog set point value for real power	Standard	✓
Analog set point value for power factor		✓
Breaker logic "open transition"	Standard	✓
Breaker logic "closed transition"	Standard	✓
Breaker logic "soft loading"	Standard	✓
Breaker logic "parallel operation"	Standard	✓
Breaker logic "external"	Standard	✓
Remote control via interface	Standard	✓

<b>Control inputs (DIs)</b>		
Switch set point value 1 ↔ 2	Standard	✓
Enable monitoring	Standard	✓
Configuration blocked	Standard	✓
Block mains protection	Standard	✓
Mains decoupling via MCB	Standard	✓
Operation mode selector blocked	Standard	✓
Switch breaker logic	Standard	✓
Release GCB/MCB	Standard	✓
Isolated controller ON	Standard	✓
External acknowledgement	Standard	✓

<b>Packages</b>		
MFR 3/PSVX+Q (7 analog inputs, event logger with real-time clock, setpoint value for cosφ)		✓

## Chapter 2.

# Electrostatic Discharge Awareness

---

All electronic equipment is static-sensitive, some components more than others. To protect these components from static damage, you must take special precautions to minimize or eliminate electrostatic discharges.

Follow these precautions when working with or near the control.

1. Before performing maintenance on the electronic control, discharge the static electricity on your body to ground by touching and holding a grounded metal object (pipes, cabinets, equipment, etc.).
2. Avoid the build-up of static electricity on your body by not wearing clothing made of synthetic materials. Wear cotton or cotton-blend materials as much as possible because these do not store static electric charges as much as synthetics.
3. Keep plastic, vinyl, and Styrofoam materials (such as plastic or Styrofoam cups, cup holders, cigarette packages, cellophane wrappers, vinyl books or folders, plastic bottles, and plastic ash trays) away from the control, the modules, and the work area as much as possible.
4. **Opening the control cover may void the unit warranty.**  
Do not remove the Printed Circuit Board (PCB) from the control cabinet unless absolutely necessary. If you must remove the PCB from the control cabinet, follow these precautions:
  - Ensure that the device is completely de-energized (all connectors must be disconnected).
  - Do not touch any part of the PCB except the edges.
  - Do not touch the electrical conductors, connectors, or components with conductive devices with your hands.
  - When replacing a PCB, keep the new PCB in the protective antistatic bag it comes in until you are ready to install it. Immediately after removing the old PCB from the control cabinet, place it in the protective antistatic bag.



### CAUTION

To prevent damage to electronic components caused by improper handling, read and observe the precautions in Woodward manual 82715, *Guide for Handling and Protection of Electronic Controls, Printed Circuit Boards, and Modules*.

## Chapter 3. Installation

---



### CAUTION

A circuit breaker must be provided near to the device and in a position easily accessible to the operator. This must also bear a sign identifying it as an isolating switch for the unit.



### NOTE

Connected inductive devices (such as operating current coils, undervoltage tripping devices, or auxiliary or power contacts) must be connected to a suitable interference suppressor.

# Wiring Diagram




Figure 3-1: Wiring diagram MFR 31






Figure 3-2: Wiring diagram MFR 32

## Power Supply




Figure 3-3: Power supply

Terminal	Description	A <sub>max</sub>
0	N terminal of the low voltage system or neutral terminal of the voltage transformer/PT's (measuring reference point)	2.5 mm <sup>2</sup>
1	9.5 to 32 Vdc, 15 W	2.5 mm <sup>2</sup>
2	0 Vdc reference point	2.5 mm <sup>2</sup>

**Note:** When used in a 12 Vdc system, please wire the power supply as described above.

## Measuring Inputs

**i NOTE** The three-phase system must have a dextrorotatory field (right-handed rotary field). If the unit is used with a laevorotatory field (left-handed rotary field), the power factor measurement will not be correct.

### Voltage

#### Generator




Figure 3-4: Measuring inputs - voltage - generator

Terminal	Measuring	Description	A <sub>max</sub>
20	400 Vac direct	Generator voltage L1	2.5 mm <sup>2</sup>
21	or via measuring transducer	Generator voltage L2	2.5 mm <sup>2</sup>
22		Generator voltage L3	2.5 mm <sup>2</sup>
0	.../100 Vac	Neutral point of the 3-phase system/transformer/PT's	2.5 mm <sup>2</sup>

**Busbar**




Figure 3-5: Measuring inputs - voltage - busbar

Terminal	Measuring	Description	A <sub>max</sub>
23	400 Vac	Busbar voltage L1	2.5 mm <sup>2</sup>
24	100 Vac	Busbar voltage L2	2.5 mm <sup>2</sup>

**Mains**




Figure 3-6: Measuring inputs - voltage - mains

Terminal	Measuring	Description	A <sub>max</sub>
50	400 Vac direct	Mains voltage L1	2.5 mm <sup>2</sup>
51	or via measuring transducer	Mains voltage L2	2.5 mm <sup>2</sup>
52		Mains voltage L3	2.5 mm <sup>2</sup>
0	.. /100 Vac	Neutral point of the 3-phase system/transformer/PT's	2.5 mm <sup>2</sup>



**NOTE**

The mains voltage measuring inputs must be connected if the unit is used in mains parallel operation.

### Current



#### CAUTION

Before disconnecting the secondary current transformer (CT) connections or the connections of the CT at the device, make sure that the CT is short-circuited.



#### NOTE

Generally current transformers should be grounded on one side.

### Generator




Figure 3-7: Measuring inputs - current - generator

Terminal	Measuring	Description	A <sub>max</sub>
25	Transformer ..1/5 A	Generator current L1, transformer term. s2 (l)	2.5 mm <sup>2</sup>
26		Generator current L1, transformer term. s1 (k)	2.5 mm <sup>2</sup>
29		Generator current L2, transformer term. s2 (l)	2.5 mm <sup>2</sup>
30		Generator current L2, transformer term. s1 (k)	2.5 mm <sup>2</sup>
31		Generator current L3, transformer term. s2 (l)	2.5 mm <sup>2</sup>
32		Generator current L3, transformer term. s1 (k)	2.5 mm <sup>2</sup>

### Mains




Figure 3-8: Mains current transformer measuring inputs

Terminal	Measuring	Description	A <sub>max</sub>
27	Transformer ..1/5 A	Mains current L1, transformer term. s2 (l)	2.5 mm <sup>2</sup>
28		Mains current L1, transformer term. s1 (k)	2.5 mm <sup>2</sup>

## Discrete Inputs



### CAUTION

Please note that the maximum voltages which may be applied at the discrete inputs are defined as follows. Voltages higher than those specified will destroy the hardware!

Maximum input range: +/-18 to 250 Vac.

### Control Inputs




Figure 3-9: Discrete inputs - control inputs

Terminal	Associated common	Description (according to DIN 40 719, part 3, 5.8.3)	A <sub>max</sub>
<b>A</b>	<b>B</b>	<b>Make contact (NO)</b>	
3	7	Enable GCB	2.5 mm <sup>2</sup>
5		Switch set point value 1 ↔ 2	2.5 mm <sup>2</sup>
6		Enable monitoring	2.5 mm <sup>2</sup>
53		MFR 31: Enable externally MFR 32: Enable MCB	2.5 mm <sup>2</sup>
34	33	Configuration blocked	2.5 mm <sup>2</sup>
35		Isolated controller ON	2.5 mm <sup>2</sup>
36		External acknowledgment	2.5 mm <sup>2</sup>
61	60	Block mains protection	2.5 mm <sup>2</sup>
<b>C</b>	<b>D</b>	<b>Break contact (NC)</b>	
4	7	Reply: GCB is open	2.5 mm <sup>2</sup>
54		MFR 31: Status: Isolated operation MFR 32: Reply: MCB is open	2.5 mm <sup>2</sup>

### Alarm / Control Inputs

The discrete inputs may be either connected in a positive or a negative polarity:  
 positive polarity      The discrete input is connected with +/-18 to 250 Vac/dc.  
 negative polarity      The discrete input is connected with GND.

#### Positive Logic




Figure 3-10: Discrete inputs - alarm inputs - positive polarity

Terminal <i>A</i>	Associated common <i>B</i>	Description (according to DIN 40 719, part 3, 5.8.3)	$A_{max}$
62	60	Discrete input [D01] - alarm input or - mains decoupling via MCB	2.5 mm <sup>2</sup>
63		Discrete input [D02] - alarm input or - operation mode selector blocked	2.5 mm <sup>2</sup>
64		Discrete input [D03] - alarm input or - switch breaker logic	2.5 mm <sup>2</sup>
65		Discrete input [D04] - alarm input	2.5 mm <sup>2</sup>
66		Discrete input [D05] - alarm input	2.5 mm <sup>2</sup>
67		Discrete input [D06] - alarm input	2.5 mm <sup>2</sup>
68		Discrete input [D07] - alarm input	2.5 mm <sup>2</sup>
69		Discrete input [D08] - alarm input	2.5 mm <sup>2</sup>
70		Discrete input [D09] - alarm input	2.5 mm <sup>2</sup>
71		Discrete input [D10] - alarm input	2.5 mm <sup>2</sup>
72		Discrete input [D11] - alarm input	2.5 mm <sup>2</sup>
73		Discrete input [D12] - alarm input	2.5 mm <sup>2</sup>

#### Negative Logic




Figure 3-11: Discrete inputs - alarm inputs - negative polarity (examples)

Associated common <i>A</i>	Terminal <i>B</i>	Description (according to DIN 40 719, part 3, 5.8.3)	$A_{max}$
60	62	Discrete input [D01] - alarm input or - mains decoupling via MCB	2.5 mm <sup>2</sup>
	63	Discrete input [D02] - alarm input or - operation mode selector blocked	2.5 mm <sup>2</sup>
	64	Discrete input [D03] - alarm input or - switch breaker logic	2.5 mm <sup>2</sup>

## Analog Inputs



### WARNING

The analog inputs of the MFR are not isolated. When using an isolation monitor, we recommend to use two-pole, isolated transmitters.

The analog inputs for active transmitters (0 to 20 mA, 0 to 10V) should only be operated with two-pole, isolated transmitters.




Figure 3-12: Analog inputs

Terminal			Description (according to DIN 40 719, part 3, 5.8.3)	A <sub>max</sub>
A	B	C		
93	94	95	Analog input 1 [T1] • <a href="#">PSVX</a> 0/4 to 20 mA, set point value P (kW)	1.5 mm <sup>2</sup>
96	97	98	Analog input 2 [T2] • <a href="#">PSVX</a> 0/4 to 20 mA, set point power factor	1.5 mm <sup>2</sup>
99	100	101	Analog input 3 [T3] • <a href="#">PSVX</a> 0/4 to 20 mA	1.5 mm <sup>2</sup>
102	103	104	Analog input 4 [T4] • <a href="#">PSVX</a> Pt100	1.5 mm <sup>2</sup>
105	106	107	Analog input 5 [T5] • <a href="#">PSVX</a> Pt100	1.5 mm <sup>2</sup>
108	109	110	Analog input 6 [T6] • <a href="#">PSVX</a> Pt100	1.5 mm <sup>2</sup>
111	112	113	Analog input 7 [T7] • <a href="#">PSVX</a> Pt100	1.5 mm <sup>2</sup>

## Relay Outputs



### Control Outputs




Figure 3-13: Relay outputs - control outputs - CB control

<i>Make contact</i>		Description	A <sub>max</sub>
Root A	Make contact B [NO]		
14	15	Command: close GCB	2.5 mm <sup>2</sup>
16	17	Command: close MCB	2.5 mm <sup>2</sup>
39	40	Command: open MCB	2.5 mm <sup>2</sup>
41	42	Command: open GCB	2.5 mm <sup>2</sup>

### Relay Manager




Figure 3-14: Relay outputs - relay manager

<i>Make contact</i>		Description	A <sub>max</sub>
Root A	Make contact B [NO]		
18	19	Readiness for operation	2.5 mm <sup>2</sup>
74	75	Relay [R1] (relay manager)	2.5 mm <sup>2</sup>
76	77	Relay [R2] (relay manager)	2.5 mm <sup>2</sup>
78	79	Relay [R3] (relay manager)	2.5 mm <sup>2</sup>
80	81	Relay [R4] (relay manager)	2.5 mm <sup>2</sup>
82	83	Relay [R5] (relay manager)	2.5 mm <sup>2</sup>
37	38	Relay [R6] (relay manager)	2.5 mm <sup>2</sup>
47	48	Relay [R7] (relay manager)	2.5 mm <sup>2</sup>



### Analog Outputs




Figure 3-15: Analog outputs

Ia A	GND B	Description	A <sub>max</sub>
130	131	Analog output [A1] - 0/4 to 20 mA	1.5 mm <sup>2</sup>
132	133	Analog output [A2] - 0/4 to 20 mA	1.5 mm <sup>2</sup>

### Pulse Outputs




Figure 3-16: Pulse outputs

Terminal	Description	A <sub>max</sub>
Real energy kWh		
A	137 Pulse output (kWh pulse)	1.5 mm <sup>2</sup>
B	136 Emitter (Open Collector)	1.5 mm <sup>2</sup>
Re-active energy kvarh		
A	135 Pulse output (kvarh pulse)	1.5 mm <sup>2</sup>
B	134 Emitter (Open Collector)	1.5 mm <sup>2</sup>

Example




Figure 3-17: Pulse output - wiring example

## Controller Outputs



The controllers are configured in the standard version as three-position controllers (made up of a change-over contact and a normally open contact]. With **option Q** these contacts can be used as different types of outputs depending on the use of jumpers and the parameters selected.

### Three-Position Controllers (Standard)




Figure 3-18: Controller - three-position controller

Terminal	Description	A <sub>max</sub>
8	common	2.5 mm <sup>2</sup>
9	raise	2.5 mm <sup>2</sup>
10	lower	2.5 mm <sup>2</sup>
11	common	2.5 mm <sup>2</sup>
12	raise	2.5 mm <sup>2</sup>
13	lower	2.5 mm <sup>2</sup>

### Multi Functional Controller Outputs

The **Option Q** is a controller output for the following signals which can be selected in the configuration menu and by installing an external jumper.

#### Versions

- **Three-position controller** via relay manager
  - **Control of n/f/P:** Parameter "**F/P contr.type**" = THREESTEP
    - n+/f+/P+ = relay manger parameter 99
    - n-/f-/P- = relay manager parameter 100
  - **Control of V/Q:** Parameter "**V/Q contr.output**" = THREESTEP
    - V+/Q+ = relay manager parameter 101
    - V-/Q- = relay manager parameter 102
- **Analog controller** output
  - **Control of n/f/P:** Parameter "**F/P contr.type**" = ANALOG
    - Current output (mA) = no jumpers necessary
    - Voltage output (V) = jumpers between 8/9
    - Connect governor to terminals 9/10
  - **Control of V/Q:** Parameter "**v/Q contr.output**" = ANALOG
    - Current output (mA) = no jumpers necessary
    - Voltage output (V) = jumpers between 11/12
    - Connect governor to terminals 12/13
- **PWM controller** output
  - **Control of n/f/P:** Parameter "**F/P contr.type**" = PWM
    - PWM output = jumpers between 8/9
    - Connect governor to terminals 9/10

Wiring of Controller

Option Q - setting: **THREESTEP** (three-position controller)




Figure 3-19: Three-position controller - external RC wiring for relay manager

Option Q - setting: **ANALOG or PWM** (analog controller) - frequency/real power controller




Figure 3-20: Analog controller n/f/P - wiring and jumper setting

Option Q - setting: **ANALOG** (analog controller) - voltage/reactive power controller




Figure 3-21: Analog controller V/Q - wiring and jumper setting

# Interface



## Interface Wiring




Figure 3-22: Interface - terminals

Wiring		Description			
Whether the terminals are designated X or Y depends on the configuration of the system. Please refer to the wiring diagram (A = X/Y, B = X/Y, etc.)					
<b>all</b>					
A (X1)	B (X2)	C (X3)	D (X4)	E (X5)	
[1]	[1]	GND	CAN-H	CAN-L	CAN bus

[1]..can be used to loop the CAN bus or/and to connect the termination resistance.

### CAN Bus Shielding




Figure 3-23: Interface - CAN bus shielding

### CAN Bus Loop



**NOTE**

Please note that the CAN bus must be terminated at both ends with an impedance which corresponds to the wave impedance of the cable (e.g. 120 Ohm). The Engine CAN bus is terminated between CAN-H and CAN-L.




Figure 3-24: Interface - loop the CAN bus

### Possible CAN Bus Problems

If no data is transmitted on the CAN bus, check the following common reasons for CAN bus communication problems:

- T structure bus is utilized
- CAN-L and CAN-H are interchanged
- Not all devices on the bus are using identical Baud rates
- Terminating resistor are missing
- Baud rate to high for wiring length

### Maximum CAN Bus Length

The maximum length of the communication bus wiring is dependent on the configured Baud rate. Refer to Table 3-1 for the maximum bus length (Source: CANopen; Holger Zeltwanger (Hrsg.); 2001 VDE VERLAG GMBH, Berlin und Offenbach; ISBN 3-8007-2448-0).

Baud rate	Max. length
1000 kbit/s	25 m
800 kbit/s	50 m
500 kbit/s	100 m
125 kbit/s	250 m
50 kbits/s	1000 m
20 kbit/s	2500 m

Table 3-1: Maximum CAN bus length

The maximum specified length for the communication bus wiring might not be achieved if wire of poor quality is utilized, there is high contact resistance, or other conditions exist. Reducing the baud rate may overcome these issues.

### DPC - Direct Configuration Interface



#### NOTE

To configure via the configuration interface (direct configuration) you need the configuration cable (ordering code "DPC"), the program LeoPC1 (delivered with the cable) and the corresponding configuration files. Please consult the online help installed when the program is installed for a description of the LeoPC1 program and its setup.

If the parameter "Direct config." is switched to ON, the communication via the interface on terminals X1-X5 is disabled.

# Chapter 4. Functional Description

## Function

### Operating Conditions

#### Idle Control and Synchronization

**Idle control:** Generator voltage and frequency are adjusted to the configured set point values by raising and lowering the controller outputs for voltage and speed/frequency as required.

**Synchronization:** Generator voltage and frequency are adjusted to the busbar values (synchronization GCB) or to the mains values (synchronization MCB) by raising and lowering the controller outputs for voltage and speed as required. The command to connect the appropriate circuit breaker is output with respect to the breaker connect time so the breaker closes at the synchronization point.

Input signals [terminal]				Function	Conditions
Reply: GCB is open [4]	Enable GCB [3]	Reply: MCB is open [54]	Enable MCB [53]		
1	0	x	x	Idle control	A
1	0	x	x	N/A	B
1	1	x	x	Synchronization of the GCB	C
0	x	1	1	Synchronization of the MCB	D

0: "OFF" / 1: "ON" / x: signal has no significance (0 or 1)

Table 4-1: Operating conditions - idle control and synchronization

Voltage and frequency controllers as well as the synchronization can be switched ON or OFF by configuration.

Conditions	Function
A	Parameter "automatic idle control" is ON.
B	Parameter "automatic idle control" is OFF.
C	For the generator and for the busbar variables, the following must apply: - $50\% V_{set} < \text{voltage} < 125\% V_{set}$ - $80\% f_{rated} < \text{frequency} < 110\% f_{rated}$
D	For the busbar and for the mains variables, the following must apply: - $50\% V_{set} < \text{voltage} < 125\% V_{set}$ - $80\% f_{rated} < \text{frequency} < 110\% f_{rated}$ - The "Command: GCB open" may not be apply.

Table 4-2: Operating conditions - idle control and synchronization - conditions

### Dead Bus Start

**Dead bus start:** Output of a connect command for the circuit breaker without synchronization.

Input signals [terminal]				Function	Conditions
Reply: GCB is open [4]	Enable GCB [3]	Reply: MCB is open [54]	Enable MCB [53]		
1	1	1	0	Dead bus start GCB	E
1	x	1	1	Dead bus start MCB	F

0: "OFF" / 1: "ON" / x: signal has no significance (0 or 1)

Table 4-3: Operating conditions - dead bus start

The busbar must be de-energized.

Condition	Function
E	The parameter "Dead bus start generator breaker" is ON and the generator voltage and frequency are within the configured limits.
F	The parameter "Dead bus start mains breaker" is ON and is valid for the mains values: - 50 % $V_{set}$ < voltage < 125 % $V_{set}$ - 42 Hz < frequency < 110 % $f_{rated}$

Table 4-4: Operating conditions - dead bus start - conditions

### Isolated Operation

**Isolated operation:** Generator voltage and frequency are adjusted to the configured set point values by raising and lowering the controller outputs for voltage and speed/frequency as required.

Input signals [terminal]					Function	Conditions
Isolated operation controller ON [35]	Reply: GCB is open [4]	Enable GCB [3]	Reply: MCB is open [54]	Enable MCB [53]		
0	0	x	1	0	no control of f/V	---
1	0	x	1	0	Isolated operation	---

0: "OFF" / 1: "ON" / x: signal has no significance (0 or 1)

Table 4-5: Operating conditions - isolated operation

An isolated operation only takes place if the generator frequency is greater than 42 Hz. Voltage control only takes place if the generator voltage is at least 80 % of the secondary transformer rated voltage and the parameter "Voltage controller isolated operation" is enabled. Voltage, frequency, and synchronization control may be enabled or disabled in the configuration menu.



**NOTE**

When using three-position controllers, these must be configured using the relay manager (see appendix "Relay Manager").



### Mains Parallel Operation

**Mains parallel operation:** The controller outputs raise and lower speed/frequency and voltage to adjust real power and power factor of the generator to the configured set point values.

Input signals [terminal]					Function	Conditions
Isolated operation controller ON [35]	Reply: GCB is open [4]	Enable GCB [3]	Reply: MCB is open [54]	Enable MCB [53]		
x	0	x	0	x	Mains parallel operation	

0: "OFF" / 1: "ON" / x: signal has no significance (0 or 1)

Table 4-6: Operating conditions - mains parallel operation

Mains parallel operation takes place only if the generator frequency is greater than 42 Hz. If during mains parallel operation the generator frequency falls below 50 % of the rated value, the relay "Command: open GCB" is activated.

## Direction of Power



If the unit's current transformers are wired according to the pin diagram shown, the following values are displayed:

- |   |  |
|---|--|
| <p><b>Positive generator real power</b></p> <p><b>Inductive generator power factor</b></p> <p><b>Positive mains real power</b></p> <p><b>Inductive mains power factor</b></p> | <p>The generator supplies real power.</p> <p>The generator is overexcited and supplies inductive reactive power.</p> <p>Real power is supplied to the mains.</p> <p>The mains supplies inductive reactive power.</p> |
|---|--|




Figure 4-1: Direction of power

## Power Factor Definition



The phasor diagram is used from the generator's view. This defines the following definitions.

Power Factor is defined as a ratio of the real power to apparent power. In a purely resistive circuit, the voltage and current waveforms are in step resulting in a ratio or power factor of 1.00 (often referred to as unity). In an inductive circuit the current lags behind the voltage waveform resulting in usable power (real power) and unusable power (reactive power). This results in a positive ratio or lagging power factor (i.e. 0.85lagging). In a capacitive circuit the current waveform leads the voltage waveform resulting in usable power (real power) and unusable power (reactive power). This results in a negative ratio or a leading power factor (i.e. 0.85leading).

<p><b>Inductive:</b> Electrical load whose current waveform lags the voltage waveform thus having a lagging power factor. Some inductive loads such as electric motors have a large startup current requirement resulting in lagging power factors.</p>	<p><b>Capacitive:</b> Electrical load whose current waveform leads the voltage waveform thus having a leading power factor. Some capacitive loads such as capacitor banks or buried cable result in leading power factors.</p>
---	--

Different power factor displays at the unit:

i0.91 (inductive) lg.91 (lagging)	c0.93 (capacitive) ld.93 (leading)
--------------------------------------	---------------------------------------

Reactive power display at the unit:

70 kvar (positive)	-60 kvar (negative)
--------------------	---------------------

Output at the interface:

+ (positive)	- (negative)
--------------	--------------

Compared with the voltage, the current is ...

lagging	leading
---------	---------


The generator is ...

over excited	under excited
--------------	---------------

Control: If the control unit is equipped with a power factor controller, ...

a voltage lower "-" signal is output as long as the measured value is "more inductive" than the reference set point Example: measured = i0.91; set point = i0.95	a voltage raise "+" signal is output as long as the measured value is "more capacitive" than the reference set point Example: measured = c0.91; set point = c0.95
---	--

Phasor diagram:



# Activation of the Circuit Breakers



## Operating Sequence for the MCB

Figure 4-2 represents the switch behavior for the following settings:

MCB open via "Enable MCB": ON

Additional information can be obtained from the descriptions of the configuration screens.




Figure 4-2: Activation of the circuit breakers - MCB

### ON/OFF switching pulse:

1 Synchronization

### → 2 close MCB:

2 closing pulse for the MCB energized

3 breaker inherent delay

4 closing pulse de-energized

## Operating Sequence for the GCB

Figure 4-3 represents the switch behavior for the following settings:

Shutdown: ON

Relay "Command: open GCB", logic: A (operating current; NO)

GCB continuous pulse: OFF

Additional information can be obtained from the descriptions of the configuration screens.




Figure 4-3: Activation of the circuit breakers - GCB

### ON/OFF switching pulse:

1 Synchronization

#### → 2 close GCB:

2 closing pulse for the GCB energized

3 breaker inherent delay

4 closing pulse de-energized

#### → 6 open GCB:

5 start of power reduction

6 end of power reduction

6 opening pulse for the GCB energized

7 opening pulse de-energized

Between 5 and 6 the power is reduced. When the power is close to zero, the GCB is opened.

## Analog Controller Outputs



The control unit may be equipped with an analog controller output in addition to a three-position controller output. Additional configuration screens appear in configuration mode. The analog PID controller forms a closed-loop control loop along with the controlled system (usually a first-order lag element). The parameters of the PID controller (proportional-action coefficient  $K_{PR}$ , derivative-action time  $T_V$  and reset time  $T_n$ ) can be modified individually. The configuration screens are used for this purpose.




Figure 4-4: Closed loop

If an abrupt disturbance variable is applied to the control loop, the reaction of the controlled system can be recorded at the output as a function of time (step response).




Figure 4-5: Step response (example)

Various values can be obtained from the step response; these are required for adjusting the controller to its optimum setting:

**Rise time  $T_{rise}$ :** The period of time starting when a control variable leaves its steady-state condition following a disturbance variable being applied to it and ending the first time the value re-enters the new steady-state condition.

**Transient time  $T_{sett}$ :** The period of time starting when a control variable leaves its steady-state condition following a disturbance variable being applied to it and ending when the value permanently re-enters the new steady-state condition.

**Overshoot  $x_m$ :** Highest transient deviation value during the transition from one steady-state condition to a new steady-state condition following modification of the disturbance variable or reference input variable ( $x_{m\text{Optimal}} \leq 10\%$ ).

**System deviation  $x_d$ :** Permanent deviation from the initial state value (PID controller:  $x_d = 0$ ).

By different conversions from these values, the values  $K_{PR}$ ,  $T_n$  and  $T_V$  can be determined. Moreover, it is possible, by performing various calculations, to determine the optimal controller settings, e. g. by calculating compensation or adjustment of the time constants, T-sum rule, symmetric optimum, Bode-diagram. Other setting procedures and information may be obtained from current literature.

### Controller Setting



#### CAUTION

The following must be observed regarding setting up the controller:

- Ensure that the emergency shutdown system is functional.
- While determining the critical frequency, monitor the amplitude and frequency.
- If either of the two values change uncontrollably:

**→ EMERGENCY SHUTDOWN ←**

**Initial state:** The start position of the controller is determined using the initial state of the controller. If the controller is switched off, the basic setting can be used to output a fixed controller position. If the genset is not running, the controller automatically resets to the initial state.

Initial state frequency = 000%
-----------------------------------

#### Initial state frequency controller

**0 to 100 %**

Analog controller output setting with controller switched off. This value is also used as the control start point when the generator is initially started.

**General settings:** The setting rule described below only serves as an example. Whether this method is suitable for setting your particular controlled system has not been and cannot be taken into account as each controlled system behaves uniquely.

There are various methods of setting a controller. The setting rules of Ziegler and Nichols are explained below (determination for abrupt disturbances on the system input); this setting method assumes a pure lag element connected in series with a first-order lag system.

1. Controller operated as a P-only controller (where  $T_n = \infty$  [Parameter setting:  $T_n = 0$ ],  $T_v = 0$ ).
2. Increase gain  $K_{PR}$  (P gain) until the control loop oscillates continuously at  $K_p = K_{p,crit}$



**CAUTION**

If the engine starts to oscillate uncontrollably, perform an emergency shutdown and alter the screen setting accordingly.

3. At the same time: measure the critical cycle duration  $T_{crit}$ .
4. Set the parameters:

**PID controller**

$$K_{PR} = 0.6 \times K_{p,crit}$$

$$T_n = 0.5 \times T_{crit}$$

$$T_v = 0.125 \times T_{crit}$$

**PI controller**

$$K_{PR} = 0.45 \times K_{p,crit}$$

$$T_n = 0.83 \times T_{crit}$$




Figure 4-6: Step response - controller setting

**P-gain**  
 $K_{pr} = 000$

**P gain ( $K_{PR}$ )** Proportional action coefficient

**1 to 240**

The proportional-action coefficient  $K_{PR}$  indicates the closed-loop control system gain. By increasing the gain, the response is increased to permit larger corrections to the variable to be controlled. The farther out of tolerance the process is the larger the response action is to return the process to the tolerance band. If the gain is configured too high, the result is excessive overshoot/undershoot of the desired value.

**Reset time**  
 $T_n = 00,0s$

**Reset time ( $T_n$ )**

**0.2 to 60.0 s**

The reset time  $T_n$  represents the I-component of the PID controller. The reset time corrects for any offset (between setpoint and process variable) automatically over time by shifting the proportioning band. Reset automatically changes the output requirements until the process variable and the setpoint are the same. This parameter permits the user to adjust how quickly the reset attempts to correct for any offset. The reset time constant must be greater than the derivative time constant. If the reset time constant is too small, the engine will continually oscillate. If the reset time constant is too large, the engine will take a long time to settle at a steady state.

**Rate time**  
 $T_v=0,00s$

**Rate time ( $T_v$ )**

**0.00 to 6.00 s**

The derivative-action time  $T_v$  represents the D-component of the PID controller. By increasing this parameter, the stability of the system is increased. The controller will attempt to slow down the action of the throttle in an attempt to prevent excessive overshoot or undershoot. Essentially this is the brake for the process. This portion of the PID loop operates anywhere within the range of the process unlike reset.



## Load and/or Var Sharing



The control ensures load and/or var sharing proportional to the rated power of the generators under every operating condition (mains parallel operation, isolated operation in parallel with other gensets, or reverse synchronization of the busbar to the mains).

The controller can communicate with up to 14 generators with a maximum power rating of 16MW each. Any controller not in constant power/base load mode and that has the GCB closed will load and/or var share.

**Operating in mains parallel with mains interchange (import/export) real power control:** Each controller participating in load/var sharing controls the generator set that it is assigned so the real power set point at the mains interchange remains constant. The real power set point for the mains interchange must be configured identically in each controller.

All controllers communicate via a CAN bus. This enables the controllers to adjust the real power generated by the generator while remaining within the rated power of the generator. A smaller generator will contribute less real power as compared to a large generator, but they will both be utilized to the same capacity factor. An example of this would be a 100KW generator and a 1000KW generator and a mains interchange of 825KW. The 100KW generator would contribute 75KW and the 1000KW generator would contribute 750 KW or both generators would be at 75% of their rated capacity.

No reactive power sharing is performed when operating in parallel with the mains. The reactive power will be defined by the configured power factor set point of the individual controllers.

The parameter "kW/kvar sharing: reference variable kW" can be used now to define the priority of the reference variable (real power at interchange) for real power sharing. A higher percentage influences the control more towards the real power set point for the interchange. A lower percentage influences the control more towards real power sharing.

The parameter "kW/kvar sharing: reference variable kvar" has no influence here.

**Isolated operation in parallel:** Each controller participating in load/var sharing controls the generator set to which it is assigned in such a manner that the set frequency and the set voltage at the bus remain constant. This makes it imperative that the same frequency and voltage set points are configured for each controller.

All controllers communicate via a CAN bus. This enables the controllers to adjust the real power generated by the generator while remaining within the rated power of the generator. A smaller generator will contribute less real power as compared to a large generator, but they will both be utilized to the same capacity factor. An example of this would be a 100KW generator and a 1000KW generator and a load of 825KW. The 100KW generator would contribute 75KW and the 1000KW generator would contribute 750 KW or both generators would be at 75% of their rated capacity.

The reactive power will be allocated in a way that it is the same for all generators involved.

The parameter "kW/kvar sharing: reference variable kW" can be used now to define the priority of the reference variable (frequency) for real power sharing. A higher percentage influences the control more towards frequency control. A lower percentage influences the control more towards real power sharing.

The parameter "kW/kvar sharing: reference variable kvar" can be used now to define the priority of the reference variable (voltage) for reactive power sharing. A higher percentage influences the control more towards voltage control. A lower percentage influences the control more towards reactive power sharing.

**Reverse synchronization of the busbar to the mains:** Distribution is carried out according to the type of isolated operation. The set point value for the bus frequency is determined by the mains frequency +  $df_{max}/2$ .

Example: If  $df_{max} = 0.2$  Hz, this results for  $df_{max}/2 = 0.1$  Hz (i.e. in a system of 50 Hz, the busbar will be raised to 50.1 Hz).

**Pre-requisites:** It is imperative that the rated system frequencies (page 64) and the circuit breaker logic (page 88) are set identically for all units participating in load/var sharing.

**Description of the interface for load/var sharing:** Load/var sharing is based on a multi-master-capable bus between the controls. This structure enables the parallel operation of up to 14 generators.

**The following must be noted to ensure trouble-free operation of the CAN bus:**

1. The maximum CAN bus length must not exceed 250 meters.
2. The CAN bus must be terminated at each end with terminating resistors that correspond to the wave impedance of the CAN bus cable (approx. 120 ohm).
3. The CAN bus must be of a linear structure. Dead-end feeders are not permissible.
4. The recommended cable for use as the CAN bus cable is a "Twisted-shielded-pair" (Ex.: Lappkabel Uni-tronic LIYCY (TP) 2×2×0.25, UNITRONIC-Bus LD 2×2×0.22).
5. The CAN bus cable must not be routed in the vicinity of high current power lines.

**Schematic of the load/var sharing via CAN bus:**

Each single unit compares the utilization factor of its generator with the mean utilization factor of all other generators. This control difference is compared with the control difference of the reference variable (e.g. frequency set point – measured frequency) and results a new reference variable.

Frequency control is carried out via the measured voltage/frequency of the voltage system.




Figure 4-7: Load/var sharing - schematic

## Language Manager



### NOTE

Please also note the parameters to this option in chapter Language Manager at page 56.

In order to load a different language into the unit, please proceed as follows:

1. Establish a connection between your PC and the unit via the direct configuration cable (DPC) or via a Gateway GW 4. To do this, connect the serial cable end to the COM port of your PC and insert the RJ45 plug in the socket on the side of the unit.
2. Enter the password for code level 2 into the unit. Also read chapter Password Protection at page 59.
3. Scroll down through the display to the configuration screen "load language".
4. Enter "YES" to load the language.
5. Scroll down only until you reach the configuration screen "language number" and select the base language in which you enter "0".
6. Enter in the "number of tool" screen the numbers (1 to 8) with which you operate the MFR via LeoPC1. These numbers are identical to the unit numbers.
7. Now start the LeoPC1 and load the corresponding configuration file. Ensure, that direct configuration is selected in the device settings in LeoPC1 and the connection between device and LeoPC1 has been started.
8. Open the "Load Language" window and load the desired language file.
9. Go to the "Which texts have to be transferred?" area and select "All texts". Next click on the "Transfer language" button to start loading the file into the control unit.
10. If, after transmission of the first language an additional language is to be loaded, the SECOND language must be selected in the configuration screen "Sprache/language" of the unit or enter a "one" in the "Language number" screen. Next repeat steps 6 through 9.
11. It is also possible to load a language via the CAN interface. If this method is utilized, the direct configuration port is disabled in the device and the data communication settings in LeoPC1 must be changed to CAN.

# Alarms



## Alarm Class

The monitoring functions are divided into four alarm classes:

**F0 - Warning alarm** - This alarm does not lead to an interruption of the operation. An alarm message is displayed without a centralized alarm.

→ Alarm text.

**F1 - Warning alarm** - This alarm does not lead to an interruption of the operation. An alarm message is displayed and a centralized alarm will be output.

→ Alarm text + flashing LED "Alarm" + Relay "Centralized alarm" (horn).

**F2 - Triggering alarm** - This alarm leads to a soft shutdown. A power reduction is performed prior to the GCB being opened. A cool down period is also carried out.

→ Alarm text + flashing LED "Alarm" + Relay "Centralized alarm" (horn) + cool down.

**F3 - Triggering alarm** - This alarm leads to the immediate opening of the GCB and a hard shutdown.

→ Alarm text + flashing LED "Alarm" + Relay "Centralized alarm" (horn) + immediate shutdown.

## Internally Detected Alarms

List of alarms determined internally depending on the monitored variables:

Type of alarm	see page	Alarm class	Alarm text	Relay output (terminal)
Generator overfrequency, level 1	107	F3	Gen.overfreq. 1	
Generator overfrequency, level 2	107	F3	Gen.overfreq. 2	
Generator underfrequency, level 1	108	F3	Gen.underfreq. 1	
Generator underfrequency, level 2	108	F3	Gen.underfreq. 2	
Generator overvoltage, level 1	109	F3	Gen.overnvolt. 1	
Generator overvoltage, level 2	109	F3	Gen.overnvolt. 2	
Generator undervoltage, level 1	110	F3	Gen.undervolt. 1	
Generator undervoltage, level 2	110	F3	Gen.undervolt. 2	
Generator time-overcurrent, level 1	99	F3	Gen.overcurr. 1	
Generator time-overcurrent, level 2	99	F3	Gen.overcurr. 2	
Reverse/reduced load	96	F3	Revers/min.power	
Overload	97	F2	Gen.overload	
Unbalanced load	105	F3	Load unbalance	
Mains overvoltage	112	F0	Mains-overnvolt.	
Mains undervoltage	112	F0	Mains-undervolt.	
Main overfrequency	111	F0	Mains-underfreq.	
Mains underfrequency	111	F0	Mains-overfreq.	
Mains phase/vector jump	114	F0	Phase shift	
Mains df/dt	116	F0	df/dt error	
Battery undervoltage	117	F1	Batt.undervolt.	
GCB synchronization time monitoring	92	F1	GCB syn.failure	
MCB synchronization time monitoring	92	F1	MCB syn.failure	
Switching to dead busbar time monitoring	93	F1	Failure df/dVmax	
Mechanical GCB malfunction on closing	94	F1	GCBclose failure	
Mechanical MCB malfunction on closing	94	F1	MCBclose failure	
Mechanical GCB malfunction on opening	94	F1	GCB open failure	
Mechanical MCB malfunction on opening	94	F1	MCB open failure	
Faulty ref.power zero contr.with interch.syn. GCB	88	F1	Power not zero	
Maintenance call	131	F1	Service	
Interface error X1 to X5	87	F1	Interf.err. X1X5	
Interface error Y1 to Y5	87	F1	Interf.err. Y1Y5	
Rotation field mismatch	91	.*	Phase sequence!	
Generator reactive power, capacitive	98		Gen.reac.pow.cap	
Generator reactive power, inductive	98		Gen.reac.pow.ind	

**Note:** In the event of mains faults, the GCB or the MCB is opened according to the configuration, and is closed again following the mains settling time.

\* This message is no alarm message in the actual sense, but an informative message, which does not have to be acknowledged and causes no shutdown of the engine. The display disappears automatically after correcting the rotating field.

Table 4-7: Alarms - text messages

## Alarm Acknowledgement

By pressing the "ACK" push button, the output of the centralized alarm and the alarm messages on the LC display are acknowledged according to the following logic:

**Horn:** After 2 minutes the horn is reset regardless of the acknowledgement of an alarm.

**Interface:** All internal alarms are communicated via the interface.



### NOTE

The control unit does not differentiate between short and long alarm acknowledgements when given through the interface. As soon as the acknowledgement bit is enabled via the interface, a "Long acknowledgement" will be performed. A "Short acknowledgement" via the interface is not possible.

### Short acknowledgment (< 2.5 s)

#### Action

- The "ACK" push-button is pressed for  $0.5\text{ s} < t < 2.5\text{ s}$
- The terminal 36 is energized for  $0.5\text{ s} < t < 2.5\text{ s}$

#### Result

The "Alarm" LED changes from blinking to continually illuminated and the horn is silenced.

Operating mode	Acknowledgment via ...		
	"ACK" button	terminal 36	interface input
AUTO	possible	possible	not possible
MANUAL	possible	not possible	not possible

Table 4-8: Alarms - short acknowledgment

### Long acknowledgment (>2.5 s)

#### Action

- The "ACK" push-button is pressed for  $t > 2.5\text{ s}$
- The terminal 36 is energized for  $t > 2.5\text{ s}$
- The acknowledge bit is enabled via the interface

#### Result

An alarm cannot be acknowledged if the fault condition still exists. If the fault condition is no longer present:

- The "Alarm" LED turns off
- The F1, F2 and F3 alarm relays are reset
- The display messages are acknowledged

Operating mode	Acknowledgment via ...		
	"ACK" button	terminal 36	interface input
AUTO	possible	possible	possible
MANUAL	possible	not possible	not possible

Table 4-9: Alarms - long acknowledgment

# Chapter 5. Display and Push-Buttons

The pressure-sensitive membrane of the front panel consists of a plastic coating. All keys have been designed as touch-sensitive membrane switch elements. The display is an LC display, comprised of 2 lines with 16 characters each, which are indirectly illuminated in red. The contrast of the display can be infinitely adjusted via a rotary potentiometer positioned on the left side. The configuration plug is located on the left side of the unit. The direct configuration cable (DPC) connects there.




Figure 5-1: Front panel MFR 31




Figure 5-2: Front panel MFR 32

## Brief Description of LED and Push-Buttons



### LEDs

No.	Description	Function
1	V1	Voltage L1
2	V2	Voltage L2
3	V3	Voltage L3
5	-7%..fn..+7%	Synchroscope
6	Automatic	Operating mode AUTOMATIC selected
7	Manual	Operating mode MANUAL selected
8	Monitoring	Monitoring is activated
9	Alarm	Alarm is active
10	GCB is closed	Reply: GCB is closed
11	MCB is closed	Reply: MCB is closed

### Push-Buttons

No.	Description	Function
12	Message↓	Route messages
12	Select	Confirm selection
13	Display V↓	Route voltage display
13	Digit↑	Increase digit
14	Set point	Activate set point value
14	Cursor→	Move cursor one position right
15	Set point↑	Increase MANUAL set point value
16	Set point↓	Decrease MANUAL set point value
17	GCB ON	Close GCB manually
18	GCB OFF	Open GCB manually
19	MCB ON	Close MCB manually
20	MCB OFF	Open MCB manually
21	MAN	Select operating mode MAN
23	LED TEST	Execute LED test
24	ACK	Acknowledge alarm messages
25	AUTO	Select operating mode AUTOMATIC
26	Set point↑	Increase AUTO setpoint value
27	Set point↓	Decrease AUTO setpoint value

### Miscellaneous

No.	Description	Function
28	LC display	LC display
29	DPC plug	Configuration plug
30	Potentiometer	Adjust LCD contrast

## LEDs



- |           |                                |                                      |   |           |                   |       |                   |
|-----------|--------------------------------|--------------------------------------|---|-----------|-------------------|-------|-------------------|
| <b>1</b>  | <b>V1 - V2 - V3</b>            | <b>Voltage control</b>               |   |           |                   |       |                   |
| <b>2</b>  | Color: Green                   |                                      |   |           |                   |       |                   |
| <b>3</b>  |                                |                                      | The LED's "V1", "V2" and "V3" show which voltage ( $V_{L1N}$ , $V_{L2N}$ , $V_{L3N}$ , $V_{L12}$ , $V_{L23}$ or $V_{L31}$ ) is currently being displayed. This applies both to the generator and the mains voltage display.   |           |                   |       |                   |
| <b>5</b>  | <b>-7%..f<sub>N</sub>..+7%</b> | <b>Phase position / synchroscope</b> |   |           |                   |       |                   |
|           | Color: Red/Yellow/Green        |                                      |   |           |                   |       |                   |
|           |                                |                                      | The LED's between -7 % and +7 % serve to visualize the generator frequency. The rated frequency ( $f_N$ ) is entered in the "generator rated frequency" screen. If the frequency is greater than +7 % or less than -7 %, the corresponding outer LED flashes.<br>As soon as the synchronization is started, the double voltage/double frequency display appears and the synchroscope becomes active. The LEDs show the current phase angle between the two displayed voltages. The green LED in the center of the 15 LED's indicates that the measured phase angle between the voltage systems displayed is less than 12 ° electrical. The phase angle is only displayed if the frequencies of the two voltages are within the following permissible ranges:<br><br><table border="0" style="margin-left: 20px;"> <tr> <td style="padding-right: 20px;">Generator</td> <td>88 to 112 % <math>f_N</math></td> </tr> <tr> <td>Mains</td> <td>96 to 104 % <math>f_N</math></td> </tr> </table><br>A distinction is made between two directions of rotation:<br>-7 % → +7 % = The LEDs illuminate from left to right, the generator frequency is higher than the mains.<br>+7 % → -7 % = The LEDs illuminate from right to left, the generator frequency is lower than the mains. | Generator | 88 to 112 % $f_N$ | Mains | 96 to 104 % $f_N$ |
| Generator | 88 to 112 % $f_N$              |                                      |   |           |                   |       |                   |
| Mains     | 96 to 104 % $f_N$              |                                      |   |           |                   |       |                   |
| <b>6</b>  | <b>Automatic</b>               | <b>Operating mode AUTOMATIC</b>      |   |           |                   |       |                   |
|           | Color: Green                   |                                      |   |           |                   |       |                   |
|           |                                |                                      | When the AUTOMATIC operation mode has been selected, the "Automatic" LED is illuminated. The "Setpoint↑", "Setpoint↓", "GCB ON", "GCB OFF", "MCB ON", and "MCB OFF" push buttons (for the operating mode MANUAL) are disabled.  |           |                   |       |                   |
| <b>7</b>  | <b>Manual</b>                  | <b>Operating mode MANUAL</b>         |   |           |                   |       |                   |
|           | Color: Green                   |                                      |   |           |                   |       |                   |
|           |                                |                                      | When the MANUAL operation mode has been selected, the "Manual" LED is illuminated. The push buttons "Setpoint↑" and "Setpoint↓" (for the operating mode AUTOMATIC) are disabled.  |           |                   |       |                   |



8	<b>Monitoring</b> Color: Green	<b>Monitoring</b>	If the "Monitoring" LED is illuminated, monitoring is enabled. The delayed programmed alarm inputs are monitored in addition to the permanently monitored alarm inputs. Generator underspeed, underfrequency, undervoltage and reverse power are also monitored.
9	<b>Alarm</b> Color: Red	<b>Alarm</b>	The unit has detected an alarm condition when the "Alarm" LED is illuminated. The control unit reacts according to the alarm class. The alarm message is shown in the LC display. If the alarm LED is flashing, a new alarm condition has occurred within the last two minutes. By performing a short acknowledgment, the alarm LED changes to continuous illumination and the centralized alarm (horn) is terminated.
10	<b>GCB on</b> Color: Green	<b>Reply: GCB is closed</b>	The "GCB ON" LED indicates that the GCB is closed when illuminated.
11	<b>MCB on</b> Color: Green	<b>Reply: MCB is closed</b>	The "MCB ON" LED indicates that the MCB is closed when illuminated.

## Push-Buttons



In order to facilitate configuring the parameters, the push buttons have an AUTOROLL function. It permits the user to advance to the next setting, configuration screen, the digit, and/or cursor position by pressing and holding the corresponding push button.

### General / Configuration

12	<b>Message↓ / Select</b> Color: Blue	<b>Message↓ / Select</b>	<p><b>Normal operation:</b> <u>Message↓</u> - By pressing this push button, the user may advance through the operating and alarm messages.</p> <p><b>Configuration:</b> <u>Select</u> - The user advances to the next configuration screen by pressing this button. If the original displayed value has been changed by pressing either the "Digit↑" or "Cursor→" push buttons, the new value is saved by pressing the "Select" push button once. By pressing this push-button again, the user causes the system to display the next configuration screen.</p>
----	---	--------------------------	--

- |          |   |  |
|----------|---|--|
| 13       | <b>Display V↓ / Digit↑</b><br>Color: Blue   | <b>Display V↓ / Digit↑</b> <hr/> <p><b>Normal operation:</b> <u>Display V↓</u> - By pressing this push-button, the generator and mains voltage display is moved forwards. <b>Note:</b> If this push-button is pressed for at least 5 seconds, the counter that is currently been displayed is (re)set.</p> <p><b>Configuration:</b> <u>Digit↑</u> - With this push-button, the number at which the cursor is currently located is increased by one digit. The increase is restricted by the admissible limits (see list of parameters included in the appendix). In case the maximum number is reached which can be set, the number automatically returns to the lowest admissible number.</p>   |
| 14       | <b>Setpoint / Cursor→</b><br>Color: Blue    | <b>Setpoint / Cursor→</b> <hr/> <p><b>Normal operation</b> <u>Setpoint</u> - By pressing this push-button, the individual setpoint values are displayed. The displayed setpoint values can be adjusted with the "Setpoint↑" or "Setpoint↓" push-buttons (depending on the selected operating mode alternatively the setpoint values for the operating modes AUTOMATIC or MANUAL can be changed). Certain setpoint values, which are entered into the unit from external sources, can only be displayed.</p> <p><b>Configuration</b> <u>Cursor→</u> - This push-button is used to move the cursor one position to the right. When the last right-hand position is reached, the cursor automatically moves to the first position left-hand of the value to be entered.</p> |
| 15<br>16 | <b>Setpoint↑ / Setpoint↓</b><br>Color: Blue | <b>Setpoint↑ / Setpoint↓ - operating mode AUTOMATIC</b> <hr/> <p>By pressing the "Setpoint↑" or "Setpoint↓" push-buttons, the setpoint selected via the "Setpoint" push-button for the operating mode AUTOMATIC is changed accordingly. Only those values which are available in the relevant operating mode and which were switched on during configuration can be changed.</p>   |
| 26<br>27 | <b>Setpoint↑ / Setpoint↓</b><br>Color: Blue | <b>Setpoint↑ / Setpoint↓ - operating mode MANUAL</b> <hr/> <p>By pressing the "Setpoint↑" or "Setpoint↓" push-buttons, the setpoint selected via the "Setpoint" push-button for the operating mode MANUAL is changed accordingly. Only those values which are available in the relevant operating mode and which were switched on during configuration can be changed.</p>   |

## Control of the Power Circuit Breakers

17 **GCB ON / GCB OFF** **Close GCB / open GCB**  
 18 Color: Green/Red

---

Note: This function is only enabled if the MANUAL operation mode has been enabled.

**GCB ON.....** Depending on which power circuit breaker logic has been selected, the GCB can be closed by pressing the "GCB ON" push button. This process can be aborted if either the "GCB OFF" or "MCB ON" push buttons are pressed or the operating mode is changed.

**GCB OFF....** Depending on which power circuit breaker logic has been selected, the GCB can be opened or synchronization of the GCB can be aborted by pressing the "GCB OFF" push-button.

19 **MCB ON / MCB OFF** **Close MCB / open MCB**  
 20 Color: Green/Red

---

Note: This function is only enabled if the MANUAL operation mode has been enabled.

**MCB ON.....** Depending on which power circuit breaker logic has been selected, the MCB can be closed by pressing the "MCB ON" push button. This process can be aborted if either the "MCB OFF" or "GCB ON" push buttons are pressed or the operating mode is changed.

**MCB OFF ...** Depending on which power circuit breaker logic has been selected, the MCB can be opened or synchronization of the MCB can be aborted by pressing the "MCB OFF" push button.

## Operating Mode Selector



### NOTE

It is possible to block the MANUAL and AUTOMATIC operation mode push buttons by enabling the discrete input [D02] (terminal 63), preventing the operating mode from being changed.

21 **MAN** **Select operating mode MAN**  
 Color: Blue

---

If the MANUAL operation mode is selected, automatic control of the power circuit breaker control is disabled. The push buttons are used to control the equipment manually. Critical automatic processes continue to remain in operation (e.g. mains watchdog function for mains parallel operation).

- 23            **LED Test**    **Check LED's**  
 Color: Blue

All control unit LED's are illuminated by pressing this button to check for proper operation.
- 24                   **ACK**        **Acknowledgment**  
 Color: Blue

Alarm messages are acknowledged pressing the "ACK" push button. The alarm messages on the LC display are cleared and the "Alarm" LED will darken. The display is reset to the basic screen. Class F2 and F3 alarms can only be acknowledged in the MANUAL operation mode. Refer to Alarm Acknowledgement on page 45.
- 25                   **AUTO**      **Select operating mode AUTOMATIC**  
 Color: Blue

If the AUTOMATIC operation mode is selected, automatic control of the power circuit breaker control is enabled. By energizing or de-energizing "Set point 1↔2" (terminal 5), the power set point can be changed.

  - Terminal 5 "Setpoint 1↔2" de-energized:  
 Real power set point 1 is active.
  - Terminal 5 "Setpoint 1↔2" energized:  
 Real power set point 2 or an external setpoint value is active. The user may configure if set point 2, a 0/4-20 mA input, or an interface is to be utilized.

## LC Display



- 28            **LC display**    **LC display**


The LC display shows messages and values, depending on the respective mode applied. In configuration mode, the individual parameters are displayed and changed. In automatic mode the operating variables (e. g. voltages and currents) can be called up.



**NOTE**

Using push-button "Display V↓" the voltages can be displayed.

### Automatic Mode (First Display Line: Measuring Values)



**Display in automatic mode, first line: measuring value**

The following measuring values are displayed (depending on the LEDs V1/V2/V3) on the top line of the display:

- "xxxx" - generator voltage relating to which LEDs V1/V2/V3 are illuminated:
 

V1 illuminates	line-to-neutral voltage	$V_{L1-N}$ ;
V2 illuminates	line-to-neutral voltage	$V_{L2-N}$ ;
V3 illuminates	line-to-neutral voltage	$V_{L3-N}$ ;
V1&V2 illum.	line-to-line voltage	$V_{L1-L2}$ ;
V2&V3 illum.	line-to-line voltage	$V_{L2-L3}$ ;
V3&V1 illum.	line-to-line voltage	$V_{L3-L1}$ .
- "yyy" - generator currents (line currents  $I_{L1}$ ,  $I_{L2}$  and  $I_{L3}$ ).

## Automatic Mode (Second Display Line: Measuring Values)



### NOTE

The bottom line can be scrolled using the "Message↓" push button. It is also possible, to scroll through any alarms that may be present using the "Message↓" push button.



#### Display in automatic mode, second line: measuring values

The following measured values are displayed in the "xxxxxxxx" area shown to the left:

##### Basic screen:

- generator cosphi/power factor
- actual generator real power
- the unit operation currently being carried out (synchronization, etc.)

##### Subordinate screen: Depending on the unit's equipment

- mains voltage
- mains current/power
- mains cosphi/power factor
- analog inputs
- generator real power
- generator re-active power (determined using phase L1 current; also if "three-phase" power measurement was selected)
- operating hours
- time remaining to the next maintenance call
- start counter
- battery voltage (power supply)
- number of subscribers participating in load sharing
- maximum generator current (slave pointer)
- the four alarm messages which occurred first
- time/date
- energy counter kWh and kvarh

These screens are displayed in succession by pressing the "Message↓" push button. When the last screen has been reached, the basic screen is displayed. If alarms have occurred, the related message texts are displayed in the sequence of their occurrence prior to the basic screen. If unit functions are active (e.g. synchronization of the GCB), the basic screen is superimposed with the corresponding message (e.g. "synchronization"). Following the termination of the unit function, the basic screen is displayed again.

## Automatic Mode (Second Display Line: Alarm Display)



### NOTE

It is possible to scroll through any alarms that may be present using the "Message↓" push-button.



#### Display in automatic mode, second line: alarms

If an alarm occurs the message is displayed in the second line of the LC display according to the following list.

Type of alarm	see page	Alarm class	Alarm text	Relay output (terminal)
Generator overfrequency, level 1	107	F3	Gen.overfreq. 1	
Generator overfrequency, level 2	107	F3	Gen.overfreq. 2	
Generator underfrequency, level 1	108	F3	Gen.underfreq. 1	
Generator underfrequency, level 2	108	F3	Gen.underfreq. 2	
Generator overvoltage, level 1	109	F3	Gen.overnvolt. 1	
Generator overvoltage, level 2	109	F3	Gen.overnvolt. 2	
Generator undervoltage, level 1	110	F3	Gen.undervolt. 1	
Generator undervoltage, level 2	110	F3	Gen.undervolt. 2	
Generator time-overcurrent, level 1	99	F3	Gen.overcurr. 1	
Generator time-overcurrent, level 2	99	F3	Gen.overcurr. 2	
Reverse/reduced load	96	F3	Revers/min.power	
Overload	97	F2	Gen.overload	
Unbalanced load	105	F3	Load unbalance	
Mains overvoltage	112	F0	Mains-overnvolt.	
Mains undervoltage	112	F0	Mains-undervolt.	
Main overfrequency	111	F0	Mains-underfreq.	
Mains underfrequency	111	F0	Mains-overfreq.	
Mains phase/vector jump	114	F0	Phase shift	
Mains df/dt	116	F0	df/dt error	
Battery undervoltage	117	F1	Batt.undervolt.	
GCB synchronization time monitoring	92	F1	GCB syn.failure	
MCB synchronization time monitoring	92	F1	MCB syn.failure	
Switching to dead busbar time monitoring	93	F1	Failure df/dVmax	
Mechanical GCB malfunction on closing	94	F1	GCBclose failure	
Mechanical MCB malfunction on closing	94	F1	MCBclose failure	
Mechanical GCB malfunction on opening	94	F1	GCB open failure	
Mechanical MCB malfunction on opening	94	F1	MCB open failure	
Faulty ref.power zero contr.with interch.syn. GCB	88	F1	Power not zero	
Maintenance call	131	F1	Service	
Interface error X1 to X5	87	F1	Interf.err. X1X5	
Interface error Y1 to Y5	87	F1	Interf.err. Y1Y5	
Rotation field mismatch	91	.*	Phase sequence!	
Generator reactive power, capacitive	98		Gen.reac.pow.cap	
Generator reactive power, inductive	98		Gen.reac.pow.ind	

**Note:** In the event of mains faults, the GCB or the MCB is opened according to the configuration, and is closed again following the mains settling time.

\* This message is no alarm message in the actual sense, but an informative message, which does not have to be acknowledged and causes no shutdown of the engine. The display disappears automatically after correcting the rotating field.

Table 5-1: Alarms - text messages

# Chapter 6. Configuration

---

Configuration can be performed via the front panel push buttons and LC display or using a PC and the LeoPC1 program with the serial interface. Additionally it is possible to configure the unit via CAN bus. The following baud rates apply to each method:

- Direct configuration                    9,600 Baud (8 bit, no parity, 1 stop bit)
- CAN bus configuration                125 kBaud



## CAUTION

Please note that configuration only should be performed when system is not operating.

Generator voltage must not be connected during configuration and the DI "Configuration blocked" (terminal 34) must be de-energized.

Code level 2 access is required to select between direct configuration or configuration via CAN.



## NOTE

Refer to Appendix B for a complete list of parameters at the end of this manual.

# Introduction



The configuration screens have an AUTOROLL function when you are in configuration mode (simultaneously pressing "Digit↑" and "Cursor→"). If the "Select" button is pressed and held, the scroll function will be activated and the user will be able to rapidly advance through the parameter screens. It is possible to back-up four configuration screens (exception: the break from the first to the last screen is not possible). To do this, simultaneously press and release the "Select" and "Cursor→" buttons. If an action, entry, or modification, is not performed within 60 seconds, the unit reverts to the automatic mode.



## NOTE

There are two different hardware versions described in this manual: A 100 Vac version [1] and a 400 Vac version [4]. The two versions vary as far as the configuration screens, the input of the parameters and the setting limits are concerned. The respective voltage values ([1]... or [4]...) are placed first to differentiate the two types.

# Basic Data



## Language Manager

Parameter 1

Sprache/language  
-----

Language first/second

first .....All texts are displayed in the base/first language.  
second.....All texts are displayed in the second language.

Parameter 2

Load language  
YES

Load language YES/NO

YES .....A language file may be loaded if code level 2 has been activated.  
NO .....Language loading capabilities are disabled. The following related configuration screens are not displayed.

Parameter 3

Language number  
0

Language selection 0/1

The number entered here determines if the first or second language is to be loaded.  
0 .....The base/first language is to be loaded.  
1 .....The second language is to be loaded.

Parameter 4

Number of tool  
00

Unit number on the CAN bus 1 to 14

If the control unit language is being modified over the CAN bus, the assigned unit number must be entered here. If the control unit language is being modified via the DPC, it is not necessary to enter a value in this screen (refer to next parameter).





**NOTE**

Please also note chapter "Direct Configuration" on page 63.

Parameter 5

Direct para. YES
---------------------

**Direct configuration**

YES/NO

**YES**..... The language will be uploaded via the DPC and the DPC connection is disabled.

**NO**..... The language will be uploaded via the CAN bus and the DPC connection is disabled.

**Version Number**

Parameter 6

Software version Vx.xxxx
-----------------------------

**Software version**

Display of the current software version.

**Service Display**

Parameter 7

Service display ON
-----------------------

**Service display**

ON/OFF

**ON**..... The following three screens are displayed:

- the generator and busbar voltages and frequencies
- the mains and busbar voltage and frequencies
- the controller breaker and relay statuses during synchronization

The specific displayed values are dependent upon the control unit hardware.

**OFF**..... The service display is disabled.

**Service Display for Versions without Potential Transformers (400 V)**

B: 000V 00,00Hz
G: 000V 00,00Hz

**Double voltage/frequency display**

The generator and busbar voltage and frequency are displayed. The phase angle between the generator and busbar is displayed by the synchroscope (LED strip):

**B**..... Busbar voltage and frequency

**G**..... Generator voltage and frequency

M: 000V 00,00Hz
B: 000V 00,00Hz

**Double voltage/frequency display**

The busbar and mains voltage and frequency are displayed. The phase angle between the busbar and mains is displayed by the synchroscope (LED strip):

**M**..... Mains voltage and frequency

**B**..... Busbar voltage and frequency

**Service Display for Versions with Voltage Transformers (100 V)**

B	00,0kV	00,00Hz
G	00,0kV	00,00Hz

**Double voltage/frequency display**

---

The generator and busbar voltage and frequency are displayed. The phase angle between the generator and busbar is displayed by the synchroscope (LED strip):

- B** .....Busbar voltage and frequency
- G** .....Generator voltage and frequency

M	00,0kV	00,00Hz
B	00,0kV	00,00Hz

**Double voltage/frequency display**

---

The busbar and mains voltage and frequency are displayed. The phase angle between the busbar and mains is displayed by the synchroscope (LED strip):

- M** .....Mains voltage and frequency
- B** .....Busbar voltage and frequency

**Status of Relays During Synchronization**

Rel.:	MCB
f	V
	GCB

**Status of breakers and relays of the controller**

---

This screen displays the real-time statuses for the three-position controller outputs with respect to the analog controller and the signals issued to the power circuit breaker during synchronization:

- f**.....+      Frequency controller raise      terminal 8/9
- Frequency controller lower      terminal 8/10
- V**.....+      Voltage controller raise      terminal 11/12
- Voltage controller lower      terminal 11/13
- MCB**.....on      Close pulse of the MCB      terminal 16/17
- off      Open pulse of the MCB      terminal 39/40
- GCB**.....on      Close pulse of the GCB      terminal 14/15
- off      Open pulse of the GCB      terminal 41/42

## Password Protection



The unit is equipped with a three-level code and configuration hierarchy. This permits multiple levels of access to configuration screens for different users. A distinction is made between:

**Code level 0 (CS0) - User: Third Party**

Only monitoring of measured values is permitted. The configuration of parameters is blocked.

**Code level 1 (CS1) - User: Customer**

Monitoring of measured values and select parameters may be changed (e.g. rated power, etc.). Changing a password is not possible in this level.

**Code level 2 (CS2) - User: Commissioner**

The user has complete access to display and change all parameters. The user may also set and change passwords for code levels 1 and 2 (see below).



**NOTE**

**Access codes remain active for two hours after the last action is performed, even if the configuration mode is accessed repeatedly. If an incorrect password is entered, the control unit reverts to code level CS0 and external users are blocked from accessing the unit (setting of password on page 72). The desired code level may be accessed again by entering the correct password for that code level.**

Parameter 8

Enter code	0000
------------	------

**Enter code number**

**0000 to 9999**

To access the configuration mode, the control unit requests the code number that is specific to a code level. The number in the LC display is a randomly generated number (RN) and may be confirmed by pressing the "Select" push button. If the random number is confirmed the code level remains at its current level. Two four-digit code numbers (0000 to 9999) exist for accessing the code levels or setting up new pass codes for the users. A pass code is not required for "third party" code level CS0, as the user does not require access to configuring parameters (protected via the code).

# Event Recorder



## NOTE

The viewing and acknowledgment of alarms depends on access authorization:

Viewing of alarms                      Access authorization CS# 0, CS# 1 and CS# 2

Acknowledgment of alarms      Access authorization CS# 2

# CS = code level (see chapter "Alarm Class" on page 44.

If an alarm occurs in the unit, an entry into the event log is made. The following information is supported/stored:

- Event
- Date of occurrence
- Time of occurrence

The event recorder stores the last 50 alarms in a FIFO (First In First Out) format, beginning with the most recent event. By pressing the "ACK" push button, the displayed alarm condition is deleted from the event recorder. The alarms are displayed on two lines. The top line indicates the date and time of the alarm occurred; the lower line shows the type of alarm.

Parameter 9

Check event list
YES

**Event recorder** **YES/NO**

- YES .....The events can be viewed and acknowledged.
- NO .....The events cannot be viewed or acknowledged.

## Internal Events and Discrete Inputs

YY-MM-DD hh:mm
xxxxxxxxxxxxxxxxxxxx

**50 × alarm log**

- YY-MM-DD hh:mm      Display of day and time of the event.
- xxxxxxxxxxxxxxxxxxxx      See table below.

Type of alarm	XXXXXXXXXXXXXXXXXX	
	German	English
<b>Internal alarm</b>		
Generator overfrequency, level 1	Gen.Überfreq. 1	Gen.overfreq. 1
Generator overfrequency, level 2	Gen.Überfreq. 2	Gen.overfreq. 2
Generator underfrequency, level 1	Gen.Unterfreq. 1	Gen.underfreq. 1
Generator underfrequency, level 2	Gen.Unterfreq. 2	Gen.underfreq. 2
Generator overvoltage, level 1	Gen.-Überspg. 1	Gen.overvolt. 1
Generator overvoltage, level 2	Gen.-Überspg. 2	Gen.overvolt. 2
Generator undervoltage, level 1	Gen.-Unterspg. 1	Gen.undervolt. 1
Generator undervoltage, level 2	Gen.-Unterspg. 2	Gen.undervolt. 2
Generator time-overcurrent, level 1	Gen.-Überstrom 1	Gen.overcurr. 1
Generator time-overcurrent, level 2	Gen.-Überstrom 2	Gen.overcurr. 2
Reverse/reduced load	Rück/Minderleist	Revers/min.power
Overload	Gen.-Überlast	Gen.overload
Unbalanced load	Schiefelast	Load unbalance
Mains overvoltage	Netz-Überspg.	Mains-overvolt.
Mains undervoltage	Netz-Unterspg.	Mains-undervolt.
Mains overfrequency	Netz-Überfreq.	Mains-underfreq.
Mains underfrequency	Netz-Unterfreq.	Mains-overfreq.
Mains vector/phase jump	Phasensprung	Phase shift
Mains df/dt	df/dt-Fehler	df/dt error
Battery undervoltage	Batt.-Unterspg.	Batt.undervolt.
GCB synchronization time monitoring	Synch.Zeit GLS	GCB syn.failure
MCB synchronization time monitoring	Synch.Zeit NLS	MCB syn.failure
Switching to dead busbar time monitoring	Stör. df/dU-max.	Failure df/dVmax
Mechanical GCB malfunction on closing	Störung GLS ZU	GCBclose failure
Mechanical MCB malfunction on closing	Störung NLS ZU	MCBclose failure
Mechanical GCB malfunction on opening	Störung GLS AUF	GCB open failure
Mechanical MCB malfunction on opening	Störung NLS AUF	MCB open failure
Faulty zero power ref. control at interch. synchronization on GCB	Bezugsleist. <>0	Power not zero
Maintenance call	Wartung	Service
Interface error X1-X5	Fehl.Schnit.X1X5	Interf.err. X1X5
Interface error Y1-Y5	Fehl.Schnit.Y1Y5	Interf.err. Y1Y5
<b>Discrete inputs</b>		
Discrete input [D01]	freely configurable	freely configurable
Discrete input [D02]		
Discrete input [D03]		
Discrete input [D04]		
Discrete input [D05]		
Discrete input [D06]		
Discrete input [D07]		
Discrete input [D08]		
Discrete input [D09]		
Discrete input [D10]		
Discrete input [D11]		
Discrete input [D12]		
Internal		
Internal		
Internal		
Internal		

Table 6-1: Event recorder - messages - Part 1

Type of alarm	XXXXXXXXXXXXXXXXXX	
	German	English
<b>Others</b>		
Change into operating mode MANUAL	BAW Hand	Manual mode
Change into operating mode AUTOMATIC	BAW Automatik	Automatic mode
Push-button "MCB OFF" depressed (in operating mode MANUAL)	Taste NLS AUS	Button MCB OFF
Push-button "GCB OFF" depressed (in operating mode MANUAL)	Taste GLS AUS	Button GCB OFF
Push-button "GCB ON" depressed (in operating mode MANUAL)	Taste GLS EIN	Button GCB ON
Push-button "MCB ON" depressed (in operating mode MANUAL)	Taste NLS EIN	Button MCB ON
Remote start	Fernstart	Remote start
Remote stop	Fernstop	Remote stop
Remote acknowledgment via interface	Fernquittierung	Remote acknowl.
Remote acknowledgment via terminal 36	Quittierung Kl.36	Acknowledg-ter 36
Acknowledgment via push-button "ACK"	Quittierg. Taste	Ackn.button QUIT
Mains failure	Netzausfall	Mains failure
Mains return	Netzwiederkehr	Mains o.k.

Table 6-2: Event recorder - messages - Part 2

### Analog Inputs

The name of the analog input is moved to the right according to the number of letters of the operating mode type. The alarm type is written in the space that has become open.

- WR Wire break
- AL Limit 1
- STOP Limit 2

```

Analog inp.1 000
STOP Analog inp.
```

#### Example

Limit value 2 (STOP) for analog input 1 has been exceeded. The text of the analog alarm input will be moved to the right either two or four spaces depending on the alarm class (here alarm class "STOP"). In this case the measured value is not displayed due to the length of the text. The length of the analog input text must be taken into consideration when configuring the analog input!

# Direct Configuration



## NOTE

To carry out direct configuration, you require a direct configuration cable (order code "DPC"), the LeoPC1 program (supplied with the cable) and the corresponding configuration files. After the program has been installed, consult the online help utility for a description of the PC program and its setup.

**Remote configuration:** For remote configuration, the CS2 password must be entered via the parameter "password DPC", otherwise the values can only be read and not written. If the unit is at the CS0 pass code level it will only permit the user to read the parameters. The control unit will not permit the user to modify any of the parameters. When the CS2 pass code is entered via LeoPC1 through the CAN bus, configuration of the unit will only be able to be performed through the CAN bus. The pass code level will change back to CS0 after 2 hours of inactivity, at which point the pass code will have to be entered again to modify any parameters. The password must be input prior to loading a language file. If the CS2 password is entered directly into the control unit, configuration via the CAN bus is automatically enabled.



## NOTE

The direct configuration via LeoPC1 and the configuration using the control panel are independent of each other and must be unlocked independent of each other. Unlocking the access via the control panel does not permit a configuration via LeoPC1 and the other way round.



## CAUTION

If the following parameter "direct para." is configured to "YES", communication via the CAN bus (terminals X1 to X5) is disabled. If communication is to be re-established via the CAN bus after the unit is configured (e.g. CAN bus connection to a Gateway GW 4), "Direct para." must be set to "NO"!

Direct configuration is disabled once the firing speed has been reached. This means that if further modifications to the control unit's parameters is desired, the only possible methods to do this is using the display and push buttons manually or via the CAN bus interface. The parameter "Direct para." is automatically changed from YES to NO (this is a function of the control unit software). The direct configuration function is de-activated for safety reasons. This is to prevent the possibility of a simultaneous generator start up and closing of circuit breakers to a dead bus in a multiple generator system (e.g. emergency power situation).

Parameter 10

Direct para.	YES
--------------	-----

### Direct configuration

YES/NO

- |          |   |
|----------|---|
| YES..... | The direct configuration plug is enabled and direct configuration of the control is possible. The CAN bus terminals X1-X5 are disabled, terminating any communication for the unit on the CAN bus. The following conditions must be met in order to carry out configuration via the direct configuration cable: |
|          | - A connection must be established via the direct configuration cable between the unit and the PC   |
|          | - The baud rate of the PC program must be set to 9,600 Baud   |
|          | - The corresponding configuration file must be used (file name: "xxxx-xxxx-yyy-zz.asm", initiated by xxxx-xxxx-yyy-zz.cfg)  |
| NO.....  | The configuration port is disabled and direct configuration cannot be performed. The CAN bus connection via the terminals X1 to X5 is enabled.  |

# Basic Settings



## CAUTION

Failure to ensure correct configuration of parameters may lead to incorrect measurements and the control failing to respond properly!

Parameter 11

Configure Measuring	YES
---------------------	-----

### Configure base settings YES/NO

Various groups of parameters are grouped together in blocks to aid in the rapid navigation through the large number of configuration screens. Selecting "YES" or "NO" does not determine if control or monitoring is performed. The user's selection has the following effect:

**YES** .....The configuration screens in this block are displayed and can either be viewed ("Select" push button) or modifications can be made to the parameters ("Cursor→", "Digit↑" or "Select" push buttons). This does not disable or enable individual parameters, only if the individual parameters in this parameter block may be accessed for modifications.

**NO** .....The parameters in this block are not displayed, cannot be modified and are therefore skipped.

Parameter 12

Generator number	00
------------------	----

### Generator number 1 to 4

For multiple generator applications that are coupled via a CAN bus, a unique number must be assigned to each generator for differentiation purposes. The generator number 1 should be assigned if the control is used in a single unit application. The generator number entered here corresponds to the generator number in the program LeoPC (in files for multiple generators).

## Generator and Mains Environmental

### Rated Values of the Frequency

Parameter 13

Generator freq. f set	00.0Hz
--------------------------	--------

### Generator set point frequency 40.0 to 70.0 Hz

The generator frequency set point is entered in this screen. This is required for the frequency controller in isolated and no-load operation. In most cases, the values entered into this screen will be 50 Hz or 60 Hz. It is possible to enter different values.

Parameter 14

Rated system frequency	00.0Hz
---------------------------	--------

### System rated frequency 50/60 Hz

The rated frequency of the system is entered in this screen. This parameter depends on the three-phase system in the relevant country.



Voltage Transformer, PTs



**CAUTION**

If the following parameter values are modified, the values of the following parameters must be verified:

- generator voltage set point (at page 66)
- voltage controller dead band (at page 77)
- synchronization dVmax (at page 91)
- dead bus start GCB dVmax (at page 93)
- generator overvoltage tripping value (at page 109)
- generator undervoltage tripping value (at page 110)

Parameter 15

**Gen.volt.transf.  
secondary 000V**

**PTs, secondary, generator**

**[1] 50 to 125 V; [4] 50 to 480 V**

The secondary voltage is set here in V. This is the voltage level that will be measured at the control unit input terminals.

Parameter 16

**Gen.volt.transf.  
primary 00.000kV**

**PTs, primary, generator**

**[1] 0.005 to 65,000 kV; [4] 0.020 to 65,000 kV**

The primary voltage is set here in kV. This entry serves to indicate the primary voltages in the display. If a potential transformer is not used, the measured voltage of 120V would be configured as "00.120kV" and 480V would be configured as "00.480kV".

Parameter 17

**Bus.volt.transf.  
secondary 000V**

**PTs, secondary, busbar**

**[1] 50 to 125 V; [4] 50 to 480 V**

The secondary voltage is set here in V. This is the voltage level that will be measured at the control unit input terminals.

Parameter 18

**Bus.volt.transf.  
primary 00.000kV**

**PTs, primary, busbar**

**[1] 0.005 to 65,000 kV; [4] 0.020 to 65,000 kV**

The primary voltage is set here in kV. This entry serves to indicate the primary voltages in the display. If a potential transformer is not used, the measured voltage of 120V would be configured as "00.120kV" and 480V would be configured as "00.480kV".



**CAUTION**

If the following parameter values are modified, the values of the following parameters must be verified:

- mains overvoltage tripping value (at page 112)
- mains undervoltage tripping value (at page 112)

Parameter 19

Mains volt.trans secondary	000V
-------------------------------	------

**PTs, secondary, mains** [1] 50 to 125 V; [4] 50 to 480 V

The secondary voltage is set here in V. This is the voltage level that will be measured at the control unit input terminals.

Parameter 20

Mains volt.trans primary	00.000kV
-----------------------------	----------

**PTs, primary, mains** [1] 0.005 to 65,000 kV; [4] 0.020 to 65,000 kV

The primary voltage is set here in kV. This entry serves to indicate the primary voltages in the display. If a potential transformer is not used, the measured voltage of 120V would be configured as "00.120kV" and 480V would be configured as "00.480kV".

**Rated Values of the Voltage**

Parameter 21

Gen.voltage V set	000V
----------------------	------

**Generator setpoint voltage** [1] 25 to 125 V; [4] 50 to 480 V

This value of the voltage specifies the generator voltage set point for no-load and isolated operation. This value corresponds with the secondary voltage of the PTs.

Parameter 22

Rated voltage System	000V
-------------------------	------

**System rated voltage** [1] 25 to 125 V; [4] 50 to 480 V

The rated voltage of the system is entered in this screen. This parameter depends on the three-phase system in the relevant country. This value corresponds with the secondary voltage of the PT'.

Parameter 23

**Voltage system**  
-----

This screen only affects the display. The watchdog screens are defined further below.

**Voltage measuring system**

**threephase/singlephase**

**Three-phase network** The electrical system (generator, busbar, and mains) is a delta system consisting of only the three external conductors (without a neutral conductor). The N-lug (terminal 0) is not connected. Only the phase-to-phase voltages are indicated in the display.

**Single-phase network** The electrical system (generator, busbar, and mains) is a wye system consisting of the three external conductors and a neutral conductor. As a result, the N-lug (terminal 0) must be connected. The phase-to-phase voltages and the phase-to-neutral voltages are indicated in the display.



**CAUTION**

If the following parameter is configured to "singlephase" a phase/vector jump monitoring is not possible.

Parameter 24

**Voltage meas.**  
**Mains** -----

This screen affects the protective functions.

**Voltage measurement system protection**

**threephase / singlephase**

The device can either monitor the phase-to-neutral voltages (four-wire system) or the phase-to-phase voltages (three-wire system). Generally the phase-to-neutral voltages are monitored when using the 400V model on low-voltage systems, and the phase-to-phase voltages are monitored when using the 100V model for the medium-high-voltage systems. Monitoring the phase-to-phase voltage is vital to prevent detection of line-to-earth-faults in compensated or isolated mains applications, which result in a voltage monitoring system fault.

**singlephase**.. The voltage at the terminals 1 through 4 are measured as a four-wire installation. All subsequent screens concerning protective functions refer to the phase-to-neutral voltage ( $V_{L-N}$ ).

**threephase**... The voltages at the terminals 1 through 4 are measured as a three-wire system. All subsequent screens concerning protective functions refer to the phase-to-phase voltage ( $V_{L-L}$ ).

## Generator Current, CT

Parameter 25

Current transf. generator 0000/x
-------------------------------------

**CT ratio, generator****[5] 10 to 7,000/5**

The current transformer ratio is necessary in order to display the actual values and control the power. When sizing a CT for the system, the minimum current flow for the CT should not be lower than 60% of the transformer's rated current at rated current. A lower percentage may lead to malfunctions and additional inaccuracies in the control and monitoring functions also occur.

The primary rated current of the CT must be entered here. It is indicated on the data plate of the CT. The secondary rated current cannot be configured and is 5 A.

If the current in the primary winding of the CT reaches the primary rated current, the secondary rated current flows in the secondary winding of the CT.

Example for current transformer ratio 300/5:

Current in the primary winding = 300 A -> current in the secondary winding = 5 A

Current in the primary winding = 150 A -> current in the second. winding = 2,5 A



**NOTE**

The following parameter is only available for units with a software version of 3.4006 or higher. Units with a lower software version use the internal value “3”.

Parameter 26

Format Power
--------------

**Power display format**

1 / 2 / 3 / 4 / 5 / 6 / 7 / 8

The format for the power display, (bus) transmission and analog output resolution can be configured here.

This parameter enables to find a setting, which gives enough resolution while being able to display the maximum value. The display format changes when an apparent power value is exceeded, which is calculated from the transformer settings according to the following formula:  $S = UGNPRIM * IGNPRIM * \sqrt{3}$

UGNPRIM = generator voltage transformer primary setting (Gen. voltage primary)

IGNPRIM = generator current transformer setting (Current transf. Generator)

- 1..... 00.0k [W/VA/var] (S up to 10 kVA)  
 0000k [W/VA/var] (S from 10 kVA up to 1000 kVA)  
 00.0M [W/VA/var] (S from 1000 kVA up to 10 MVA)  
 000M [W/VA/var] (S from 10 MVA)
- 2..... 00.0k [W/VA/var] (S up to 20 kVA)  
 0000k [W/VA/var] (S from 20 kVA up to 2000 kVA)  
 00.0M [W/VA/var] (S from 2000 kVA up to 20 MVA)  
 000M [W/VA/var] (S from 20 MVA)
- 3..... 00.0k [W/VA/var] (S up to 30 kVA)  
 0000k [W/VA/var] (S from 30 kVA up to 3000 kVA)  
 00.0M [W/VA/var] (S from 3000 kVA up to 30 MVA)  
 000M [W/VA/var] (S from 30 MVA)
- 4..... 00.0k [W/VA/var] (S up to 40 kVA)  
 0000k [W/VA/var] (S from 40 kVA up to 4000 kVA)  
 00.0M [W/VA/var] (S from 4000 kVA up to 40 MVA)  
 000M [W/VA/var] (S from 40 MVA)
- 5..... 00.0k [W/VA/var] (S up to 50 kVA)  
 0000k [W/VA/var] (S from 50 kVA up to 5000 kVA)  
 00.0M [W/VA/var] (S from 5000 kVA up to 50 MVA)  
 000M [W/VA/var] (S from 50 MVA)
- 6..... 00.0k [W/VA/var] (S up to 60 kVA)  
 0000k [W/VA/var] (S from 60 kVA up to 6000 kVA)  
 00.0M [W/VA/var] (S from 6000 kVA up to 60 MVA)  
 000M [W/VA/var] (S from 60 MVA)
- 7..... 00.0k [W/VA/var] (S up to 70 kVA)  
 0000k [W/VA/var] (S from 70 kVA up to 7000 kVA)  
 00.0M [W/VA/var] (S from 7000 kVA up to 60 MVA)  
 000M [W/VA/var] (S from 60 MVA)
- 8..... 00.0k [W/VA/var] (S up to 80 kVA)  
 0000k [W/VA/var] (S from 80 kVA up to 8000 kVA)  
 00.0M [W/VA/var] (S from 8000 kVA up to 60 MVA)  
 000M [W/VA/var] (S from 60 MVA)

Example:

$$S = U_{GNPRIM} * I_{GNPRIM} * \sqrt{3} = 10 \text{ kV} * 200 \text{ A} * \sqrt{3} = 3,46 \text{ MVA}$$

If this parameter is configured to "3" (default), the power format is 00.0 MW, if it is configured to "4", it is 0000 kW.



**NOTE**

If this parameter is configured for a higher resolution (higher value), large values (above the calculated apparent power) might be displayed incorrectly. However, this parameter does not affect the monitoring functions.

Parameter 27

Power measuring Gen. -----
-------------------------------

**Generator power measuring**

**singlephase/threephase**

When selecting generator power measurement, single-phase or three-phase measurement may be selected. If "single-phase power measurement" is configured, the voltage in phase L<sub>12</sub> and the current in phase L<sub>1</sub> are used for power measurement. If "three-phase power measurement" is configured, the currents from all three phases and the relevant voltages are used for power measurement.



**NOTE**

When producing positive real power, a positive real current flows in the "k to l" direction in the current transformer. Positive re-active power means that with a positive effective direction, inductive re-active (lagging) current flows in the effective direction. If the unit is connected to the terminals of a generator and the outgoing circuits of the current transformer facing the generator are connected to "k", the unit shows a positive real power when the generator supplies real power. Refer to the "Direction of Power" section on page 34.

Parameter 28

Rated power gen. 0000kW
----------------------------

**Generator rated power**

**5 to 16,000 kW**

The generator rated power is entered into this screen. It is critical to enter the correct value in this parameter as numerous measurement, control, and monitoring functions refer to this value (e.g. generator overload monitoring).

Parameter 29

Rated current generator 0000A
----------------------------------

**Generator rated current**

**10 to 7,000 A**

The generator rated current is entered into this screen. It is critical to enter the correct value in this parameter as numerous measurement, control, and monitoring functions refer to this value (e.g. generator overcurrent monitoring).

**Mains Current, CT / Mains Power**

**Mains current measuring via mains current transformer/CT**

Parameter 30

Current transf. mains	0000/x
--------------------------	--------

**CT ratio, mains**

**5 to 7,000/x A**

The current transformer ratio is necessary in order to display the actual values and control the power. When sizing a CT for the system, the minimum current flow for the CT should not be lower than 60% of the transformer's rated current at rated current. A lower percentage may lead to malfunctions and additional inaccuracies in the control and monitoring functions also occur.

The primary rated current of the CT must be entered here. It is indicated on the data plate of the CT. The secondary rated current cannot be configured and is 5 A

If the current in the primary winding of the CT reaches the primary rated current, the secondary rated current flows in the secondary winding of the CT.

Example for current transformer ratio 300/5:

Current in the primary winding = 300 A -> current in the secondary winding = 5 A

Current in the primary winding = 150 A -> current in the second. winding = 2,5 A

Parameter 31

Angle adjustment Mainscurr.	000°
--------------------------------	------

**Angle adjustment for measuring of mains current**

**-180 to 180 °**

If a transformer is located between the measuring point for the voltage of the mains and the generator, it is possible that there is a phase shift between these two measuring points. If so, special voltage transducers must be used to adjust the phase angle of the voltages. The synchronization is at the right phase angle with these transducers, but measurement of the mains power is wrong because mains current is still measured without phase angle correction. This configuration screen allows the user to adjust the phase angle measurement of the mains current, so that the measurement of the mains power is correct.

## Change Passwords



### NOTE

Once the code level is entered, access to the configuration menus will be allowed for two hours after the last function is performed or until another password is entered into the control. If a user needs to exit a code level then code level CS0 should be entered. This will block any configuration of the control. A user may return to CS0 by allowing the entered password to expire after two hours or by changing any one digit on the random number generated on the password screen and entering it into the unit. If power to the unit is cycled off, the unit starts up in CS0.

Parameter 32

Define level 1
code            0000

**Assign code level 1 (customer) 0000 to 9999**

---

This screen is only displayed in code level 2. The user may change the password for this code level in this screen. After entering this code, the user has access rights to only a select few parameters.

The default password for this code level (CS) is    **CS1 = 0 0 0 1**

Parameter 33

Define level 2
code            0000

**Assign code level 2 (commissioner) 0000 to 9999**

---

This screen is only displayed in code level 2. The user may change the password for this code level in this screen. After entering this code, the user has full access rights to all parameters.

The default password for this code level (CS) is    **CS2 = 0 0 0 2**



# Controller



## CAUTION

Entering incorrect values can lead to the control unit failing to function properly and destroy the generator!

Parameter 34

Configure Controller	YES
----------------------	-----

### Configure controllers

YES/NO

Various groups of parameters are grouped together in blocks to aid in the rapid navigation through the large number of configuration screens. Selecting "YES" or "NO" does not determine if control or monitoring is performed. The user's selection has the following effect:

**YES**..... The configuration screens in this block are displayed and can either be viewed ("Select" push-button) or modifications can be made to the parameters ("Cursor→", "Digit↑" or "Select" push buttons). This does not disable or enable individual parameters, only if the individual parameters in this parameter block may be accessed for modifications.

**NO**..... The parameters in this block are not displayed, cannot be modified and are therefore skipped.

## Constant and Interchange Real Power Controller

These screens appear only if the real power controller (see chapter "Real Power Controller" on page 82) is configured to "ON".



## NOTE

The fixed-value power controller does not monitor the mains interchange point. If excess power for the load requirements is generated, the excess power is exported to the mains. If insufficient power for the load requirements is generated, remaining power required is imported from the mains.

Parameter 35

Power controller	
Pset1	I0000kW

### P controller: setpoint value 1

C/I/E 0 to 16,000 kW

Setpoint 1 is enabled when the discrete input "Setpoint 1↔2" is de-energized (no voltage applied to terminal 5). The mains interchange (import/export) real power is then controlled to the set point 1 value.

#### Generator real power control

**C**..... The letter C stands for constant power set point (= base load). The generator shall always supply the value entered for the constant power level. All load swings are absorbed by the utility. The generator will always start when a constant power (base load) operation is enabled.

#### Mains interchange (import/export) real power control

**I**..... The letter I stands for import power (power supplied by the mains). The value entered for the import level shall always be supplied by the utility. All load swings are absorbed by the generator(s) provided the load rating for the generator(s) is not exceeded. The generator will start when the power imported from the utility exceeds the level configured in this parameter.

**E**..... The letter E stands for export power (power supplied to the mains). The value entered for the export level shall always be supplied to the utility. All load swings are absorbed by the generator(s) provided the load rating for the generator(s) is not exceeded. The generator will always start when an export power operation is enabled.

Parameter 36

Power controller  
Pset2 I0000kW

**P controller: setpoint value 2**

**C/I/E 0 to 16,000 kW**

Setpoint 2 is enabled when the discrete input "Setpoint 1↔2" is energized (voltage applied to terminal 5) and the external setpoint value (via 0/4 to 20 mA analog input or interface) has not been selected. The mains interchange (import/export) real power is then controlled to the set point 2 value.

Generator real power control

**C** .....The letter C stands for constant power set point (= base load). The generator shall always supply the value entered for the constant power level. All load swings are absorbed by the utility. The generator will always start when a constant power (base load) operation is enabled.

Mains interchange (import/export) real power control

**I** .....The letter I stands for import power (power supplied by the mains). The value entered for the import level shall always be supplied by the utility. All load swings are absorbed by the generator(s) provided the load rating for the generator(s) is not exceeded. The generator will start when the power imported from the utility exceeds the level configured in this parameter.

**E** .....The letter E stands for export power (power supplied to the mains). The value entered for the export level shall always be supplied to the utility. All load swings are absorbed by the generator(s) provided the load rating for the generator(s) is not exceeded. The generator will always start when an export power operation is enabled.

### Frequency Controller

Parameter 37

Initial state  
Frequency 000%

**f controller: initial state**

**0 to 100 %**

This value is the initial state or start value for the frequency controller when the control unit is not operating or changing from a real power controller to a frequency controller. This value relates to Parameter 46 "F/P contr. output".

Parameter 38

Freq.controller  
ON

**f controller**

**ON/OFF**

**ON**.....The generator frequency control is enabled. The generator frequency is controlled according to the operation function being performed (isolated operation / synchronization). The subsequent screens of this function are displayed.

**OFF**.....Generator frequency control is disabled, and the subsequent screens of this function are not displayed.

Parameter 39

f-contr. active  
at: 00.0Hz

**f controller: start frequency**

**0.0 to 70.0 Hz**

The frequency controller is activated when the generator frequency exceeds this configured value. This parameter prevents the control unit from affecting other control units in parallel with it while going through the start up cycle.

Parameter 40

Delay time for  
f-contr. 000s

**f controller: delayed start**

**0 to 999 s**

The frequency must exceed the value configured in the previous screen uninterrupted for the time configured here to enable the frequency controller.

Parameter 41

Freq.controller  
Ramp 00Hz/s

**f controller: setpoint value ramp**

**1 to 50 Hz/s**

The set point value is transmitted to the speed governor via a ramp. The slope of the ramp is used to alter the rate at which the governor modifies the setpoint value. The more rapidly the desired change of the setpoint value is to be carried out, the greater the value entered here must be.



**NOTE**

The following settings in the n/f controller area affect the P controller.

Parameter 42

F/P contr.type  
-----

**f controller: type**

**THREESTEP / ANALOG / PWM**

**THREESTEP** The signal to control the speed/frequency/real power is output via the relay manager to any configured relay. You can use the following parameters of the relay manager:

parameter 99 = n+/f+/P+

parameter 100 = n-/f-/P-

**ANALOG ....** Control is performed via the analog controller outputs to terminals 8/9/10. The signal selection is made in Parameter 46 "F/P contr. output" and through the use of an external jumper depending on the configured signal.

**PWM .....** The control of speed/frequency/real power is performed via a PWM signal. The signal amplitude is set in Parameter 47 "Level PWM". An additional jumper must be added.

**Three-Position Controller (Setting THREESTEP)**

Parameter 43

Freq.controller  
dead band 0.00Hz

**f controller: dead band**

**0.02 to 1.00 Hz**

**Isolated operation** The generator frequency is controlled in such a manner, that in a steady state, the actual value does not deviate from the generator frequency set point by more than the configured dead band value.

**Synchronization** The generator frequency is controlled in such a manner, that in its steady state, the differential frequency does not exceed the configured dead band value. The mains or busbar frequency is used as the set point value.

Parameter 44

Freq.controller  
time pulse>000ms

**f controller: minimum ON period**

**10 to 250 ms**

The minimum ON period of the relay should be selected in such a manner that the speed governor responds reliably to the control pulse. The time configured here determines the length of the control pulse. The smallest possible time must be configured in order to ensure optimum control behavior.

Parameter 45

Freq.controller  
gains.Kp 00.0

**f controller: gain**

**0.1 to 99.9**

The gain factor  $K_p$  indicates the frequency controller gain. By increasing the gain factor, the response is increased to permit larger corrections to the variable to be controlled. The farther out of tolerance the process is the larger the response action is to return the process to the tolerance band. If the gain is configured too high, the result is excessive overshoot/undershoot of the desired value.

**Analog Controller Output (Setting ANALOG/PWM)**

Parameter 46

**F/P contr.output**  
-----

**f controller: output range**

**see below**

If Parameter 42 "F/P contr. type" has been configured as "ANALOG", the type of analog output must be selected in this screen. The use of a jumper between terminals 8/9 determines if the output is a voltage or current output. The PWM signal can be inverted in this screen (refer to the note below the table). All available ranges are listed in the table below.

Type	Setting in above configuration screen	Jumper between term. 8/9	Range	Lower level	Upper level
Current	+/-20mA (+/-10V)	no	+/-20mA	-20 mA	+20 mA
	+/-10mA (+/-5V)		+/-10mA	-10 mA	+20 mA
	0 to 10mA (0 to 5V)		0 to 10mA	0 mA	10 mA
	0 to 20mA (0 to 10V)		0 to 20mA	0 mA	20 mA
	4 to 20mA		4 to 20mA	4 mA	20 mA
	10 to 0mA (5 to 0V)		10 to 0mA	10 mA	0 mA
	20 to 0mA (10 to 0V)		20 to 0mA	20 mA	0 mA
Voltage	20 to 4mA	yes	20 to 4mA	20 mA	4 mA
	+/-20mA (+/-10V)		+/-10V	-10 Vdc	+10 Vdc
	+/-10mA (+/-5V)		+/-5V	-5 Vdc	+5 Vdc
	+/-3V		+/-3V	-3 Vdc	+3 Vdc
	+/-2.5V		+/-2,5V	-2.5Vdc	+2.5 Vdc
	+/-1V		+/-1V	-1 Vdc	+1 Vdc
	0 to 10mA (0 to 5V)		0 to 5V	0 Vdc	5 Vdc
	0.5V to 4.5V		0.5 to 4.5V	0.5 Vdc	4.5 Vdc
	0 to 20mA (0 to 10V)		0 to 10V	0 Vdc	10 Vdc
	10 to 0mA (5 to 0V)		5 to 0V	5 Vdc	0 Vdc
	4.5V to 0.5V		4.5 to 0.5V	4.5 Vdc	0.5 Vdc
	20 to 0mA (10 to 0V)		10 to 0V	10 Vdc	0 Vdc



**NOTE**

The control logic of the PWM signal can be inverted by the following steps:

- Select "F/P contr.type" = ANALOG
- Select with parameter "F/P contr.output" any of the listed inverted control outputs (10 to 0mA, 20 to 0mA, 20 to 4mA, 5 to 0V, 4.5V to 0.5V, or 10 to 0V outputs)
- Back-up one screen to "F/P contr.type" (by pressing "Select" and "Cursor→" simultaneously)
- Select "F/P contr.type" = PWM

Now the PWM signal is inverted.

Parameter 47

**Level PWM**  
-----

**f control: PWM level**

**3.0 to 10.0 V**

If PWM has been selected in the previous screen the amplitude of the PWM signal can be adjusted here.

Parameter 48

**Freq.controller gain.Kpr**     000

**f controller: P gain**

**1 to 240**

The proportional-action coefficient  $K_{PR}$  indicates the closed-loop control system gain. By increasing the gain, the response is increased to permit larger corrections to the variable to be controlled. The farther out of tolerance the process is the larger the response action is to return the process to the tolerance band. If the gain is configured too high, the result is excessive overshoot/undershoot of the desired value.

Parameter 49

**Freq. controller  
reset Tn 00.0s**

**f controller: reset time** **0.0 to 60.0 s**

The reset time  $T_n$  represents the I-component of the PID controller. The reset time corrects for any offset (between set point and process variable) automatically over time by shifting the proportioning band. Reset automatically changes the output requirements until the process variable and the set point are the same. This parameter permits the user to adjust how quickly the reset attempts to correct for any offset. The reset time constant must be greater than the derivative time constant. If the reset time constant is too small, the engine will continually oscillate. If the reset time constant is too large, the engine will take too long to settle at a steady state.

Parameter 50

**Freq. controller  
derivat.Tv 0.00s**

**f controller: derivative-action time** **0.00 to 6.00 s**

The derivative-action time  $T_v$  represents the D-component of the PID controller. By increasing this parameter, the stability of the system is increased. The controller will attempt to slow down the action of the throttle in an attempt to prevent excessive overshoot or undershoot. Essentially this is the brakes for the process. This portion of the PID loop operates anywhere within the range of the process unlike reset.

### Voltage Controller

Parameter 51

**Starting point  
voltage 000%**

**V controller: initial state** **0 to 100 %**

This value is the initial state or start value for the frequency controller when the control unit is not operating or changing from a power factor controller to a voltage controller. This value relates to Parameter 57 "V/Q contr. output".

Parameter 52

**Volt. controller  
ON**

**V controller** **ON/OFF**

**ON**..... Generator voltage control is enabled. The subsequent screens of this function are displayed.  
**OFF**..... Control is disabled, and the subsequent screens of this function are not displayed.



### NOTE

The following settings in the V controller area affect the power factor (cosphi) controller.

Parameter 53

**V/Q contr.type  
-----**

**V controller: Type** **THREESTEP / ANALOG**

**THREESTEP** The signal to control the voltage/cosphi (power factor) is output via the relay manager to any configured relay. You can use the following parameters of the relay manager:  
 parameter 101 = U+/cosphi+  
 parameter 102 = U-/cosphi-  
**ANALOG** .... A control is done via the analog controller outputs to terminals 11/12/13. The signal selection is made in Parameter 57 "V/Q contr. output" and through the use of an external jumper depending on the configured signal.

### Three-Position Controller (Setting THREESTEP)

Parameter 54

Volt.controller  
dead band 00.0V

V controller: dead band [1] 0.1 to 15.0 V; [4] 0.5 to 60.0 V

**Isolated operation** The generator voltage set point is controlled in such a manner, that in a steady state, the actual value does not deviate from the generator voltage set point by more than the configured dead band value.

**Synchronization** The generator voltage is controlled in such a manner, that in its steady state, the differential voltage does not exceed the configured dead band value. The mains or busbar frequency is used as the set point value.

Parameter 55

Volt.controller  
time pulse>000ms

V controller: minimum ON period 20 to 250 ms

The minimum ON period of the relay should be selected in such a manner that the voltage regulator responds reliably to the control pulse. The time configured here determines the length of the control pulse. The smallest possible time must be configured in order to ensure optimum control behavior.

Parameter 56

Volt.controller  
gain.Kp 00.0

V controller: gain 0.1 to 99.9

The gain factor  $K_p$  indicates the voltage controller gain. By increasing the gain factor, the response is increased to permit larger corrections to the variable to be controlled. The farther out of tolerance the process is the larger the response action is to return the process to the tolerance band. If the gain is configured too high, the result is excessive overshoot/undershoot of the desired value.

**Analog Controller (Setting ANALOG)**

Parameter 57

V/Q contr.output  
-----

**V controller: range**

**see below**

If Parameter 53 "V/Q contr. type" has been configured as "ANALOG", the type of analog output must be selected in this screen. The use of a jumper between terminals 11/12 determines if the output is a voltage or current output. All available ranges are listed in the table below.

Type	Setting in above configuration screen	Jumper between term. 11/12	Range	Lower level	Upper level
Current	+/-20mA (+/-10V)	no	+/-20mA	-20 mA	+20 mA
	+/-10mA (+/-5V)		+/-10mA	-10 mA	+20 mA
	0 to 10mA (0 to 5V)		0 to 10mA	0 mA	10 mA
	0 to 20mA (0 to 10V)		0 to 20mA	0 mA	20 mA
	4 to 20mA		4 to 20mA	4 mA	20 mA
	10 to 0mA (5 to 0V)		10 to 0mA	10 mA	0 mA
	20 to 0mA (10 to 0V)		20 to 0mA	20 mA	0 mA
Voltage	20 to 4mA	yes	20 to 4mA	20 mA	4 mA
	+/-20mA (+/-10V)		+/-10V	-10 Vdc	+10 Vdc
	+/-10mA (+/-5V)		+/-5V	-5 Vdc	+5 Vdc
	+/-3V		+/-3V	-3 Vdc	+3 Vdc
	+/-2.5V		+/-2.5V	-2.5Vdc	+2.5 Vdc
	+/-1V		+/-1V	-1 Vdc	+1 Vdc
	0 to 10mA (0 to 5V)		0 to 5V	0 Vdc	5 Vdc
	0.5V to 4.5V		0.5 to 4.5V	0.5 Vdc	4.5 Vdc
	0 to 20mA (0 to 10V)		0 to 10V	0 Vdc	10 Vdc
	10 to 0mA (5 to 0V)		5 to 0V	5 Vdc	0 Vdc
	4.5V to 0.5V		4.5 to 0.5V	4.5 Vdc	0.5 Vdc
	20 to 0mA (10 to 0V)		10-0V	10 Vdc	0 Vdc

Parameter 58

Volt.controller gain.Kpr 000

**V controller: P-gain**

**1 to 240**

The proportional-action coefficient  $K_{PR}$  indicates the closed-loop control system gain. By increasing the gain, the response is increased to permit larger corrections to the variable to be controlled. The farther out of tolerance the process is the larger the response action is to return the process to the tolerance band. If the gain is configured too high, the result is excessive overshoot/undershoot of the desired value.

Parameter 59

Volt.controller reset Tn 00.0s

**V controller: reset time**

**0.0 to 60.0 s**

The reset time  $T_n$  represents the I-component of the PID controller. The reset time corrects for any offset (between set point and process variable) automatically over time by shifting the proportioning band. Reset automatically changes the output requirements until the process variable and the set point are the same. This parameter permits the user to adjust how quickly the reset attempts to correct for any offset. The reset time constant must be greater than the derivative time constant. If the reset time constant is too small, the engine will continually oscillate. If the reset time constant is too large, the engine will take too long to settle at a steady state.

Parameter 60

Volt.controller derivat.Tv 0.00s

**V controller: derivative-action time**

**0.00 to 6.00 s**

The derivative-action time  $T_v$  represents the D-component of the PID controller. By increasing this parameter, the stability of the system is increased. The controller will attempt to slow down the action of the throttle in an attempt to prevent excessive overshoot or undershoot. Essentially this is the brakes for the process. This portion of the PID loop operates anywhere within the range of the process unlike reset.

### Power Factor Controller

Parameter 61

**Pow.fact.contr.**  
ON

**Power factor controller** ON/OFF

**ON** .....The power factor is controlled independent of the load in mains parallel operations. If the measured secondary currents are lower than 5% of the rated current, the power factor cannot be accurately measured. In order to prevent power factor swings, the controller automatically locks the power factor at a set value. The subsequent screens of this function are displayed.

**OFF** .....Power factor control is disabled, and the subsequent screens of this function are not displayed.

Parameter 62

**Pow.fact.contr.**  
**setpoint** 0.00

**Power factor controller: internal set point value** i0.70 to 1.00 to c0.70

When operating in mains parallel, the control regulates the re-active power in a manner that results in the generator producing power at the power factor configured here. The designation "i" equals inductive (generator overexcited/leading) and "c" capacitive (generator underexcited/lagging) re-active power. This set point is enabled only in mains parallel operation.



#### NOTE

Please note the configured settings for the voltage controller (refer to Voltage Controller on page 77). The settings for the voltage controller also affect the power factor controller.

### External Power Factor Set Point Value

Parameter 63

**Power factor**  
**external** ON

**Power factor set point: external set point value** ON/OFF

**ON** .....The power factor set point 2 value may be enabled via an external signal. The subsequent screens of this function are displayed. This set point 2 is enabled when terminal 5" ("Setpoint 1↔2) is energized.

**OFF** .....If this function is configured as "OFF", the control unit utilizes set point 1 only. The external set point value specification cannot be carried out via the 0 to 20 mA input. The subsequent screens of this function are not displayed.

Parameter 64

**Analog input**  
0-00mA

**Power factor set point: range** 0 to 20 / 4 to 20 mA

A 0 to 20 mA or 4 to 20 mA analog input for the power factor controller is selected here, depending on the type of input used.

**0 to 20 mA** ...Minimum value of the setpoint is 0 mA; maximum value is 20 mA.

**4 to 20 mA** ...Minimum value of the setpoint is 4 mA; maximum value is 20 mA.

Parameter 65

**Ext. Pow.Factor**  
0mA 0.00

**Power factor set point: minimum value** i0.70 to 1.00 to c0.70

The minimum value of the power factor is defined here (e.g. i0.95).

Parameter 66

**Ext. Pow.Factor**  
20mA 0.00

**Power factor set point: maximum value** i0.70 to 1.00 to c0.70

The maximum value of the power factor is defined here (e.g. c0.95).



### Three-Position Controller (Setting THREESTEP)

Parameter 67

Pow. fact. contr. dead band 00.0%
--------------------------------------

**Power factor controller: dead band**

**0.5 to 25.0 %**

The unit automatically calculates the amount of re-active power, which is required to maintain the configured power factor. In mains parallel operation, the re-active power is controlled in such a manner, that in its steady state, the actual value does not deviate from the internally calculated percentage set point (set point 1) value by more than the configured dead band. In this case, the percentage value refers to the generator rated power.

Parameter 68

Pow. fact. contr. gain Kp 00.0
-----------------------------------

**Power factor controller: gain**

**0.1 to 99.9**

The gain factor  $K_p$  indicates the power factor controller gain. By increasing the gain factor, the response is increased to permit larger corrections to the variable to be controlled. The farther out of tolerance the process is the larger the response action is to return the process to the tolerance band. If the gain is configured too high, the result is excessive overshoot/undershoot of the desired value.

### Analog Controller (Setting ANALOG)

Parameter 69

Pow. fact. contr. gains Kpr 000
------------------------------------

**Power factor controller: P gain**

**1 to 240**

The proportional-action coefficient  $K_{PR}$  indicates the closed-loop control system gain. By increasing the gain, the response is increased to permit larger corrections to the variable to be controlled. The farther out of tolerance the process is the larger the response action is to return the process to the tolerance band. If the gain is configured too high, the result is excessive overshoot/undershoot of the desired value.

Parameter 70

Pow. fact. contr. reset Tn 00.0s
-------------------------------------

**Power factor controller: reset time**

**0.0 to 60.0 s**

The reset time  $T_n$  represents the I-component of the PID controller. The reset time corrects for any offset (between set point and process variable) automatically over time by shifting the proportioning band. Reset automatically changes the output requirements until the process variable and the set point are the same. This parameter permits the user to adjust how quickly the reset attempts to correct for any offset. The reset time constant must be greater than the derivative time constant. If the reset time constant is too small, the engine will continually oscillate. If the reset time constant is too large, the engine will take too long to settle at a steady state.

Parameter 71

Pow. fact. contr. derivat. Tv 0.00s
--

**Power factor controller: derivative-action time**

**0.00 to 6.00 s**

The derivative-action time  $T_v$  represents the D-component of the PID controller. By increasing this parameter, the stability of the system is increased. The controller will attempt to slow down the action of the throttle in an attempt to prevent excessive overshoot or undershoot. Essentially this is the brakes for the process. This portion of the PID loop operates anywhere within the range of the process unlike reset.

### Real Power Controller

Parameter 72

Power controller
ON

**P controller** **ON/OFF**

**ON** .....In a mains parallel operation, the real power is automatically controlled at the configured set point (see page 73) when the real power controller is enabled. The subsequent screens of this function are displayed.

**OFF** .....Control is disabled, and the subsequent screens of this function are not displayed.

### Set Point Ramp %/s

Parameter 73

Power controller
ramp        000 %/s

**P controller: set point ramp %/s** **0 to 100 %/s**

The setpoint change is supplied to the controller via a percent per second ramp in reference to the generator rated power (Parameter 28). The slope of the ramp is used to alter the rate at which the controller modifies the set point value. The more rapidly the change in the set point is to be carried out, the greater this value must be.

### Power Limitation

Parameter 74

Power limit
P max.        000%

**P controller: real power limitation - maximum** **10 to 120 %**

If the maximum generator real power is to be limited, the desired limit of the generator rated power (Parameter 28) must be entered into this screen as a percentage. The generator is controlled in such a manner that this value is not exceeded. The value "P<sub>max</sub>" only limits the real power controller set point and has no effect in isolated operation.

Parameter 75

Power limit
P min.        00%

**P controller: real power limitation - minimum** **0 to 50 %**

If the minimum generator real power is to be limited, the desired limit of the generator rated power (Parameter 28) must be entered into this screen as a percentage. The generator is controlled in such a manner that the generator real power does not fall below this value. This parameter is not enabled during constant power control.

**External Set Point Value**

Parameter 76

Power setpoint external ON
-------------------------------

**P set point: external set point value** **ON/OFF**

**ON**..... The real power set point 2 value may be specified via an external signal. The subsequent screens of this function are displayed. This setpoint is enabled when terminal 5 ("Setpoint 1↔2") is energized.

**OFF**..... If this function is configured to "OFF", the control unit utilizes set point 1 only. The external set point value specification cannot be carried out via the 0-20 mA input. The subsequent screens of this function are not displayed.

Parameter 77

Analog input 0-00mA
------------------------

**P set point: range** **0 to 20 / 4 to 20 mA**

A 0 to 20 mA or 4 to 20 mA analog input of the power factor controller is selected here depending on the type of input used.

**0 to 20 mA** ... Minimum value of the setpoint is 0 mA; maximum value is 20 mA.

**4 to 20 mA** ... Minimum value of the setpoint is 4 mA; maximum value is 20 mA.



**CAUTION**

The interchange power set point (import/export power) can be scaled. When controlling interchange power, it is vital to ensure that a constant power setting is not configured simultaneously with an Import or Export power setting when scaling the external analog input.

<b>External setpoint</b>	<b>0/4 mA</b>	<b>C</b>	<b>I</b>	<b>E</b>	<b>I</b>	<b>E</b>
<b>External setpoint</b>	<b>20 mA</b>	<b>C</b>	<b>I</b>	<b>E</b>	<b>E</b>	<b>I</b>

Parameter 78

Ext. setpoint 0mA 0000kW
-----------------------------

**P set point: minimum value** **C/E/I 0 to 16,000 kW**

The minimum real power value is defined here (e.g. 0 kW).

Parameter 79

Ext. setpoint 20mA 0000kW
------------------------------

**P set point: maximum value** **C/E/I 0 to 16,000 kW**

The maximum real power value is defined here (e.g. 100 kW).

### Three-Position Controller (Setting THREESTEP)

Parameter 80

Power controller dead band	00.0%
-------------------------------	-------

**P controller: dead band**

**0.1 to 25.0 %**

In mains parallel operation, the real power is controlled in such a manner, that in its steady state, the current value does not deviate from the real power set point by more than the configured percentage value. In this case, the percentage value refers to the generator rated power (Parameter 28).

Parameter 81

Power controller gain $K_p$	00.0
--------------------------------	------

**P controller: gain factor**

**0.1 to 99.9**

The gain factor  $K_p$  indicates the power controller gain. By increasing the gain factor, the response is increased to permit larger corrections to the variable to be controlled. The farther out of tolerance the process is the larger the response action is to return the process to the tolerance band. If the gain is configured too high, the result is excessive overshoot/undershoot of the desired value.

Parameter 82

Power controller band ratio	*0.0
--------------------------------	------

**P controller: dead band factor**

**1.0 to 9.9**

Once the controller has reached a steady state condition and has not output a raise/lower pulse for more than 5 seconds, the dead band is increased by the configured dead band ratio factor.

Example: In the case of an dead band of 2.5 % and a factor of 2.0 the dead band is in-creased after 5 s to 5.0 %. If the control deviation subsequently exceeds 5.0 %, again, the controller's original sensitivity is automatically reset (2.5 %). This input can be used, in the event of small control deviations, to avoid unnecessarily frequent actuation processes, thereby protecting the adjustment facility.

## Analog Ccontroller (Setting ANALOG)

Parameter 83

Power controller gain Kpr	000
------------------------------	-----

**P controller: P gain**

**1 to 240**

The proportional-action coefficient  $K_{PR}$  indicates the closed-loop control system gain. By increasing the gain, the response is increased to permit larger corrections to the variable to be controlled. The farther out of tolerance the process is the larger the response action is to return the process to the tolerance band. If the gain is configured too high, the result is excessive overshoot/undershoot of the desired value.

Parameter 84

Power controller reset Tn	00.0s
------------------------------	-------

**P controller: reset time**

**0.0 to 60.0 s**

The reset time  $T_n$  represents the I-component of the PID controller. The reset time corrects for any offset (between set point and process variable) automatically over time by shifting the proportioning band. Reset automatically changes the output requirements until the process variable and the set point are the same. This parameter permits the user to adjust how quickly the reset attempts to correct for any offset. The reset time constant must be greater than the derivative time constant. If the reset time constant is too small, the engine will continually oscillate. If the reset time constant is too large, the engine will take too long to settle at a steady state.

Parameter 85

Power controller derivat.Tv	0.00s
--------------------------------	-------

**P controller: derivative-action time**

**0.00 to 6.00 s**

The derivative-action time  $T_v$  represents the D-component of the PID controller. By increasing this parameter, the stability of the system is increased. The controller will attempt to slow down the action of the throttle in an attempt to prevent excessive overshoot or undershoot. Essentially this is the brakes for the process. This portion of the PID loop operates anywhere within the range of the process unlike reset.

## Partial Load Limit

Parameter 86

Warm up load limit value	000%
-----------------------------	------

**P controller: partial load limit**

**5 to 110 %**

If the engine requires warming up, the control may be configured to run with a partial load. The partial load value is configured as a percentage of the generator load rating. Refer to generator rated power (Parameter 28).

Parameter 87

Warm up load time	000s
----------------------	------

**P controller: partial load limit time**

**0 to 600 s**

The time period for the partial load warm up is configured in this screen. The time period is started with the initial closing of the GCB. If a partial load warm up period is not desired, this parameter must be configured as zero.

### Load/var Sharing

Parameter 88

Active power  
load share ON

**Load sharing** **ON/OFF**

---

- ON** .....Real power is shared between all generators operating in parallel. The power output by each generator is dependent upon the individually configured values. The subsequent screens of this function are displayed.
- OFF** .....Load sharing is not carried out, and the subsequent screens of this function are not displayed.

Parameter 89

Act.load share  
factor 00%

**Load sharing: reference variable** **10 to 99 %**

---

The load sharing reference variable is a weighing factor. By increasing the configured value, the greater priority the primary control variable becomes. By lowering the configured value, the greater priority the secondary control variable becomes.

Definition "primary control variable"

- Isolated operation = frequency control
- Mains parallel operation = real power control at the mains interchange (import/export)

Definition "secondary control variable"

- Isolated operation = real power load sharing in reference to the other generators
- Mains parallel operation = real power load sharing in reference to the other generators

Parameter 90

Reactive power  
load share ON

**var sharing** **ON/OFF**

---

- ON** .....Re-active power is shared between all generators operating in parallel. The power output by each generator is dependent upon the individually configured values. The subsequent screens of this function are displayed.
- OFF** .....Re-active load sharing is not carried out, and the subsequent screens of this function are not displayed.

Parameter 91

React.load share  
factor 00%

**var sharing: reference variable** **10 to 99 %**

---

The load sharing reference variable is a weighing factor. By increasing the configured value, the greater priority the primary control variable becomes. By lowering the configured value, the greater priority the secondary control variable becomes.

Definition "primary control variable"

- Isolated operation = voltage control
- Mains parallel operation = re-active power control at the mains interchange (import/export)

Definition "secondary control variable"

- Isolated operation = re-active load sharing in reference to the other generators
- Mains parallel operation = re-active load sharing in reference to the other generators
- 

Var sharing is only performed during parallel isolated operations.

## Interface

### CAN Bus (Terminal X1 to X5)

Parameter 92

Control via COM X1X5	ON
-------------------------	----

**CAN bus: control via interface COM X1-X5**

**ON/OFF**

- ON**..... Control via the serial interface is enabled if the direct configuration parameter is configured to "OFF" (Parameter 5), "Control via COM X1X5" configured to "ON", the AUTOMATIC operating mode is enabled, and the discrete input "Setpoint 1↔2" (terminal 5) has been energized. The generator can be given a remote start, synchronized, and the GCB can be opened via the CAN bus (refer to Appendix F, page 146, for a description of the interface telegram). The generator real power setpoint and the generator power factor set point may also be transmitted. If an unsuccessful data exchange is determined, a class F1 alarm is initiated.
- OFF**..... Interface monitoring is disabled. The control unit does not receive control data via the CAN bus. The internally power setpoint "P<sub>Set-point2</sub>" is enabled with the discrete input "Setpoint 1↔2" (terminal 5). At the same time, the internal power factor set point is enabled.

# Breaker



Parameter 93

Configure Breaker	YES
-------------------	-----

## Configure breakers

YES/NO

Various groups of parameters are grouped together in blocks to aid in the rapid navigation through the large number of configuration screens. Selecting "YES" or "NO" does not determine if control or monitoring is performed. The user's selection has the following effect:

**YES** .....The configuration screens in this block are displayed and can either be viewed ("Select" push button) or modifications can be made to the parameters ("Cursor→", "Digit↑" or "Select" push buttons). This does not disable or enable individual parameters, only if the individual parameters in this parameter block may be accessed for modifications.

**NO** .....The parameters in this block are not displayed, cannot be modified and are therefore skipped.

## Breaker Logic

Parameter 94

Breaker logic:	-----
----------------	-------

## Breaker logic

see below

The unit automatically controls the two breakers (MCB and GCB). Up to five (5) breaker logic modes may be selected from. These are: EXTERNAL and PARALLEL for MFR-31 & MFR-32, and OPEN TRANSIT, CLOSED TRANSIT, and INTERCHANGE for MFR-32.



### NOTE

For a dead bus start it is necessary to enable the dead bus start function. To trigger the watchdogs "generator underfrequency" as well as "generator undervoltage", terminal 6 (enable monitoring) must be energized. It is possible to switch the breaker logic by energizing and de-energizing discrete input [D03] (terminal 64). The second breaker logic may be configured during the configuration of the discrete inputs. When discrete input [D03] is energized, the second breaker logic is enabled.



Logics



**CAUTION**

Following table is valid only if Parameter 241 "Download and open GCB" is configured "ON".

Operation mode MANUAL	Operation mode AUTOMATIC
<p>Breaker logic <b>EXTERNAL</b>                      In this operating mode, the MCB and the GCB are operated in "MANUAL" mode only.</p>	
<p>The MCB and the GCB can be manually opened and closed without synchronization. The circuit breakers are opened for decoupling from the mains.</p>	<p>All breaker control must be carried out via a master controller (e.g. a PLC). The MFR 3 issues the breaker open commands under fault conditions.</p>
<p>Breaker logic <b>PARALLEL</b> - Mains parallel operation                      This breaker logic represents continuous mains parallel operation.</p>	
<p>Mains parallel operation can be initiated by pressing the "GCB ON" or "MCB ON" push-button.</p>	<p>By energizing terminal 3 "Enable GCB", the GCB is synchronized or closed to the dead busbar without synchronization and the generator initiates a mains parallel operation. When terminal 3 is de-energized, the generator performs a power reduction and opens the GCB.</p>
<p>Breaker logic <b>OPEN TRANSITION</b> - break-before-make                      With this breaker logic, the MCB and GCB are never synchronized.</p>	
<p>The source of power can be changed from either the mains or generator without synchronization by pressing the "GCB ON" or "MCB ON" push-button.</p>	<p>When terminal 3 "Enable GCB" is energized, the system changes to generator operation. When terminal 3 "Enable GCB" is de-energized, the system changes back to mains operation. If terminal 53 is not energized, the MCB remains closed even if the busbar is voltage-free - terminal 53 "Enable MCB" must be energized.</p>
<p>Breaker logic <b>CLOSED TRANSITION</b> - make-before-break                      In this breaker logic, the MCB and the GCB are synchronized, in order to avoid a voltage-free busbar. Immediately after the synchronization of one breaker, the other is opened. Continuous mains parallel operation is not possible.</p>	
<p>Via the "GCB ON" and "MCB ON" push-button, synchronization to either generator or the mains operation is performed.</p>	<p>The GCB is synchronized and closed via a signal "Enable GCB" (terminal 3 energized). The MCB is then opened. Following disabling the "Enable GCB" signal, the MCB is reverse synchronized and closed. The GCB is then opened.</p>
<p>Breaker logic <b>INTERCHANGE</b> - soft loading                      In this breaker logic, the MCB and the GCB are synchronized, in order to avoid a voltage-free busbar. The generator assumes load at the configured rate, avoiding block loading or unloading. Continuous mains parallel operation is not possible. When terminal 3 "Enable GCB" is de-energized, the MCB is synchronized. The set point of the mains import power must be set to "10000kW", the mains current transducer or the analog input for the mains power measuring (option IN20) must be connected to the control.</p>	
<p>By pressing either the "GCB ON" or "MCB ON" push button, synchronization to either generator or mains operation can be carried out. The power controller must be enabled. If during an interchange synchronization "zero" import power is not achieved within the configured time, a message and a class 1 alarm are issued.</p>	<p>When terminal 3 "Enable GCB" is energized, the GCB is synchronized and the generator assumes load until a mains interchange power = 0 kW is reached. The MCB is then opened. When terminal 3 "Enable GCB" is de-energized, the MCB is reverse synchronized, the generator performs a power reduction, and the GCB is then opened.</p>

Parameter

Parameter 95

Add-off ramp  
max.time 000s

Add-on/add-off ramp 0 to 999 s

This time can be used to influence two functions:

**Add-off:** The maximum amount of time the generator has to shed load below 3% of the generator load rating (Parameter 28) is configured here. If the generator has not dropped below 3% of the generator load rating within this time period, the GCB is opened.

**Add-on with soft loading:** If the mains interchange (import/export) real power value does not reach 0kW in breaker logic "INTERCHANGE" within the time configured here, a class F1 alarm and an alarm message are issued. In addition, the relay manager relay programmed with relay manager function 93 (Appendix E) is enabled and the MCB is prevented from opening.

Parameter 96

GCB open at F2  
max.time 000s

Max. permissible time with F2 prior to open the GCB 0 to 999 s

Prerequisite: Load sharing and automatic start/stop are configured "ON". The generator is in isolated operation and at least one additional generator is connected to the busbar.

If a class F2 alarm occurs, shutting the generator down is delayed by the time configured here. This gives another generator the opportunity to start and assume the load. The generator is shut down when this time expires.

Parameter 97

Signal logic GCB  
-----

GCB: signal logic Continuous/Impulse

**Continuous** ..The "Command: close GCB" relay can be looped directly into the self-holding circuit of the power circuit breaker. After the connect pulse has been issued and the reply from the GCB has been received, the "Command: close GCB" relay remains energized. If the power circuit breaker has to be opened, the relay de-energizes.

**Impulse** .....The "Command: close GCB" relay issues a connect pulse. An external holding circuit must perform the GCB self-holding functions of the GCB. The reply of the GCB is used to detect the closed contacts.

In both cases, the "Command: open GCB" relay energizes to open the breaker.

Parameter 98

Opening GCB  
-----

GCB: open (terminal 41/42) NO-cont./NC-cont.

**NO-cont.** .....If the GCB is to be opened, the "Command: open GCB" relay (terminal 41/42) is energized. Following "Reply: GCB is open" the relay is de-energized again.

**NC-cont.**.....If the GCB is to be opened, the "Command: open GCB" relay (terminal 41/42) is de-energized. Following "Reply: GCB is open" the relay is energized again.

## Synchronization

Parameter 99

<b>Synchronize</b>	
<b>df max</b>	0.00Hz

**Synch.: max. permissible differential frequency (pos. slip) 0.02 to 0.49 Hz**

This is the upper frequency differential limit for synchronization. The prerequisite for a breaker closure command is that the positive frequency differential be lower than the configured value. A positive value corresponds to positive slip. This means that the generator frequency is higher than the busbar frequency for synchronizing the GCB or the bus bar frequency is higher than the mains frequency for synchronizing the MCB.

Parameter 100

<b>Synchronize</b>	
<b>df min</b>	-0.00Hz

**Synch.: max. permissible differential frequency (neg. slip) 0.00 to -0.49 Hz**

This is the lower frequency differential limit for synchronization. The prerequisite for a breaker closure command is that the negative frequency differential be lower than the configured value. A negative value corresponds to negative slip. This means that the generator frequency is lower than the busbar frequency for synchronizing the GCB or the bus bar frequency is lower than the mains frequency for synchronizing the MCB.

Parameter 101

<b>Synchronize</b>	
<b>dV max</b>	00.0%

**Synch.: max. permissible differential voltage 00.1 to 15.0 %**

The measured voltage differential between the two systems to be connected cannot exceed the percentage value configured here for a connect command to be issued.

Parameter 102

<b>Synchronize</b>	
<b>time pulse</b>	>0.00s

**Synch.: pulse time 0.02 to 0.26 s**

The duration of the connect pulse can be adjusted for the switching element. This applies to synchronization and dead bus start closure.

Parameter 103

<b>Closing time</b>	
<b>GCB</b>	000ms

**Synch.: inherent breaker time GCB 40 to 300 ms**

The time configured here permits the control to compensate for the inherent delay in the GCB from the time it receives the command to close and the contacts are closed. This permits the controller to issue the closure command independent of the differential frequency so that the GCB contacts close at the synchronous point.

Parameter 104

<b>closing time</b>	
<b>MCB</b>	000ms

**Synch.: inherent breaker time CB 40 to 300 ms**

The time configured here permits the control to compensate for the inherent delay in the MCB from the time it receives the command to close and the contacts are closed. This permits the controller to issue the closure command independent of the differential frequency so that the MCB contacts close at the synchronous point.

Parameter 105

<b>Autom. breaker</b>	
<b>deblocking</b>	ON

**Synch.: breaker de-blocking ON/OFF**

**ON**..... Prior to each connect pulse, a "Command: open GCB" or "Command: open MCB" is issued for 1 second. A connect signal is then issued until the circuit breaker is closed.

**OFF**..... Circuit breaker initialization on closing is carried out only via the connect pulse. No open pulse is issued prior to the close pulse.

## Synchronization Time Monitoring

Parameter 106

<code>Sync.time contr.</code> <code>ON</code>
--

**Synchronization time monitoring** **ON/OFF**

---

**ON** .....Synchronization time monitoring is performed. The subsequent screens of this function are displayed.

**OFF** .....Synchronization time monitoring is not performed. Synchronization is attempted until it is accomplished. The subsequent screens of this function are not displayed.

Parameter 107

<code>Sync.time contr.</code> <code>Delay</code> <code>000s</code>
---

**Synchronization time monitoring: final value** **10 to 999 s**

---

When the synchronization of the GCB or MCB is initiated, this timer is started after the delayed monitoring functions have expired. If the circuit breaker to be synchronized has not closed prior to this timer expiring, a message and a class F1 alarm are issued. The control continues to attempt to synchronize the breaker.

<b>Tripping of class F1 alarm</b>
-----------------------------------

## Dead Bus Start

If the busbar is in a voltage-free state, the direct connection (dead bus start) of the GCB or MCB may be carried out. If both connect commands are issued simultaneously, priority is given to the MCB if the input "Enable MCB" (terminal 53) is energized.



### NOTE

The MCB is never opened except in a mains failure function.

Parameter 108

GCB dead bus op.	ON
------------------	----

**Dead bus start GCB** **ON/OFF**

**ON**..... A dead bus start is performed in the event of a de-energized busbar and an open MCB. The prerequisite for the dead bus operation to initiate is the detection of operating conditions, which correspond to the configured specifications below. The subsequent screens of this function are displayed.

**OFF**..... A dead bus start is not performed, and the subsequent screens of this function are not displayed.

Parameter 109

GCB dead bus op.	df max	0.00Hz
------------------	--------	--------

**Dead bus start: max. permissible differential frequency GCB** **0.05 to 5.00 Hz**

The prerequisite to issuing a close command is that the monitored generator frequency does not deviate from the generator rated frequency by more than the value configure here.

Parameter 110

GCB dead bus op.	dV max	00.0%
------------------	--------	-------

**Dead bus start: max. perm. differential voltage GCB** **00.1 to 20.0 %**

The prerequisite to issuing a close command is that the monitored generator voltage does not deviate from the generator rated voltage by more than the percentage configure here.

Parameter 111

GCB dead bus op.	max.time	000s
------------------	----------	------

**Dead bus start: max. time to close the GCB** **0 to 999 s**

If the GCB is to be closed onto a dead busbar, this timer is initiated at the start of the breaker closing sequence. If the breaker fails to close before the configured time expires, a class F1 alarm is issued.

<b>Tripping of class F1 alarm</b>
-----------------------------------

Parameter 112

MCB dead bus op.	ON
------------------	----

**Dead bus start MCB** **ON/OFF**

**ON**..... A dead bus start is performed in the event of a de-energized busbar and an open GCB. The subsequent screens of this function are displayed.

**OFF**..... A dead bus start is not performed.

### Breaker Monitoring

Parameter 113

Supervision GCB  
ON

**Breaker monitoring GCB** ON/OFF

**ON** .....Monitoring of the GCB is performed (except in the "EXTERNAL" CB logic). If the circuit breaker cannot be closed by the fifth attempt, the relay manager function 89 relay is energized and a class F1 alarm and message are issued. The control unit continues to attempt to close the GCB. If, 2 seconds following a "Command: open GCB" pulse, the "Reply: GCB is open" is detected, the relay manager function 91 relay is energized and an alarm message is displayed. If the generator is load sharing, the add-on command is deleted so that another control can close the breaker.

**Tripping of class F1 alarm**

**OFF** .....Monitoring is not performed.

Parameter 114

Supervision MCB  
ON

**Breaker monitoring MCB** ON/OFF

**ON** .....Monitoring of the MCB is performed (except in the "EXTERNAL" CB logic). If the circuit breaker cannot be closed by the fifth attempt, the relay manager function 90 relay is energized and a class F1 alarm and message are issued. The control unit continues to attempt to close the MCB. If, 2 seconds following a "Command: open MCB" pulse, the "Reply: MCB is open" is detected, the relay manager function 92 relay is energized and an alarm message is displayed. If the generator is load sharing, the add-on command is deleted so that another control can close the breaker.

**Tripping of class F1 alarm**

**OFF** .....Monitoring is not performed.

### Mains Decoupling

If the application the control unit is being configured for is an isolated system, this configuration screen and its settings do not apply. If the application is a single-breaker unit in a mains parallel operation, the GCB is configured as always open.



#### NOTE

The "Blocking of mains protection" input (terminal 61) disables mains monitoring and decoupling.

Parameter 115

Mains decoupling  
via ---

**Mains decoupling through ...** MCB/GCB

The fault condition decoupling logic for the control unit is configured here. If the generator is used in a parallel isolated application, the MCB must be configured here. If the generator is to be used in a mains parallel application, the GCB must be configured to decouple.

### Mains Settling Time

Parameter 116

Mains settling  
time 000s

**Mains settling time** 0 to 999 s

It is possible for to delay the synchronization of the generator to the mains for the period of time configured here. This will permit the user to ensure that the mains voltage is stable while the generator continues to operate in an isolated (parallel) mode or idle offline.

# Protection



Parameter 117

Configure Monitoring	YES
----------------------	-----

## Configure monitoring

YES/NO

Various groups of parameters are grouped together in blocks to aid in the rapid navigation through the large number of configuration screens. Selecting "YES" or "NO" does not determine if control or monitoring is performed. The user's selection has the following effect:

**YES**..... The configuration screens in this block are displayed and can either be viewed ("Select" push button) or modifications can be made to the parameters ("Cursor→", "Digit↑" or "Select" push buttons). This does not disable or enable individual parameters, only if the individual parameters in this parameter block may be accessed for modifications.

**NO**..... The parameters in this block are not displayed, cannot be modified and are therefore skipped.

## Mains Power Monitoring

A main power limit may be configured and monitored. One of the freely configurable relays may also be assigned relay manager function 84 so that the system may disconnect from the load via an external circuit.



### NOTE

This function does not issue a centralized alarm or output a message. Only a relay output is enabled, which must be monitored externally.



### CAUTION

Mains power monitoring is not designed as a generator protective function. If this function is to be used for generator protection, it must be utilized in conjunction with an external circuit.

Parameter 118

Mains power mon.	ON
------------------	----

## Mains power monitoring

ON/OFF

**ON**..... Mains power monitoring is enabled. One relay must be configured with relay manager function 84. The subsequent screens of this function are displayed.

**OFF**..... Mains power monitoring is not enabled. The subsequent screens of this function are not displayed.

Parameter 119

Mains power mon. res.val.	B00000kW
---------------------------	----------

## Mains power monitoring: limit

E/I 0 to 16,000 kW

The monitored limit value is configured here. If the value is exceeded, the configured relay is energized. Incoming/import power is entered with a "-", before the value. Outgoing/export power is entered with a "+" before the value. When the value is saved the "-" becomes "I" and the "+" becomes "E".

Parameter 120

Mains power mon. hysteresis	000kW
-----------------------------	-------

## Mains power monitoring: hysteresis

0 to 999 kW

If the monitored limit has been exceeded, the power must drop below the mains power monitoring limit value by the value configured here before the relay will de-energize.

Parameter 121

Mains power mon. Dealy	000s
------------------------	------

## Mains power monitoring: delay

0 to 600 s

The mains power monitoring threshold limit must be exceeded, without interruption, for the time period configured here before the configured relay will be energized.

### Reverse/Reduced Power Monitoring



#### NOTE

All percentage indications of the power are in relation to the generator rated power (Parameter 28).

**Function:** "Real power not within the permissible range"

The real power measured in a single phase or in three phases is below the configured limit value for the minimum load or below the configured value for reverse power. By configuring positive threshold values (minimum load monitoring), a shutdown can be performed before the generator goes into reverse power.

Parameter 122

Rev./red.power monitoring ON

**Generator reverse/reduced power** ON/OFF

- ON.....Generator real power monitoring is enabled. The subsequent screens of this function are displayed.
- OFF.....Generator power monitoring is not enabled. The subsequent screens of this function are not displayed.

Parameter 123

Rev./red.power resp.value -00%

**Generator reverse/reduced power: limit** -99 to 99 %

**Reverse power monitoring:** When the real power falls below the negative percentage limit value, the unit recognizes a reverse power condition. The unit issues a class F3 a alarm.

**Reduced power monitoring:** When the real power falls below the positive percentage limit value, the unit recognizes a reduced power condition. The unit issues a class F3 a alarm.

**Tripping of class F3 alarm**

Parameter 124

Rev./red.power Delay 00.0s

**Generator reverse/reduced power: delay** 00.1 to 99.9 s

The reverse/reduced power monitoring threshold limit must be exceeded, without interruption, for the time period configured here before the configured relay will be energized.



## Generator Overload Monitoring



### NOTE

All percentage indications of the power are in relation to the generator rated power (Parameter 28).

**Function:** "Positive real power not within the permissible range"

The real power of the generator is outside the configured overload limit values, and an alarm is issued.

Parameter 125

Gen.overload monitoring	ON
-------------------------	----

**Generator overload** **ON/OFF**

**ON**..... Generator overload monitoring is enabled. The subsequent screens of this function are displayed.

**OFF**..... Generator overload monitoring is not performed. The subsequent screens of this function are not displayed.

Parameter 126

Gen.overload MOP resp.value	000%
-----------------------------	------

**Generator overload: limit MOP (Mains Operating in Parallel)** **80 to 150 %**

The value configured in this screen is a percentage of the configured generator rated power. If this level is reached or exceeded for the configured delay time, the unit issues an alarm and opens the GCB.

<b>Tripping of class F2 alarm</b> without load shedding
--

Parameter 127

Gen.overload MOP Delay	00s
------------------------	-----

**Generator overload: delay MOP (Mains Operating in Parallel)** **0 to 99 s**

The generator overload MOP monitoring threshold limit must be exceeded, without interruption, for the time period configured here before the configured relay will be energized.

Parameter 128

Gen.overload IOP resp.value	000%
-----------------------------	------

**Generator overload: limit IOP (Isolated Operating in Parallel)** **80 to 150 %**

The value configured in this screen is a percentage of the configured generator rated power. If this level is reached or exceeded for the configured delay time, the unit issues an alarm and opens the GCB.

<b>Tripping of class F2 alarm</b> without load shedding
--

Parameter 129

Gen.overload IOP Delay	00s
------------------------	-----

**Generator overload: delay IOP (Isolated Operating in Parallel)** **0 to 99 s**

The generator overload IOP monitoring threshold limit must be exceeded, without interruption, for the time period configured here before the configured relay will be energized.

### Generator Re-active Power Monitoring



#### NOTE

All percentage indications of the power are in relation to the generator rated power (Parameter 28).

**Function:** "Re-active power not within the permissible range"

The re-active power of the generator is outside the configured re-active power limits, and an alarm is issued.

Parameter 130

Reactive power  
Monitoring ON

**Re-active power monitoring** ON/OFF

**ON**.....Generator inductive re-active power monitoring is enabled. The subsequent screens of this function are displayed.

**OFF**.....Generator inductive re-active power monitoring is not performed. The subsequent screens of this function are not displayed.

### Inductive Re-active Power Monitoring

Parameter 131

Reactive pow.ind  
Limit 000%

**Re-active (inductive) power: limit** 5 to 100 %

The value configured in this screen is a percentage of the configured generator rated power. If this level is reached or exceeded for the configured delay time, the unit issues an alarm and opens the GCB.

**Tripping of class F3 alarm**

Parameter 132

Reactive pow.ind  
Delay 000s

**Re-active (inductive) power: delay** 0 to 600 s

The generator inductive re-active power monitoring threshold limit must be exceeded, without interruption, for the time period configured here before the configured relay will be energized.

### Capacitive Re-active Power Monitoring (Loss of Excitation)

Parameter 133

Reactive pow.cap  
Limit 000%

**Re-active (capacitive) power: limit** 5 to 100 %

The value configured in this screen is a percentage of the configured generator rated power. If this level is reached or exceeded for the configured delay time, the unit issues an alarm and opens the GCB.

**Tripping of class F3 alarm**

Parameter 134

Reactive pow.cap  
Delay 000s

**Re-active (capacitive) power: delay** 0 to 600 s

The generator capacitive re-active power monitoring threshold limit must be exceeded, without interruption, for the time period configured here before the configured relay will be energized.

## Time-Overcurrent Monitoring (TOC)



### NOTE

All percentage indications of the current are in relation to the generator rated current (Parameter 29).

**Function:** The user may configure two steps for time-overcurrent monitoring. The threshold values and delays can be configured so that the individual set points are independent of each other. Overcurrent level 1 disconnects lower overcurrent levels that are present over longer periods of time. Overcurrent level 2 disconnects the more destructive higher currents quickly to protect against short circuit conditions.




Figure 6-1: Characteristic of the time-overcurrent monitoring

Parameter 135

Gen.overcurrent monitoring	ON
----------------------------	----

**Time-overcurrent monitoring** **ON/OFF**

- ON**..... Generator overcurrent monitoring is enabled. The subsequent screens of this function are displayed.
- OFF**..... Generator overcurrent monitoring is not performed. The subsequent screens of this function are not displayed.

Parameter 136

Gen.overcurr. 1 resp.value	000%
----------------------------	------

**Time-overcurrent: limit 1** **0 to 300 %**

The value configured in this screen is a percentage of the configured generator rated current. If this level is reached or exceeded for the configured delay time, the unit issues an alarm and opens the GCB.

<b>Tripping of class F3 alarm</b>
-----------------------------------

Parameter 137

Gen.overcurr. 1 Delay	00.00s
-----------------------	--------

**Time-overcurrent: delay 1** **0.02 to 99.98 s**

The generator time-overcurrent monitoring threshold limit 1 must be exceeded, without interruption, for the time period configured here before the configured relay will be energized.

Parameter 138

Gen. overcurr. 2
resp. value 000%

**Time-overcurrent: limit 2**

**0 to 300 %**

The value configured in this screen is a percentage of the configured generator rated current. If this level is reached or exceeded for the configured delay time, the unit issues an alarm and opens the GCB.

<b>Tripping of class F3 alarm</b>
-----------------------------------

Parameter 139

Gen. overcurr. 2
Delay 00.00s

**Time-overcurrent: delay 2**

**0.02 to 99.98 s**

The generator time-overcurrent monitoring threshold limit 2 must be exceeded, without interruption, for the time period configured here before the configured relay will be energized.

## Inverse Time-Overcurrent Monitoring



### NOTE

All percentage indications of the current are in relation to the generator rated current (Parameter 29).

**Function:** Monitoring of overcurrents including inversely proportional time dependent tripping characteristic. The selected trip curve defines the tripping time according to the measured current. The tripping time will be decreased according to a defined curve the higher the measured current is. According to IEC 255 three different characteristics are available.

normal inverse: 
$$t = \frac{0.14}{(I/I_p)^{0.02} - 1} * t_p [s]$$

high inverse: 
$$t = \frac{13.5}{(I/I_p) - 1} * t_p [s]$$

extreme inverse: 
$$t = \frac{80}{(I/I_p)^2 - 1} * t_p [s]$$

- Variables:
- $t$  tripping time
  - $t_p$  time set point value
  - $I$  fault current / monitored current
  - $I_n$  rated (nominal) current (Parameter 29)
  - $I_p$  current set point value

If  $t$  is greater than 650 s the system trips at 650 s. If  $t$  is lower than  $t_{min}$  the tripping time is  $t_{min}$ . The reaction time for  $t_{min}$  depends on the time it takes to monitor the fault and the operating time of the relays.  $t_{min}$  is at least 20 ms.

Please consider during configuration:

- for  $I_{start}$ :  $I_{start} > I_n$  and  $I_{start} > I_p$
- for  $I_p$  the smaller  $I_p$  is, the steeper is the slope of the tripping curve

Configuration Screens

Parameter 140

Inv.time ov.cur.  
Monitor. ON

Inverse time-overcurrent monitoring

ON/OFF

ON..... Inverse time-overcurrent monitoring is enabled. The subsequent screens of this function are displayed.

OFF..... Inverse time-overcurrent monitoring is disabled. The subsequent screens of this function are not displayed.

Parameter 141

Inv.time char.  
-----

Inverse time-overcur.: characteristic

normal inv./high inv./extremely inv.

normal inv..... "normal inv." tripping characteristic is used.

high inv..... "high inv." tripping characteristic is used.

extremely inv. ... "extremely inv." tripping characteristic is used.

Tripping of class F3 alarm

Parameter 142

Inv.time ov.cur.  
Tp=0.00s

Inverse time-overcurrent: time constant Tp

0.00 to 1.98s

The time constant for  $t_p$  is defined by this parameter.

Parameter 143

Inv.time ov.cur.  
Ip=0.0\*In

Inverse time-overcurrent: current constant Ip

0.1 to 3.0\*In

The current constant for  $I_p$  is defined by this parameter. This set point is dependent upon the rated current ( $I_n$ )

Parameter 144

Inv.time ov.cur.  
I start= 0.00\*In

Inverse time-overcurrent: I start

1.00 to 3.00\*In

The lower tripping value for inverse time-overcurrent protection is defined by this parameter. If the monitored current ( $I$ ) is below  $I_{start}$ , the inverse time-overcurrent protection does not trip.  $I_p$  is used as the lower tripping value if  $I_{start}$  is configured less than  $I_p$ .

Characteristics




Figure 6-2: Inverse time-overcurrent - characteristic "normal inverse"




Figure 6-3: Inverse time-overcurrent - characteristic "high inverse"




Figure 6-4: Inverse time-overcurrent - characteristic "extremely inverse"

## Inverse Time-Overcurrent Monitoring with Voltage Restraint



### NOTE

This monitoring function is an additional functionality for the inverse time overcurrent monitoring function. If the inverse time overcurrent monitoring is disabled (Parameter 140), time-overcurrent monitoring with voltage restraint is disabled too.

All percentage indications of the current are in relation to the generator rated current (Parameter 29).

**Function:** This function is recommended for a generator that must be monitored with droop excitation and precautions for short-circuit excitation (e.g. supplementary components) are not available. A short-circuit close to the terminal may be caused due to the low voltage excitation cannot be maintained. As a result, the unit cannot maintain power in order to initiate a voltage independent overcurrent delay. The voltage restraint functionality reduces the overcurrent threshold of the inverse time overcurrent monitoring function proportionally with the monitored voltage if this function is enabled. If the monitored voltage falls below the threshold defined by the knee curve setting (Parameter 146), the overcurrent threshold remains at the value of the knee curve setting. The reduction of the inverse time threshold occurs according to Figure 6-5.

Current L1: corresponds to voltage L1-L2

Current L2: corresponds to voltage L2-L3

Current L3: corresponds to voltage L3-L1




Figure 6-5: Characteristic of the inverse time-overcurrent monitoring with voltage restraint (knee curve setting 20 %)

Legend:	$I_a$	Adjusted current threshold value
	$I_p$	Configured value (Parameter 143)
	$V_n$	Rated voltage
	$V$	Monitored voltage

Example:

Initial conditions:

Rated voltage  $V_n = 100 \text{ V}$

Configured value  $I_p = 2.0 * 5 \text{ A} = 10 \text{ A}$  (rated current  $I_n = 5 \text{ A}$ )

Case 1 (monitored voltage  $V > 90\% V_n$ ):

As long as the monitored voltage exceeds 90% of the rated voltage, the configured value will not be adjusted.

->  $I_a = I_p$

Case 2 (monitored voltage  $V < 90\% V_n$ , but actual voltage  $V >$  knee curve setting):

If the monitored voltage falls below 90% of the rated voltage, the configured value is adjusted proportionally with the ratio of monitored and rated voltage.

->  $I_a = (V/V_n) * I_p$

Case 3 (monitored voltage  $V <$  knee curve setting):

If the monitored voltage falls below the percentage value of the rated voltage configured by the knee curve setting (Parameter 146), the configured value is adjusted to the proportional value at the knee curve setting.

->  $I_a = \{(knee \text{ point setting in } [\%])/100\} * I_p$

If the knee curve setting is configured to 20% for example and the monitored voltage is lower than 20% of the rated voltage, the adjusted value  $I_a$  falls not below 20% of the configured value  $I_p$ .

Parameter 145

Inv.time ov.cur. V-restr.        ON
--

**Voltage restraint time-overcurrent** **ON/OFF**

**ON** .....Inverse time-overcurrent monitoring with voltage restraint is enabled. The subsequent screens of this function are displayed.

**OFF** .....Inverse time-overcurrent monitoring is not performed. The subsequent screens of this function are not displayed.

Parameter 146

Inv.time ov.curr knee curve U>00%
--------------------------------------

**Voltage restraint time-overcurrent** **10 to 90 %**

The threshold limit for the voltage is defined in this parameter. The knee of the curve describes the lower limit of the threshold value lowering, i.e. the trip current belonging to this limit remains valid and will not be lowered further in case of an additional voltage drop.

<b>Tripping of alarm class 3</b>
----------------------------------



## Earth Fault Monitoring

### Calculation of the ground current:

The measuring of the ground current is based on the calculation of the vectoral sum of the three phase currents. To ensure that the ground fault protection operates properly, the configured ground currents should be a minimum of 10% of the current transformer's rating.

Parameter 147

<b>Earth fault monitoring    ON</b>
---

### Ground fault monitoring

**ON/OFF**

**ON**..... Ground fault monitoring is enabled. The subsequent screens of this function are displayed.

**OFF**..... Ground fault monitoring is not performed. The subsequent screens of this function are not displayed.

Parameter 148

<b>Earth fault response v. 000%</b>
---

### Threshold ground current limit

**5 to 100 %**

If the value of the ground current exceeds the entered percentage, the unit issues an alarm. In an additional relay is configured in the relay manager the alarm is also transmitted to this relay.

Parameter 149

<b>Earth fault delay        00,00s</b>
--

### Earth fault delay

**0.02 to 99.98 s**

The ground fault monitoring threshold limit must be exceeded, without interruption, for the time period configured here before the configured relay will be energized.

# Generator Load Imbalance Monitoring



## NOTE

All percentage indications of the current are in relation to the generator rated current (Parameter 29).

**Function:** "Generator load imbalance not within the permissible range"

The threshold value, expressed as a percentage, specifies the permissible deviation of the current in a conductor from the calculated mean value of all three-conductor currents. If the measured value is greater than the threshold value, an alarm is issued.

Parameter 150

Load unbalance  
Monitoring ON

**Unbalanced load** **ON/OFF**

**ON** .....Generator load imbalance monitoring is enabled. The subsequent screens of this function are displayed.

**OFF** .....Generator load imbalance monitoring is not performed. The subsequent screens of this function are not displayed.

Parameter 151

Load unbalance  
max. 000%

**Unbalanced load: limit** **0 to 100 %**

The value configured in this screen is a percentage of the configured generator rated current. If this level is reached or exceeded, the unit issues an alarm and opens the GCB.

**Tripping of class F3 alarm**

Parameter 152

Load unbalance  
Delay 00.00s

**Unbalanced load: delay** **0.02 to 99.98 s**

The load imbalance monitoring threshold limit must be exceeded, without interruption, for the time period configured here before the configured relay will be energized.

## Generator Overfrequency Monitoring

The monitoring of the frequency is carried out at two levels. The measurement of the frequency encompasses all three phases if all voltages are greater than 15 % of the rated value (100 Vac or 400 Vac). This enables a very rapid and precise frequency measurement. The frequency, however, is also correctly detected if voltage in only one phase is present.

**Function:** "Generator frequency not within the permissible range"

A fault condition is recognized if the frequency of the generator is outside of the limit values configured for overfrequency. The enabling of generator overfrequency monitoring is delayed via "Delayed monitoring" in order to enable correct generator start-up. An alarm is issued if a fault condition is detected.

Parameter 153

<b>Gen. overfreq. monitoring</b> ON
-------------------------------------

**Generator overfrequency** **ON/OFF**

**ON**..... Generator overfrequency monitoring is enabled. The subsequent screens of this function are displayed.

**OFF**..... Generator overfrequency monitoring is not performed. The subsequent screens of this function are not displayed.

Parameter 154

<b>Gen. overfreq. 1</b> f >            00.00Hz
---

**Generator overfrequency: limit 1** **40.00 to 85.00 Hz**

The value for overfrequency limit 1 is configured in this screen. If the monitored frequency reaches or exceeds this level for the configured delay time, the unit issues an alarm and opens the GCB.

<b>Tripping of class F3 alarm</b>
-----------------------------------

Parameter 155

<b>Gen. overfreq. 1</b> Delay            00.00s
--

**Generator overfrequency: delay 1** **0.02 to 99.98 s**

The generator overfrequency monitoring threshold limit 1 must be exceeded, without interruption, for the time period configured here before the configured relay will be energized.

Parameter 156

<b>Gen. overfreq. 2</b> f >            00.00Hz
---

**Generator overfrequency: limit 2** **40.00 to 85.00 Hz**

The value for overfrequency limit 2 is configured in this screen. If the monitored frequency reaches or exceeds this level for the configured delay time, the unit issues an alarm and opens the GCB.

<b>Tripping of class F3 alarm</b>
-----------------------------------

Parameter 157

<b>Gen. overfreq. 2</b> Delay            00.00s
--

**Generator overfrequency: delay 2** **0.02 to 99.98 s**

The generator overfrequency monitoring threshold limit 1 must be exceeded, without interruption, for the time period configured here before the configured relay will be energized.

### Generator Underfrequency Monitoring

The monitoring of the frequency is carried out at two levels. The measurement of the frequency encompasses all three phases if all voltages are greater than 15 % of the rated value (100 Vac or 400 Vac). This enables a very rapid and precise frequency measurement. The frequency, however, is also correctly detected if voltage in only one phase is present.

**Function:** "Generator frequency not within the permissible range"

A fault condition is recognized if the frequency of the generator is outside of the limit values configured for underfrequency. The enabling of generator underfrequency monitoring is delayed via "Delayed monitoring" in order to enable correct generator start-up. An alarm is issued if a fault condition is detected.



#### NOTE

Energizing terminal 6 ("monitoring") enables this monitoring.

Parameter 158

Gen.underfreq.  
monitoring ON

**Generator underfrequency** ON/OFF

**ON**.....Generator underfrequency monitoring is enabled. The subsequent screens of this function are displayed.

**OFF**.....Generator underfrequency monitoring is not performed. The subsequent screens of this function are not displayed.

Parameter 159

Gen.underfreq. 1  
f > 00.00Hz

**Generator underfrequency: limit 1** 40.00 to 85.00 Hz

The value for underfrequency limit 1 is configured in this screen. If the monitored frequency reaches or falls below this level for the configured delay time, the unit issues an alarm and opens the GCB.

**Tripping of class F3 alarm**

Parameter 160

Gen.underfreq. 1  
Delay 00.00s

**Generator underfrequency: delay 1** 0.02 to 99.98 s

The generator underfrequency monitoring threshold limit 1 must be exceeded, without interruption, for the time period configured here before the configured relay will be energized.

Parameter 161

Gen.underfreq. 2  
f > 00.00Hz

**Generator underfrequency: limit 2** 40.00 to 85.00 Hz

The value for underfrequency limit 2 is configured in this screen. If the monitored frequency reaches or falls below this level for the configured delay time, the unit issues an alarm and opens the GCB.

**Tripping of class F3 alarm**

Parameter 162

Gen.underfreq. 2  
Delay 00.00s

**Generator underfrequency: delay 2** 0.02 to 99.98 s

The generator underfrequency monitoring threshold limit 1 must be exceeded, without interruption, for the time period configured here before the configured relay will be energized.

## Generator Overvoltage Monitoring

The line-to-line voltage is monitored to detect overvoltage conditions.

**Function:** "Generator voltage not within the permissible range"

At least one phase of the generator voltage is outside of the limit values configured for overvoltage. The enabling of generator overvoltage monitoring is delayed via "Delayed monitoring" in order to enable correct generator start-up. An alarm is issued if a fault condition is detected.

Parameter 163

Gen. overvoltage monitoring	ON
-----------------------------	----

### Generator overvoltage

ON/OFF

**ON**..... Generator overvoltage monitoring is enabled. The subsequent screens of this function are displayed.

**OFF**..... Generator overvoltage monitoring is not performed. The subsequent screens of this function are not displayed.

Parameter 164

Gen. overvolt. 1	
U >	000V

### Generator overvoltage: limit 1

[1] 20 to 150 V; [4] 20 to 520 V

The value for overvoltage limit 1 is configured in this screen. If the monitored voltage reaches or exceeds this level for the configured delay time, the unit issues an alarm and opens the GCB. This value refers to the secondary voltage of the generator PT inputs (Parameter 15).

Tripping of class F3 alarm
----------------------------

Parameter 165

Gen. overvolt. 1	
Delay	00.00s

### Generator overvoltage: delay 1

0.02 to 99.98 s

The generator overvoltage monitoring threshold limit 1 must be exceeded, without interruption, for the time period configured here before the configured relay will be energized.

Parameter 166

Gen. overvolt. 2	
U >	000V

### Generator overvoltage: limit 2

[1] 20 to 150 V; [4] 20 to 520 V

The value for overvoltage limit 2 is configured in this screen. If the monitored voltage reaches or exceeds this level for the configured delay time, the unit issues an alarm and opens the GCB. This value refers to the secondary voltage of the generator PT inputs (Parameter 15).

Tripping of class F3 alarm
----------------------------

Parameter 167

Gen. overvolt. 2	
Delay	00.00s

### Generator overvoltage: delay 2

0.02 to 99.98 s

The generator overvoltage monitoring threshold limit 1 must be exceeded, without interruption, for the time period configured here before the configured relay will be energized.

# Generator Undervoltage Monitoring

The line-to-line voltage is monitored to detect undervoltage conditions.

**Function:** "Generator voltage not within the permissible range"

At least one phase of the generator voltage is outside of the limit values configured for undervoltage. The enabling of generator undervoltage monitoring is delayed via "Delayed monitoring" in order to enable correct generator start-up. An alarm is issued if a fault condition is detected.



## NOTE

Energizing terminal 6 ("monitoring") enables this monitoring.

Parameter 168

Gen.undervolt.  
monitoring ON

**Generator undervoltage** ON/OFF

- ON.....Generator undervoltage monitoring is enabled. The subsequent screens of this function are displayed.
- OFF.....Generator undervoltage monitoring is not performed. The subsequent screens of this function are not displayed.

Parameter 169

Gen.undervolt. 1  
U > 000V

**Generator undervoltage: limit 1** [1] 20 to 150 V; [4] 20 to 520 V

The value for undervoltage limit 1 is configured in this screen. If the monitored voltage reaches or falls below this level for the configured delay time, the unit issues an alarm and opens the GCB. This value refers to the secondary voltage of the generator PT inputs (Parameter 15).

**Tripping of class F3 alarm**

Parameter 170

Gen.undervolt. 1  
Delay 00.00s

**Generator undervoltage: delay 1** 0.02 to 99.98 s

The generator undervoltage monitoring threshold limit 1 must be exceeded, without interruption, for the time period configured here before the configured relay will be energized.

Parameter 171

Gen.undervolt. 2  
U > 000V

**Generator undervoltage: limit 2** [1] 20 to 150 V; [4] 20 to 520 V

The value for undervoltage limit 2 is configured in this screen. If the monitored voltage reaches or falls below this level for the configured delay time, the unit issues an alarm and opens the GCB. This value refers to the secondary voltage of the generator PT inputs (Parameter 15).

**Tripping of class F3 alarm**

Parameter 172

Gen.undervolt. 2  
Delay 00.00s

**Generator undervoltage: delay 2** 0.02 to 99.98 s

The generator undervoltage monitoring threshold limit 1 must be exceeded, without interruption, for the time period configured here before the configured relay will be energized.

## Mains Frequency Monitoring



### NOTE

The "Blocking of mains protection" input (terminal 61) disables mains monitoring and decoupling.

Monitoring of the mains frequency is absolutely vital if a generator is to be operated in parallel with a public utility. In the event of a mains failure (e. g. short interruption) the generator which is in mains parallel operation, must be automatically disconnected from the mains.

#### Function: "Mains frequency not within the permissible range"

The mains frequency is outside of the limit values configured for overfrequency or underfrequency. The power circuit breaker, which is configured to carry out decoupling from the mains, is immediately opened. The prerequisite of mains frequency monitoring is a mains parallel operation (both GCB and MCB are closed). An alarm is issued if a fault condition is detected.

Parameter 173

Mains frequency monitoring	ON
----------------------------	----

#### Mains frequency

ON/OFF

**ON**..... Mains frequency monitoring is enabled. The subsequent screens of this function are displayed.  
**OFF**..... Mains frequency monitoring is not performed. The subsequent screens of this function are not displayed.

Parameter 174

Mains overfreq.	f >	00.00Hz
-----------------	-----	---------

#### Mains overfrequency: limit

40.00 to 70.00 Hz

The value for the mains overfrequency limit is configured in this screen. If the monitored frequency reaches or exceeds this level for the configured delay time, the unit issues an alarm and opens either the GCB or the MCB depending on which is configured for decoupling from the mains.

Tripping of class F0 alarm
----------------------------

Parameter 175

Mains overfreq.	Delay	00.00s
-----------------	-------	--------

#### Mains overfrequency: delay

0.02 to 99.98 s

The mains overfrequency monitoring threshold limit must be exceeded, without interruption, for the time period configured here before the configured relay will be energized.

Parameter 176

Mains underfreq.	f <	00.00Hz
------------------	-----	---------

#### Mains underfrequency: limit

40.00 to 70.00 Hz

The value for the mains underfrequency limit is configured in this screen. If the monitored frequency reaches or falls below this level for the configured delay time, the unit issues an alarm and opens either the GCB or the MCB depending on which is configured for decoupling from the mains.

Tripping of class F0 alarm
----------------------------

Parameter 177

Mains underfreq.	Delay	00.00s
------------------	-------	--------

#### Mains underfrequency: delay

0.02 to 99.98 s

The mains underfrequency monitoring threshold limit must be exceeded, without interruption, for the time period configured here before the configured relay will be energized.

## Mains Voltage Monitoring



### NOTE

The "Blocking of mains protection" input (terminal 61) disables mains monitoring and decoupling.

Monitoring the mains voltage is absolutely vital if a generator is to be operated in parallel with a public utility. In the event of mains failure (e. g. short interruption) the generator which is in mains parallel operation must be automatically disconnected from the mains.

#### Function: "Mains voltage not within the permissible range"

At least one phase of the mains voltage is outside of the limit values configured for overvoltage or undervoltage. The power circuit breaker configured for mains decoupling is immediately opened. The prerequisite of mains voltage monitoring is a mains parallel operation (both GCB and MCB are closed). An alarm message is issued if a fault condition is detected.

Parameter 178

Mains voltage monitoring	ON
--------------------------	----

**Mains voltage** **ON/OFF**

- ON** .....Mains voltage monitoring is enabled. The subsequent screens of this function are displayed.
- OFF** .....Mains voltage monitoring is not performed. The subsequent screens of this function are not displayed.

Parameter 179

Mains volt.monit	U Ph.-N.
------------------	----------

**Mains voltage monitoring** **U Ph.-Ph. / U Ph.-N.**

- U Ph.-Ph.**.....Mains voltage monitoring refers to the phase-phase voltages  $V_{Ph-Ph}$ .
- U Ph.-N.** .....Mains voltage monitoring refers to the phase-neutral voltages  $V_{Ph-N}$ .

Parameter 180

Mains overvolt.	U Ph.-Ph.> 000V
-----------------	-----------------

**Mains overvoltage: limit** **[1] 20 to 150 V; [4] 20 to 520 V**

The phase-phase voltage value for mains overvoltage limit is configured in this screen. If the monitored voltage reaches or exceeds this level for the configured delay time, the unit issues an alarm and opens the GCB. This value refers to the secondary voltage of the mains PT inputs (Parameter 19). This setting is only valid if the mains voltage monitoring (Parameter 179) is configured to U Ph.-Ph.

**Tripping of class F0 alarm**

Parameter 181

Mains overvolt.	U Ph.-N.> 000V
-----------------	----------------

**Mains overvoltage: limit** **[1] 20 to 87 V; [4] 20 to 300 V**

The phase-neutral voltage value for mains overvoltage limit is configured in this screen. If the monitored voltage reaches or exceeds this level for the configured delay time, the unit issues an alarm and opens the GCB. This value refers to the secondary voltage of the mains PT inputs (Parameter 19). This setting is only valid if the mains voltage monitoring (Parameter 179) is configured to U Ph.-N.

**Tripping of class F0 alarm**

Parameter 182

Mains overvolt.	Delay 00,00s
-----------------	--------------

**Mains overvoltage: delay** **0.02 to 99.98 s**

The mains overvoltage monitoring threshold limit must be exceeded, without interruption, for the time period configured here before the configured relay will be energized.



Parameter 183

**Mains undervolt.**  
**U Ph.-Ph.< 000V**

**Mains undervoltage: limit**

[1] 20 to 150 V; [4] 20 to 520 V

The phase-phase voltage value for mains undervoltage limit is configured in this screen. If the monitored voltage reaches or falls below this level for the configured delay time, the unit issues an alarm and opens the GCB. This value refers to the secondary voltage of the mains PT inputs (Parameter 19).

This setting is only valid if the mains voltage monitoring (Parameter 179) is configured to U Ph.-Ph.

**Tripping of class F0 alarm**

Parameter 184

**Mains undervolt.**  
**U Ph.-N.< 000V**

**Mains undervoltage: limit**

[1] 20 to 87 V; [4] 20 to 300 V

The phase-neutral voltage value for mains undervoltage limit is configured in this screen. If the monitored voltage reaches or falls below this level for the configured delay time, the unit issues an alarm and opens the GCB. This value refers to the secondary voltage of the mains PT inputs (Parameter 19).

This setting is only valid if the mains voltage monitoring (Parameter 179) is configured to U Ph.-N.

**Tripping of class F0 alarm**

Parameter 185

**Mains undervolt.**  
**Delay 00.00s**

**Mains undervoltage: delay**

0.02 to 99.98 s

The mains undervoltage monitoring threshold limit must be exceeded, without interruption, for the time period configured here before the configured relay will be energized.

### Mains dφ/dt Phase/Vector Shift Monitoring



#### NOTE

The "Blocking of mains protection" input (terminal 61) disables mains monitoring and decoupling.

A dφ/dt phase/vector jump is a sudden change in the voltage vector angle, and may be caused by a major generator load change. In this case, the measuring circuit detects a change in the cycle duration once. This change in the vector angle is compared with a calculated mean value from previous measurements. Monitoring encompasses all three phases. The threshold value in degrees specifies the difference in time between the mean and the current value in reference to a full cycle. Monitoring can be set in various manners. The dφ/dt phase/vector shift monitoring may be used as an additional method for decoupling from the mains. The minimum voltage at which the phase shift monitoring is enabled is 70 % of the rated PT secondary voltage input.

**Function:** "Voltage cycle duration not within the permissible range"

The voltage vector exceeds the configured limit value for the phase/vector shift. The breaker configured for mains decoupling is opened. The requirement therefore is a mains parallel operation (both GCB and MCB are closed). An alarm is issued if a fault condition is detected.

Parameter 186

Phase shift monitoring	ON
------------------------	----

**dφ/dt phase/vector shift** **ON/OFF**

**ON** .....Mains voltage phase shift monitoring is enabled. The subsequent screens of this function are displayed.

**OFF** .....Mains voltage phase shift monitoring is not performed. The subsequent screens of this function are not displayed.

Parameter 187

Monitoring	-----
------------	-------

**dφ/dt phase/vector shift: type** **one/three-phase / three phase only**

**one/three-phase:** During single-phase voltage phase shift monitoring, tripping occurs if the phase shift exceeds the configured threshold value in any one of the three phases. This type of monitoring is very sensitive, and may lead to nuisance tripping if the configured phase angle settings are too small.

**three phase only:** During three-phase voltage phase shift monitoring, tripping occurs only if the phase shift exceeds the configured threshold value in all three phases within 2 cycles.

**Tripping of class F0 alarm**



**NOTE**

If monitoring is configured to "three phase only", only the second screen will be displayed; if monitoring is configured to "one/three-phase", both screens are displayed.

Parameter 188

Phase shift	
one-phase	00°

This screen is only visible if monitoring is configured to "one/three-phase".

**dφ/dt phase/vector shift: limit single-phase**

**3 to 30 °**

Tripping occurs if the electrical angle of the voltage curve shifts in any one phase by more than this configured angle. If the value is reached or exceeded, the unit issues an alarm message.

Parameter 189

Phase shift	
three-phase	00°

**dφ/dt phase/vector shift: limit three-phase**

**3 to 30 °**

Tripping occurs if the electrical angle of the voltage curve shifts simultaneously in all three phases by more than this configured angle. If the value is reached or exceeded, the unit issues an alarm message.

### Mains df/dt Rate Of Change Of Frequency Monitoring (ROCOF)



#### NOTE

The "Blocking of mains protection" input (terminal 61) disables mains monitoring and decoupling.

#### Function: "Frequency change per time unit not within the permissible range"

The control unit determines a measuring value for the change in frequency per unit of time (Hz/s). In order to enable reliable differentiation between dφ/dt phase/vector shift and df/dt, measurement is carried out over 4 cycles. This results in a minimum tripping time of approx. 100 ms (at 50 Hz). The breaker configured as the mains decoupling breaker is opened. The requirement therefore is a mains parallel operation (both GCB and MCB are closed). An alarm is issued if a fault condition is detected.

Parameter 190

df/dt-monitoring  
ON

df/dt (ROCOF) ON/OFF

- ON.....Mains frequency monitoring is enabled, and any change in frequency per unit of time (Hz/s) within the defined range is registered. The subsequent screens of this function are displayed.
- OFF.....Mains frequency monitoring is not performed. The subsequent screens of this function are not displayed.

Parameter 191

df/dt-monitoring  
release> 0.0Hz/s

df/dt (ROCOF): limit 1.0 to 9.9 Hz/s

The value to be monitored for the ROCOF is configured in this screen. If the monitored frequency reaches or exceeds this level for the configured delay time, the unit issues an alarm and opens in dependence of the setting the GCB or the MCB depending on which is configured for decoupling from the mains.

**Tripping of class F0 alarm**

Parameter 192

df/dt-monitoring  
Delay time 0.0s

df/dt (ROCOF): delay 0.1 to 9.9 s

The ROCOF monitoring threshold limit must be exceeded, without interruption, for the time period configured here before the configured relay will be energized.

### Mains Decoupling (Selection Between dφ/dt and df/dt)

Parameter 193

Mainstrip via  
-----

Mains decoupling via Phase shift / df/dt

The opening of the GCB/MCB (refer to Parameter 115"Mains decoupling via...") may be performed if either df/dt or phase/vector shift monitoring fault condition is detected.

**df/dt**.....Decoupling from the mains is performed if a df/dt fault condition is detected.

**Phase shift**....Decoupling from the mains is performed if a dφ/dt phase/vector shift fault condition is detected.

## Battery Voltage Monitoring

Parameter 194

<b>Batt. undervolt.</b>	
<b>U &lt;</b>	<b>00.0V</b>

**Battery voltage: limit**

**9.5 to 30.0 V**

The battery undervoltage threshold value is configured in this screen. If the monitored voltage reaches or is falls below this level for the configured delay time, the unit issues an alarm.

<b>Tripping of class F1 alarm</b>
-----------------------------------

Parameter 195

<b>Batt. undervolt.</b>	
<b>Delay</b>	<b>00s</b>

**Battery voltage: delay**

**0 to 99 s**

The battery undervoltage monitoring threshold limit must be exceeded, without interruption, for the time period configured here before the configured relay will be energized.

**Note:** Regardless of the configured battery voltage watchdog, readiness for operation is withdrawn and a message is displayed if the power supply falls below 9 Vdc.

# Discrete Inputs



Parameter 196

Configure Dig.input	YES
------------------------	-----

## Configure discrete inputs

YES/NO

Various groups of parameters are grouped together in blocks to aid in the rapid navigation through the large number of configuration screens. Selecting "YES" or "NO" does not determine if control or monitoring is performed. The user's selection has the following effect:

**YES** .....The configuration screens in this block are displayed and can either be viewed ("Select" push button) or modifications can be made to the parameters ("Cursor→", "Digit↑" or "Select" push buttons). This does not disable or enable individual parameters, only if the individual parameters in this parameter block may be accessed for modifications.

**NO** .....The parameters in this block are not displayed, cannot be modified and are therefore skipped.

## Blocking of Operation Mode Selector [D02]

Parameter 197

opMode blocking via term.63	ON
--------------------------------	----

## Blocking of the operating mode selector

ON/OFF

**ON** .....By enabling this discrete input [D02] (terminal 63), the operating mode cannot be changed between MANUAL and AUTOMATIC by pressing the push buttons.

**OFF** .....The discrete input is used as an alarm input.

## Selection of the Mains Decoupling via Discrete Input [D01]

Parameter 198

Mains decoupling via term.62	OFF
---------------------------------	-----

## Mains decoupling via terminal 62

ON/OFF

**ON** .....The designated mains decoupling breaker may be changed according to the state of discrete input [D01]:

- Discrete input [D01] (term. 62) **not energized**: decoupling via GCB
- Discrete input [D01] (term. 62) **energized**: decoupling via MCB

**OFF** .....The discrete input is used as an alarm input.

## Breaker Logic via Discrete Input [D03]

Parameter 199

Breaker logic via term.64 ON
------------------------------

### Breaker logic via discrete input [D03]

ON/OFF

**ON**..... This discrete input is used as a control input:

- Discrete input [D03] (terminal 64) is **not energized**:  
The breaker logic configured in Parameter 94 is used
- Discrete input [D03] (terminal 64) is **energized**:  
The breaker logic configured in Parameter 200 is used

**OFF**..... The discrete input is used as an alarm input.

Parameter 200

Breaker logic: -----
-------------------------

### Breaker logic

see below

The unit automatically controls the two breakers (MCB and GCB). In this case, up to five control functions (modes) may be selected. These are: EXTERNAL, PARALLEL, OPEN TRANSIT, CLOSED TRANSIT and INTERCHANGE.



### NOTE

For a dead bus start it is necessary to enable the dead bus start function. To trigger the watchdogs "generator underfrequency" as well as "generator undervoltage", terminal 6 (enable monitoring) must be energized. It is possible to switch the breaker logic by energizing and de-energizing discrete input [D03] (terminal 64). The second breaker logic may be configured during the configuration of the discrete inputs. When discrete input [D03] is energized, the second breaker logic is enabled.

## Discrete inputs: Setting

Discrete input	1	2	3	4	5	6	7	8	9	10	11	12
Number	1	2	3	4	5	6	7	8	9	A	B	C
Terminal	62	63	64	65	66	67	68	69	70	71	72	73
Function	A/C	A/C	A/C	Alarm input								

A/C..Alarm or control input (dependent on configuration)



### NOTE

**Operating current (NO, make contact):** The discrete input is enabled by energizing it.  
This does not provide wire break monitoring!

**Closed circuit current (NC, break contact):** The discrete input is enabled by de-energizing it.  
This may provide wire break monitoring.

**Example:** Discrete inputs 1 through 4 (same procedure for inputs 5 to 12)

Parameter 201

Dig. input function	1234	EEEE
---------------------	------	------

### Discrete input: function

E/D

The alarm inputs can be enabled regardless if the contact is configured as an operating current (NO) or an idle current (NC) contact. The idle current input enables monitoring for an opening in the circuit. Either a positive or a negative polarity voltage may be applied.

**E** Enable to operate as an operating current (NO) contact. Energizing the discrete input enables the alarm.

**D** Disable to operate as a closed circuit current (NC) contact. De-energizing the discrete input enables the alarm.

Parameter 202

Dig. input	1234
delay	0000

**Discrete input: delay**

**0 to 9**

A delay can be assigned to each alarm input. The delay is entered in the form of delay stages. The individual stages are listed below. The input must be present, without interruption, before the configured time period before the alarm is issued.

Delay [stage]	Delay [time]
0	100 ms
1	200 ms
2	500 ms
3	1 s
4	2 s
5	5 s
6	10 s
7	20 s
8	50 s
9	100 s

Parameter 203

Delayed monitoring	1234 YYYY
--------------------	--------------

**Alarm input: delayed monitoring**

**Y/N**

This screen defines the discrete alarm inputs that are to have the monitoring delayed until engine-firing speed has been achieved.

**Y** .....The discrete input is only monitored after engine-firing speed has been achieved (the green "Monitoring" LED is illuminated).

**N** .....The discrete input is constantly monitored.

Parameter 204

Dig. input	1234
Alarm class	0000

**Discrete input: alarm class**

**0 to 3**

The user may assign the desired alarm class to each discrete alarm input.

The monitoring functions are divided into four alarm classes:

**F0 - Warning alarm** - This alarm does not lead to an interruption of the operation. An alarm message is displayed without a centralized alarm.  
→ Alarm text.

**F1 - Warning alarm** - This alarm does not lead to an interruption of the operation. An alarm message is displayed and a centralized alarm will be output.  
→ Alarm text + flashing LED "Alarm" + Relay "Centralized alarm" (horn).

**F2 - Triggering alarm** - This alarm leads to a soft shutdown. A power reduction is performed prior to the GCB being opened. A cool down period is also carried out.  
→ Alarm text + flashing LED "Alarm" + Relay "Centralized alarm" (horn) + cool down.

**F3 - Triggering alarm** - This alarm leads to the immediate opening of the GCB and a hard shutdown.  
→ Alarm text + flashing LED "Alarm" + Relay "Centralized alarm" (horn) + immediate shutdown.

**Discrete Inputs: Text**

**Example:** Alarm text terminal 62



**NOTE**

It is possible to configure upper and lower case letters, numbers, and characters.

Parameter 205

Errortxt.term.62	Terminal 62
------------------	-------------

**Discrete input: name**

**user defined**

The user may define the text to be displayed when the corresponding discrete input alarm is enabled.



# Analog Inputs



Parameter 206

<b>Configure Analog.inp.    YES</b>
---

## Configure analog inputs

YES/NO

Various groups of parameters are grouped together in blocks to aid in the rapid navigation through the large number of configuration screens. Selecting "YES" or "NO" does not determine if control or monitoring is performed. The user's selection has the following effect:

**YES**..... The configuration screens in this block are displayed and can either be viewed ("Select" push button) or modifications can be made to the parameters ("Cursor→", "Digit↑" or "Select" push buttons). This does not disable or enable individual parameters, only if the individual parameters in this parameter block may be accessed for modifications.

**NO**..... The parameters in this block are not displayed, cannot be modified and are therefore skipped.

## Analog Inputs: Setting

- Analog input 1                    real power set point
- Analog input 2                    power factor set point
- Analog input 3                    0/4 to 20 mA
- Analog inputs 4/5/6/7          Pt100

Fixed assignment of the inputs:

Analog input	1	2	3	4	5	6	7
Type			0/4 to 20 mA	Pt100			
Terminals	93/94/95	96/97/98	99/100/101	102/103/104	105/106/107	108/109/110	111/112/113
Function	Real power set point	Power factor set point	Alarm input				

### Pt100 Input ([T4] to [T7])

The Pt100 temperature input is designed for temperatures up to 240 °C. A name may be assigned to each Pt100 input. Each input is displayed with its name, and can be monitored in two stages. The first stage initiates a class 1 alarm, and the second stage initiates a class 3 alarm.

Parameter 207

Temperature x Pt100	ON
------------------------	----

[x = 4 to 7]

**Analog input, Pt100** **ON/OFF**

**ON** .....The value of this analog input is displayed and monitoring is enabled. The subsequent screens of this function are displayed.  
**OFF** .....Monitoring is not performed. The analog input value and the subsequent screens of this function are not displayed.

Parameter 208

***Name*** -----000°C
--------------------------

**Analog input, Pt100: name** **user defined**

A user-defined name up to 11 characters may be assigned to the analog input. If an alarm condition is detected, the name and temperature threshold value are displayed with an exclamation mark.

Parameter 209

Limit warning	000°C
------------------	-------

**Analog input, Pt100: warning (limit 1)** **0 to 255 °C**

The limit value at which a warning occurs is configured here.

<b>Tripping of class F1 alarm</b>
-----------------------------------

Parameter 210

Limit shutdown	000°C
-------------------	-------

**Analog input, Pt100: shutdown (limit 2)** **0 to 255 °C**

The limit value at which a shutdown occurs is configured here.

<b>Tripping of class F3 alarm</b>
-----------------------------------

Parameter 211

Delay limit 1/2	000s
--------------------	------

**Analog input, Pt100: delay (limit 1 + 2)** **0 to 600 s**

The analog input monitoring threshold limit must be exceeded, without interruption, for the time period configured here before an alarm is issued (this delay time applies to both limit values).

Parameter 212

Monitoring for -----
-------------------------

**Analog input, Pt100: monitoring for** **high limit mon./low limit mon.**

The analog input is monitored in different manners:  
**high limit mon.** .... The value must exceed the configured limit.  
**low limit mon.**..... The value must fall below the configured limit.



#### NOTE

If limit value monitoring is not required, a limit value which is higher than the expected level must be configured in the corresponding screen (e. g. for the ambient temperature: 100 °C).

### Analog Input 0/4 to 20 mA ([T2]-[T3])

0/4 to 20 mA values can be read here. A name and a unit of measurement may be assigned to the input. The analog input is displayed with its name, and can be monitored in two stages. The first stage initiates a class 1 alarm, and the second stage initiates a class 3 alarm.

Parameter 213

Analog input 3 scaleable    ON
-----------------------------------

**Analog input, 0/4 to 20 mA** **ON/OFF**

**ON**..... The value of this analog input is displayed and monitoring is enabled. The subsequent screens of this function are displayed.  
**OFF**..... Monitoring is not performed. The analog input value and the subsequent screens of this function are not displayed.

Parameter 214

Name and unit -----
------------------------

**Analog input, 0/4 to 20 mA: name** **user defined**

A user-defined name may be assigned to the analog input. A maximum of four zeros may be used to reserve places for the numerical measuring values. The placeholders may be divided by characters (e. g. comma). The measured values subsequently appear wherever the zeros are placed.

Parameter 215

Analog input x 0-00mA
--------------------------

[x = 1-7]

**Analog input, 0/4 to 20 mA: measuring range** **0 to 20 mA / 4 to 20mA**

The input range 0 to 20 mA or 4 to 20 mA is selected in this screen. If 4 to 20 mA is selected here and a current of less than 2 mA is measured, this is assessed as a broken wire (Parameter 222).

Parameter 216

Value at 0%            0000
--------------------------------

**Analog input, 0/4 to 20 mA: lower level value** **-9,999 to 9,999**

The scaleable analog input must be assigned a numerical value which corresponds to the lowest input value → Definition of the lower value (0 % equals 0 kW, 0 V etc.) with minimum analog input value (0 mA or 4 mA).

Parameter 217

Value at 100%        0000
------------------------------

**Analog input, 0/4 to 20 mA: upper level value** **-9,999 to 9,999**

The scaleable analog input must be assigned a numerical value which corresponds to the highest input value → Definition of the upper value (100 % equals 500 kW, 400 V etc.) with maximum analog input value (20 mA).

Parameter 218

Limit warning value        0000
------------------------------------

**Analog input, 0/4 to 20 mA: warning (limit 1)** **-9,999 to 9,999**

Threshold limit value at which a warning occurs is configured here.

<b>Tripping of class F1 alarm</b>
-----------------------------------

Parameter 219

Limit shutdown value        0000
-------------------------------------

**Analog input, 0/4 to 20 mA: shutdown (limit 2)** **-9,999 to 9,999**

The limit value that a shutdown occurs is configured here.

<b>Tripping of class F3 alarm</b>
-----------------------------------

Parameter 220

Delay		
Limit 1/2	000s	

**Analog input, 0/4 to 20 mA: delay (limit 1 + 2)** **0 to 600 s**

The analog input monitoring threshold limit must be exceeded, without interruption, for the time period configured here before an alarm is issued (this delay time applies to both limit values).

Parameter 221

Monitoring for	
-----	

**Analog input, 0/4 to 20 mA: monitoring for** **high limit mon./low limit mon.**

The analog input is monitored in different manners:  
**high limit mon.** .... The value must exceed the configured limit.  
**low limit mon.** The value must fall below the configured limit.

**Measuring Range Monitoring**

Parameter 222

Analog in.	--.
------------	-----

**Analog input: measuring range monitoring**

This message appears when positive or negative deviation from the measuring range occurs. The control assesses a fault condition depending on the values specified below.



**NOTE**

The control assesses that a wire break has occurred when the following values are measured for the listed analog input types. When a wire break has been assessed by the control, the threshold limit monitoring for the analog input is deactivated.

**Measuring range monitoring, tripping at**

4 to 20 mA	2 mA	(negative deviation)
Pt100	240 °C	(positive deviation)
Pt1000	150 °C	(positive deviation)
PTC	16 kΩ	(positive deviation)
180 Ω VDO, 0 to 5 bar	193 Ω	(positive deviation)
180 Ω VDO, 0 to 10 bar	193 Ω	(positive deviation)
180 Ω VDO temperature	400 Ω	(positive deviation)

**Delayed Monitoring of the Analog Inputs**

Parameter 223

An. input	1234
Superv.del.	YYYY

**Analog input: delayed monitoring 1 through 4** **Y/N**

The user may enable analog inputs 1 through 4 to be constantly monitored or only monitored when the engine is running ("firing speed reached").  
**Y** .....Monitoring of the analog input is delayed by the time configured in Parameter 239 (green "Monitoring" LED is illuminated).  
**N** .....The analog input is always monitored.

Parameter 224

An. input	5678
Superv.del.	NNNN

**Analog input: delayed monitoring 5 to 8** **Y/N**

The user may enable analog inputs 5 through 8 to be constantly monitored or only monitored when the engine is running ("firing speed reached").  
**Y** .....Monitoring of the analog input is delayed by the time configured in Parameter 239 (green "Monitoring" LED is illuminated).  
**N** .....The analog input is always monitored.

# Outputs



Parameter 225

<b>Configure Outputs</b>	<b>YES</b>
--------------------------	------------

### Configure outputs

YES/NO

Various groups of parameters are grouped together in blocks to aid in the rapid navigation through the large number of configuration screens. Selecting "YES" or "NO" does not determine if control or monitoring is performed. The user's selection has the following effect:

**YES**..... The configuration screens in this block are displayed and can either be viewed ("Select" push button) or modifications can be made to the parameters ("Cursor→", "Digit↑" or "Select" push buttons). This does not disable or enable individual parameters, only if the individual parameters in this parameter block may be accessed for modifications.

**NO**..... The parameters in this block are not displayed, cannot be modified and are therefore skipped.

## Analog Outputs

The analog output manager can be used to apply specific measurement variables to the available analog outputs. The outputs may be configured as 0 to 20 mA or as 4 to 20 mA. A list of the parameters, which may be configured, is located in Appendix D. Each parameter is assigned a unique number. The parameter may be scaled via an upper and a lower input value. The analog outputs may also be assigned an engineering unit of measure (refer to "Analog output manager" in Appendix D).



### NOTE

The list of values and setting limits for the analog output manager is contained in chapter "Analog Output Manager" starting on page 141.

**Possible outputs:** 130/131 and 132/133

**Example:** Analog output 130/131

Parameter 226

<b>Analg.out.130131</b>	
<b>parameter</b>	<b>00</b>

### Analog outputs: parameter

0 to 23

The number of the desired measurement variable output is entered here. A list of all parameters available for configuration, along with the output and limit value ranges, is located in Appendix D.

Parameter 227

<b>Analg.out.130131</b>	
<b>0-00mA</b>	

### Analog outputs: range

OFF / 0 to 20 / 4 to 20 mA

The output is enabled or disabled and the type of output (0 to 20 mA or 4 to 20 mA) may be selected.

Parameter 228

<b>Analg.out.130131</b>	
<b>0%</b>	<b>0000</b>

### Analog output: scaling of the lower level

0 to 9,990

The 0 % value for the monitored range is set here: refer to Appendix D.

Parameter 229

<b>Analg.out.130131</b>	
<b>100%</b>	<b>0000</b>

### Analog output: scaling of the upper level

0 to 9,990

The 100 % value for the monitored range is set here: refer to Appendix D.

## Relay Manager

The relay manager enables the user to assign combinations of functions to each relay of terminals 37/38, 47/48, and 74-83. In order to achieve this, each possible function has its own number. A text, which describes a logical condition for this relay's picking up, must now be entered in the configuration menu for each relay. Up to three numbers may be involved in this link. The length of the text must not exceed 16 characters. The unit detects incorrect function numbers or incorrect formula constructions, and does not accept these. The user must enter the logical combination to be performed.



### NOTE

The list of function numbers for the relay manager is located in Appendix E "Relay Manager" starting on page 126.

### Description of the programming

Permissible text and their meaning include:

- + OR operator (logical function)
- ★ AND operator (logical function)
- NOT operator (logical function)
- 1, 2, 3, ... Function numbers
- + / ★ the following applies: "★" before "+"

Example of logical conditions and relevant texts

Requested function Relay energizes if ...	Programming
... function 22 is enabled.	22
... function 22 is not enabled.	- 22
... function 2 and function 27 are enabled.	2 ★ 27
... function 2 or function 27 is enabled.	2 + 27
... function 5 is not or function 3 or function 13 are enabled.	3 + -5 + 13
... functions 4 or 7 or 11 are enabled.	4 + 7 + 11
... function 4 is not and function 7 is not and function 11 is not enabled.	- 4 ★ -7 ★ -11
... functions 4 and 7 and 11 are enabled.	4 ★ 7 ★ 11
... functions 7 and 11 are enabled simultaneously or function 4 is enabled.	4 + 7 ★ 11
... function 4 is not or function 7 is not or function 11 is not enabled.	-4 + -7 + -11



### NOTE

If the user programs an illogical function, the entered line is deleted.

### Programming of Relay Outputs

Parameter 230

**Assignm.relay x**  
**3+-8+13**

[x = 1 to 7]

#### Relay manager: programming

#### user defined

Relay x [x = 1 through 7] is enabled if the logical condition in the second line is met.

Example: **3 + -8 + 13** (OR link)

- 3** Alarm class 3 is enabled
- 8** Operating mode MANUAL is not enabled
- 13** Alarm "Generator underspeed" is enabled

## Pulse Outputs



### NOTE

The pulse outputs of the energy counter are not calibrated!

These outputs issue pulses whose frequency is proportional to the measured real power or re-active power. The frequency of the pulses can be adjusted. The length of a pulse is 50 ms to 100 ms. The pulse frequency is adjustable so that the time between pulses does not fall under 100 ms at maximum power.

### Pulse Counter for Real Power

Parameter 231

Pulse output 1 -----
-------------------------

**Output of kWh pulses** **+kWh / -kWh**

**+kWh** ..... The output of pulses occurs for positive real power.  
**-kWh** ..... The output of pulses occurs for negative real power.

Parameter 232

Pulse output 1 logic -----
-------------------------------

**Output of the kWh pulse** **positive/negative**

**positive** ..... The output of the kWh pulses (both positive/negative) occur with positive logic (per kWh pulse the Open Collector output will be opened).  
**negative** ..... The output of the kWh pulses (both positive/negative) occur with negative logic (per kWh pulse the Open Collector output will be closed).

Parameter 233

Active energy Pulse/kWh 000.0
----------------------------------

**Pulse per positive kWh** **0.1 to 150.0**

The number of pulses per measured unit to be output is configured here. (Ex.: If 20 kWh have been measured and "Pulse/kWh 020.00" has been configured, a total of 20 kWh × 20 pulses/kWh = 400 pulses have been output. The evaluation of the pulses must be performed externally.)

### Pulse Counter Re-active Power

Parameter 234

Pulse output 2 -----
-------------------------

**Output of kvarh pulses** **+kvarh / -kvarh**

**+kvarh** ..... The output of pulses occurs for inductive re-active power.  
**-kvarh** ..... The output of pulses occurs for capacitive re-active power.

Parameter 235

Pulse output 2 logic -----
-------------------------------

**Output of the kvarh pulse** **positive/negative**

**positive** ..... The output of the kvarh pulses (both positive/negative) occur with positive logic (per kvarh pulse the Open Collector output will be opened).  
**negative** ..... The output of the kvarh pulses (both positive/negative) occur with negative logic (per kvarh pulse the Open Collector output will be closed).

Parameter 236

Reactive energy Pulse/kvah 000.0
-------------------------------------

**Pulse per kvarh** **0.1-150.0**

The number of pulses per measured unit to be output is configured here. (Ex.: If 20 kvarh, inductive have been measured and "Pulse/kvah 020.00" has been configured, a total of 20 kvarh inductive × 20 pulses/kvarh = 400 pulses have been output. The evaluation of the pulses must be performed externally.)

# Drive



Parameter 237

<b>Configure Drive</b>	<b>YES</b>
------------------------	------------

## Configure drive

**YES/NO**

Various groups of parameters are grouped together in blocks to aid in the rapid navigation through the large number of configuration screens. Selecting "YES" or "NO" does not determine if control or monitoring is performed. The user's selection has the following effect:

**YES** .....The configuration screens in this block are displayed and can either be viewed ("Select" push button) or modifications can be made to the parameters ("Cursor→", "Digit↑" or "Select" push buttons). This does not disable or enable individual parameters, only if the individual parameters in this parameter block may be accessed for modifications.

**NO** .....The parameters in this block are not displayed, cannot be modified and are therefore skipped.

Parameter 238

<b>Automatic idle running</b>	<b>ON</b>
-------------------------------	-----------

## Automatic idle control

**ON/OFF**

The automatic idle control may be enabled in this screen.

**ON** .....The automatic idle control is enabled. The controller adjust the machine to the configured voltage and frequency.

**OFF** .....The automatic idle control is disabled.



## Delayed Monitoring and Ignition Speed

Parameter 239

**Monitoring on  
after 00s**

### Delayed monitoring

0 to 99 s

Any parameters configured for delayed monitoring (e.g. oil pressure, generator underfrequency, etc.) will not be assessed until the expiration of the time configured here. This timer starts when the control unit detects that the engine has reached firing speed.

Parameter 240

**Monitoring on  
at f gen > 00Hz**

### Ignition speed

15 to 70 Hz

The user configures the point that the engine firing speed has been reached. Once the controller detects this, the frequency controller assumes speed control.

**Note:** Measurement is only possible above 15 Hz, even if 5 Hz are displayed.




Figure 6-6: Ignition speed - delayed monitoring

### Shutdown (Unload and Open GCB)



**NOTE**

Please note chapter "Breaker Logic" (starting page 88) for description of the breaker logics.

Parameter 241

Download and open GCB	ON
--------------------------	----

<b>Shutdown</b>	<b>ON/OFF</b>
-----------------	---------------

- ON** ..... The GCB is opened (following power reduction), if terminal 3 is de-energized.
- OFF** ..... The GCB remains closed, and the controller set points are maintained.

# Counter



Parameter 242

<b>Configure Counters</b>	<b>YES</b>
---------------------------	------------

## Configure counters

YES/NO

Various groups of parameters are grouped together in blocks to aid in the rapid navigation through the large number of configuration screens. Selecting "YES" or "NO" does not determine if control or monitoring is performed. The user's selection has the following effect:

**YES**..... The configuration screens in this block are displayed and can either be viewed ("Select" push button) or modifications can be made to the parameters ("Cursor→", "Digit↑" or "Select" push buttons). This does not disable or enable individual parameters, only if the individual parameters in this parameter block may be accessed for modifications.

**NO**..... The parameters in this block are not displayed, cannot be modified and are therefore skipped.

## Maintenance Call

Parameter 243

<b>Service interval</b>	<b>ON</b>
-------------------------	-----------

## Maintenance call

ON/OFF

**ON**..... Maintenance call counter is enabled and an alarm message will be displayed when the counter expires. Refer to Parameter 244 for a description of the maintenance call function.

**OFF**..... The maintenance call counter is disabled.

Parameter 244

<b>Service interval in</b>	<b>0000h</b>
----------------------------	--------------

## Maintenance call: sequence

0 to 9.999 h

A maintenance interval can be specified in this screen. After the engine has been in operation for the number of hours configured here, a maintenance call message (class F1 alarm) is displayed. Following the acknowledgement of the message, the counter is reset to this value.



### NOTE

If maintenance has been performed prior to the counter expiring, it is possible to reset the maintenance counter to the configured value. The unit must be in code level 1 or 2 in order to achieve this. The counter is reset in a 2-step procedure for safety reasons. The following procedure applies:

**1. Step:** Configure the desired number of hours for the maintenance call.

**2. Step:** Integration of the value which has been saved:

1. Exit the configuration mode and switch the controller into **AUTOMATIC** mode
2. Navigate to the display screen "Service interval in 000h" using the "Select" button
3. Press and hold the "Digit" push button for 7 seconds

### Operating Hours Counter

Parameter 245

Op.hours counter
ON

Operating hours counter ON/OFF

ON .....Operating hours counter is enabled. Refer to Parameter 246 for a description.

OFF .....The counter is not enabled.



#### NOTE

The operating hours counter can be set to a maximum value of 65,000 hours.

Parameter 246

Op.hours counter
set            00000h

Operating hours counter: value 0 to 65,000 h

This parameter can be used to specify the number of hours an engine has been in operation. This permits the user to display the correct number of engine hours if this controller is used on an older engine or this controller is to replace an older controller.



#### NOTE

If the control unit operating hours must be configured to a specific value, the unit must be in code level 2 in order to achieve this. The counter is reset in a 2-step procedure for safety reasons. The following procedure applies:

- 1. Step:** Configure and store the desired operating hours.
- 2. Step:** Integration of the value which has been saved:
  - 1. Exit the configuration mode and switch the controller into AUTOMATIC mode
  - 2. Navigate to the display screen "Op.hours 000h" using the "Select" button
  - 3. Press and hold the "Digit" push button for 7 seconds

## Start Counter

Parameter 247

Start counter	ON
---------------	----

**Start counter**

**ON/OFF**

**ON**..... Start counter is enabled. Refer to Parameter 248 for a description.  
**OFF**..... The counter is not enabled.



### NOTE

**After 32,000 starts, the counter is automatically reset.**

Parameter 248

Start counter	
set	00000

**Start counter: value**

**0 to 32,000**

The start counter is used to display how many times the engine has been started. Following each starting attempt the start counter is increased by one. This permits the user to display the correct number of starts if this controller is used on an older engine, a starter is replaced, or this controller is to replace an older controller.

Only maintenance personnel should configure the start counter!



### NOTE

**If the control unit number of starts must be configured to a specific value, the unit must be in code level 2 in order to achieve this. The counter is reset in a 2-step procedure for safety reasons. The following procedure applies:**

- 1. Step:** Configure and store the desired number of starts.
- 2. Step:** Integration of the value which has been saved:
  1. Exit the configuration mode and switch the controller into **AUTOMATIC** mode
  2. Navigate to the display screen "start counter 00000" using the "Select" button
  3. Press and hold the "Digit" push button for 7 seconds

## kWh/kvarh Counter

Parameter 249

Display kWh	+-
on?	YY

**Display kWh counter**

**Y/N**

It is possible to display the positive kWh counter (+) and/or the negative kWh counter (-) by selecting "Y" or "N". It is possible to display no counters, one counter or both counters by making the appropriate entry.  
**Y**..... The selected kWh counter is visible.  
**N**..... The selected kWh counter is not visible.

Parameter 250

Display kvarh	+-
on?	YY

**Display kvarh counter**

**Y/N**

It is possible to display the inductive kvarh counter (+) and/or the capacitive kvarh counter (-) by selecting "Y" or "N". It is possible to display no counters, one counter or both counters by making the appropriate entry.  
**Y**..... The selected kvarh counter is visible.  
**N**..... The selected kvarh counter is not visible.

## Resetting the Counters

Resetting the counters (start counter, operating hours counter, kWh counter, kvarh counter) must be performed in code level 2.

To reset the individual counters, the control unit must be in the AUTOMATIC mode. Navigate to the display screen that is to be reset or changed. Press and hold the "Digit" button for at least 7 seconds.

For the start counter and the operating hours counter, the values that have been configured in the parameters "Start counter set" or "Op.hours counter set" will be integrated into the display.

## Real Time Clock

Parameter 251

<b>Time</b>	00:00
-------------	-------

**Time** user defined

The hours and minutes of the internal clock are configured.

Hour	
00	Beginning hour of the day
01	1 <sup>st</sup> hour of the day
...	...
23	23 <sup>rd</sup> hour of the day
Minute	
00	Beginning minute of the hour
01	1 <sup>st</sup> minute of the hour
...	...
59	59 <sup>th</sup> minute of the hour

Parameter 252

<b>Year, month</b>	00,00
--------------------	-------

**Date** user defined

The year and date of the internal clock are configured.

Year	
99	Year 1999
00	Year 2000
01	Year 2001
...	...
Month	
01	Month January
02	Month February
...	...
12	Month December

Parameter 253

<b>Day, weekday</b>	00/0
---------------------	------

**Day and weekday** user defined

The day and weekday of the internal clock are configured.

Day	
01	1 <sup>st</sup> day of the month
02	2 <sup>nd</sup> day of the month
...	...
31	31 <sup>st</sup> day of the month, if available
Weekday	
1	Monday
2	Tuesday
...	...
7	Sunday

## Current Slave Pointer

A current slave pointer, which records and stores the maximum generator current, is implemented in the unit. The display of the maximum generator current can be selected in **Automatic** mode via the "Message" push button. The following screen appears in the display:

000 000 000 000
max. Gen. current

**Current slave pointer**

The maximum generator current in the three phases is displayed and stored in this screen.

**Resetting:** Pressing and holding the "ACK" pushbutton for 3 seconds while the current slave pointer screen is displayed, will reset the display screen.

# Chapter 7. Commissioning



## **DANGER - HIGH VOLTAGE**

When commissioning the control, please observe all safety rules that apply to the handling of live equipment. Ensure that you know how to provide first aid in the event of an uncontrolled release of energy and that you know where the first aid kit and the nearest telephone are. Never touch any live components of the system or the back of the system:

**LIFE THREATENING**



## **CAUTION**

Only a qualified technician may commission unit. The "EMERGENCY-STOP" function must be operational prior to commissioning of the system and must not depend on the unit for its operation.



## **CAUTION**

Prior to commissioning ensure that all measuring devices are connected in correct phase sequence. The connect command for the unit circuit breaker must be disconnected at the unit circuit breaker. The rotating field must be monitored for proper rotation. Any absence of or incorrect connection of voltage measuring devices or other signals may lead to malfunctions and damage the unit, the engine, and/or components connected to the unit!



## **CAUTION**

Please consider that the unit does not have an internal rotating field monitoring.

The unit assumes always a clockwise phase rotation direction of all three voltage systems, which are measured.

A rotating field monitoring must be provided by the customer in order to avoid a CB closure with a counter-clockwise rotating field.

### **Procedure**

1. After checking to ensure that all measuring voltages have been connected to the correct phases, the power supply (12/24 Vdc) may be connected.
2. By simultaneously pressing the two push buttons "Digit↑" and "Cursor→", the configuration mode is accessed. After entering the access code number, the unit may be configured according to the application requirements (refer to the Configuration section).
3. After the control unit has been configured, the unit will display the measured system values. These values should be confirmed with a calibrated measuring instrument.
4. The initial operation should be performed in the **MANUAL operation mode** (press the "MANUAL" push button). All measured generator values must be verified. Any alarm messages should be investigated to determine the cause.

5. Operating mode **AUTOMATIC** (press the push button "AUTO"): A synchronization can now be carried out for the GCB by energizing the "Enable GCB" discrete input.

**Check-out of the synchronization:** Disconnect the connect pulse "Command: close GCB". Check the generator and the generator busbar phase rotation. Check the connect command with a zero voltmeter (determination of the phase angle) at the GCB. If several pulses have been output at the correct synchronous point, switch the operating mode to MANUAL and reconnect the connect pulse "Command: close GCB".

6. If steps 1 through 5 have been carried out successfully, mains parallel operations may commence. It is recommended to start with a constant power/base load operation (approx. 25 % of the generator rated power). While this operation is being performed, the displayed measuring values must be verified. Test the GCB shutdown for proper operation. Check the real power controller and, if necessary, the power factor controller. Enter various set point values and verify proper operation.
7. If mains parallel operation performs in a satisfactory manner, the synchronization of the MCB must be checked:

A power failure in the system must be simulated or monitored by the control Unit. During mains parallel operation, change the operating mode from AUTOMATIC to MANUAL. Open the MCB ("MCB ON" LED will turn off). Press the AUTOMATIC pushbutton to return the control unit back to the AUTOMATIC operating mode.

Check the generator busbar and the mains field rotation. Check the connect command with a zero voltmeter (determination of the phase angle) at the MCB. If several pulses have been output at the correct synchronous point, switch the operating mode to MANUAL and reconnect the connect pulse "Command: close MCB".







## NOTE

The automatic operation mode is influenced by the input signals "Automatic 1" and "Automatic 2". Ensure that the power circuit breaker reply messages are processed as the opposite of the condition (i.e. when the power circuit breaker is closed the reply message for the inputs: CB is open (terminal 54) is 0 volts. The CB auxiliary contact should be configured as normally closed contacts (NC)! Refer to the description of the alarm and control inputs starting on page 22 of this manual). It is vital that these replies be connected!

Electrical isolation between voltage supply and discrete control and feedback inputs: By the use of corresponding external wiring, the common reference point of the discrete inputs can be electrically isolated from the power supply voltage (0 V, terminal 2). This is necessary if the discrete inputs are not to be enabled with 24 Vdc and an electrical isolation of the control voltage (e. g. 220 Vdc, 220 Vac) from the supply voltage must be ensured.



# Appendix A. Dimensions



2002-11-21 | MFR 3 Dimensions r3ww-4702-ab.skf

Figure 7-1: Dimensions

# Appendix B. Technical Data

<b>Measuring voltage</b> -----	
- Measuring voltage	Rated value ( $V_{rated}$ ) $\sphericalangle/\Delta$ ..... [1] 66/115 Vac [4] 230/400 Vac
	Maximum value $V_{ph-ph}$ (UL/cUL) [1] max. 150 Vac [4] max. 300 Vac
	Rated voltage $V_{ph-ground}$ [1] 150 Vac [4] 300 Vac
	Rated surge voltage [1] 2.5 kV [4] 4.0 kV
- Measuring frequency .....	40.0 to 70.0 Hz
- Accuracy .....	Class 1
- Linear measuring range up to.....	$1.3 \times V_{rated}$
- Input resistance .....	[1] 0.21 M $\Omega$ [4] 0.7 M $\Omega$
- Maximum power consumption per path .....	0.15 W
<b>Measuring current</b> ----- <b>isolated</b>	
- Measuring current .....	[5] $\cdot/5$ A
- Accuracy .....	Class 1
- Maximum continuous current .....	$I_{Gen} = 3.0 \times I_{rated}$ , $I_{Mains} = 1.5 \times I_{rated}$
- Power consumption.....	< 0.15 W
- Rated short to time current (1 s).....	[5] $10.0 \times I_{rated}$
<b>Ambient variables</b> -----	
- Power supply.....	12/24 Vdc (9.5 to 32 Vdc)
- Intrinsic consumption.....	max. 15W
- Ambient temperature.....	-20 to 70 °C
- Ambient humidity .....	95 %, not condensing
<b>Discrete inputs</b> ----- <b>isolated</b>	
- Input range ( $V_{Cont, digital input}$ ).....	Rated voltage 18 to 250 Vac/dc
- Input resistance .....	approx. 68 k $\Omega$
<b>Relay outputs</b> ----- <b>potential free</b>	
- Contact material .....	AgCdO
- General purpose (GP) ( $V_{Cont, relay output}$ )	AC ..... 2.00 Aac@250 Vac DC ..... 2.00 Adc@24 Vdc 0.36 Adc@125 Vdc 0.18 Adc@250 Vdc
- Pilot duty (PD) ( $V_{Cont, relay output}$ )	AC ..... B300 DC ..... 1.00 Adc@24 Vdc 0.22 Adc@125 Vdc 0.10 Adc@250 Vdc
<b>Pulse outputs</b> -----	
- Type .....	transistor output
- Rated gate voltage.....	24 Vdc
- Maximum gate voltage.....	32 Vdc
- Minimum gate current.....	10 mAdc
- Maximum gate current.....	30 mAdc (0.5 Vdc)

**Analog inputs ----- freely scaleable**

- Resolution..... 10 Bit
- Pt100/Pt1000 input ..... for measuring resistance according to IEC 751  
 [Pt100] 2/3 wire measuring, 0 to 200 °C  
 [Pt1000] 2 wire measuring, -30 to 200 °C
- 0/4 to 20 mA input..... Differential measuring, load 150 Ω
- 0 to 5/10 V input..... Differential measuring, input resistance approx. 16.5 kΩ
- 0 to 180/380 Ω input..... Differential measuring, sensor current ≤1.9 mA

**Analog outputs ----- isolated**

- At rated value ..... freely scaleable
- Insulation voltage ..... 3,000 Vdc
- Versions..... 0 to 5 Vdc, ±5 Vdc, 0 to 10 Vdc, 0 to 20 mA
- Resolution PWM ..... 8/12 Bit (depending on model)
- 0/4 to 20 mA output..... Maximum load 500 Ω
- 0 to 10 V/±5 V output..... Internal resistance ≤ 1 kΩ

**Interface ----- isolated**

- Insulation voltage ..... 3,000 Vdc
- Version ..... variable

**Housing -----**

- Type..... APRANORM DIN 43 700
- Dimensions (W× H × D) ..... 144 × 144 × 118 mm
- Front cutout (W×H)..... 138 [+1.0] × 136 [+1.0] mm
- Wiring..... Screw to type terminals  
 1.5 mm<sup>2</sup> or 2.5 mm<sup>2</sup> (depending on plug connector)  
 use 60/75 °C copper wire only  
 use class 1 wire only or equivalent
- Weight ..... approx. 1,000 g

**Protection-----**

- Protection system..... IP 42 from front with proper installation  
 IP54 from front with gasket (gasket: P/N 8923-1039)  
 IP21 from back
- Front foil..... insulating surface
- EMC test (CE) ..... tested according to applicable EN guidelines
- Listings ..... CE marking; UL listing for ordinary locations  
 UL/cUL listed, Ordinary Locations, File No.: E231544

## Appendix C. Measured Quantities and Accuracy

Measuring value	Display/range	Accuracy	Note
<b>Frequency</b>			
Generator, busbar $f_{L1gen/bus}$ , $f_{L2gen/bus}$ , $f_{L3gen}$	15.0 to 85.0 Hz		
Mains $f_{L1mains}$ , $f_{L2mains}$ , $f_{L3mains}$	40.0 to 85.0 Hz		
<b>Voltage</b>			
$V_{L1}$ , $V_{L2}$ , $V_{L3}$ , $V_{L12}$ , $V_{L23}$ , $V_{L31}$	0 to 520 V	1 %	Transformer ratio adjustable
<b>Current</b>			
Generator, mains $I_{L1gen/mains}$ , $I_{L2gen}$ , $I_{L3gen}$	0 to 9,999 A	1 %	-
Maximum value $I_{L1gen}$ , $I_{L2gen}$ , $I_{L3gen}$	0 to 9,999 A	1 %	Current slave pointer
<b>Real power</b>			
Total real actual power	-32.0 to 32.0 MW	2 %	-
<b>Re to active power</b>			
Actual value in L1, L2, L3	-32.0 to 32.0 Mvar	2 %	-
<b>Power factor cos <math>\phi</math></b>			
Actual power factor $I_{L1gen/mains}$ value	i0.00 to 1.00 to c0.00		-
<b>Miscellaneous</b>			
Real energy	0 to 4,200 GWh		not calibrated by PTB
Running hours	0 to 65,000 h		-
Maintenance call	0 to 9,999 h		-
Start counter	0 to 32,750 → 1		-
Battery voltage	10 to 30 V		-
<b>Analog inputs</b>			
Pt100	0 to 250 °C		not calibrated by PTB
0/4 to 20 mA	freely scaleable		-
0 to 10 V	freely scaleable		-
0 to 150 mV	freely scaleable		-

**Reference conditions:** The data apply to the following reference conditions:

- Input voltage = sinusoidal rated voltage
- Input current = sinusoidal rated current
- Frequency = rated frequency  $\pm 2 \%$
- Power supply = rated voltage  $\pm 2 \%$
- Power factor = 1
- Ambient temperature  $23 \text{ °C} \pm 2 \text{ K}$
- Warm to up period = 20 minutes.

# Appendix D. Analog Output Manager



**NOTE**

The parameters listed below can only be output correctly if the existing version of the unit permits this.

Parameter	Output	Value	Range of the two limit values
0	The analog output is inactive.	---	---
1	Generator real power <sup>1)</sup>	[dimensionless]	0% lower power value (can also be negative) e. g. -0050 kW 100% upper power value (can also be negative) e. g. 0200 kW
2	Generator power factor [e. g. (-070 to +080) /100] (find definition at the end of this table)	[dimensionless]	0% lower difference to power factor = 1 e. g. -0030 corresponds to c0.70 100% upper difference to power factor = 1 e. g. 0030 corresponds to i0.70
3	Generator frequency	[Hz*100]	0% lower frequency e. g. 0000 corresponds to 00.00 Hz. 100% upper frequency e. g. 7000 corresponds to 70.00 Hz.
4	Generator re-active power	[kvar]	0% capacitive re-active power (negative) e. g. -0100 kvar 100% inductive re-active power (positive) e. g. +0100 kvar
5	Rated power of all generators connected to generator busbar minus nominal actual power	[kW]	0% lower power value (can also be negative) e. g. -0050 kW 100% upper power value (can also be negative) e. g. 0200 kW
6	Total actual power of all generators connected to generator busbar	[kW]	
7	Generator apparent power in L1	[A]	0% lower current output e. g. 0000 A 100% upper current output e. g. 500 A
8	Generator apparent power in L2	[A]	
9	Generator apparent power in L3	[A]	
10	Speed via Pickup (terminal 91, 92, 93)	[rpm]	0% lower speed e. g. 0000 rpm 100% upper speed e. g. 3000 rpm

Parameter	Output	Value	Range of the two limit values
11	Analog input [T1]	[°C] or [°F] or freely scaleable	0% lower value e. g. 0000 corresponds to 000 °C at temperature input 100% upper value e. g. 0255 corresponds to 255 °C at temperature input  0% lower value e. g. 0000 corresponds to 00.0 bar oil pressure 100% upper value e. g. 0100 corresponds to 10.0 bar oil pressure
12	Analog input [T2]	[°C] or [°F] or freely scaleable	
13	Analog input [T3]	[°C] or [°F] or freely scaleable	
14	Analog input [T4]	[°C] or [°F] or freely scaleable	
15	Analog input [T5]	[°C] or [°F] or freely scaleable	
16	Analog input [T6]	[°C] or [°F] or freely scaleable	
17	Analog input [T7]	[°C] or [°F] or freely scaleable	
18	additional freely scaleable analog input (terminal 91, 92)		
19	Mains real power	[kW]	0% lower value e. g. -0800 kW 100% upper value e. g. 0800 kW
20	Mains apparent power in L1	[A]	0% lower current value e. g. 0000 A 100% upper current value e. g. 500 A
21	Mains power factor [e. g. (-070 to +080) /100] (find definition at the end of this table)	[dimensionless]	0% lower difference to power factor = 1 e. g. -0030 corresponds to c0.70 100% upper difference to power factor = 1 e. g. 0030 corresponds to i0.70
22	Mains re-active power	[kvar]	0% capacitive re-active power (negative) e. g. -0100 kvar 100% inductive re-active power (positive) e. g. +0100 kvar

<sup>1)</sup>**Note to parameter 1 and 2:** The analog output is calculated according to the displayed real power without the engineering unit of measure "kW" or "MW". The number of displayed digits is valid. Example: 20 mA corresponds to "200".

20 mA will be output at the following display: 200 kW or 20.0 MW

10 mA will be output at the following display: 100 kW or 10.0 MW

The control unit automatically switches from "kW" to "MW" when the primary transformer real power of 3,000 kW is exceeded:  $I_{gen\ prim} \times V_{gen\ prim} \times \sqrt{3} \geq 3,000\ kW$ .

The description 0 % corresponds to the minimum input of 4 mA or 0 mA; the description 100 % corresponds to the maximum input of 20 mA. The values can be entered with or without a leading sign (see parameter 1).

**Definition of power factor scaling:** According to the scaling of the analog output, the power factor can be output within the range from capacitive values ranging from c0.00 to unity power factor = 1 to inductive values up to i0.00.




Figure 7-2: analog outputs – power factor scaling

# Appendix E. Relay Manager

No.	Output
1	Class F1 alarm
2	Class F2 alarm
3	Class F3 alarm
4	Class F1, F2 or F3 centralized alarm
5	Class F2 or F3 centralized alarm
6	Ignition speed reached
7	Generator voltage within 88 to 112 % of the rated voltage
8	Busbar voltage within 88 to 112 % of the rated voltage
9	Mains voltage within 88 to 112 % of the rated voltage
10	AUTOMATIC operating mode
11	MANUAL operating mode
12	Mains overfrequency
13	Mains underfrequency
14	Mains overvoltage
15	Mains undervoltage
16	Mains phase/vector jump
17	Mains df/dt failure
18	Generator underfrequency 1
19	Generator overfrequency 1
20	Generator overspeed
21	Plausibility check: Generator frequency
22	Generator undervoltage 1
23	Generator overvoltage 1
24	Generator time-overcurrent 1
25	Generator time-overcurrent 2
26	Generator load imbalance
27	Generator overload 1
28	Generator reverse/reduced power
29	Time limit exceeded: Synchronization GCB
30	Generator re-active power, capacitive
33	Generator re-active power, inductive
32	Ground failure
33	Battery undervoltage
34	Interface failure terminals X1 to X5
35	Analog input [T1], terminals 93 - 95, level 1
36	Analog input [T1], terminals 93 - 95, level 2
37	Analog input [T2], terminals 96 - 98, level 1
38	Analog input [T2], terminals 96 - 98, level 2
39	Analog input [T3], terminals 99 - 101, level 1
40	Analog input [T3], terminals 99 - 101, level 2
41	Analog input [T4], terminals 102 - 104, level 1
42	Analog input [T4], terminals 102 - 104, level 2
43	Analog input [T5], terminals 105 - 107, level 1
44	Analog input [T5], terminals 105 - 107, level 2
45	Analog input [T6], terminals 108 - 110, level 1
46	Analog input [T6], terminals 108 - 110, level 2
47	Analog input [T7], terminals 111 - 113, level 1
48	Analog input [T7], terminals 111 - 113, level 2
49	Analog input, terminals 91 - 92, level 1
50	Analog input, terminals 91 - 92, level 2
51	Discrete input, terminal 34
52	Discrete input, terminal 35
53	Discrete input, terminal 36
54	Discrete input, terminal 37
55	Discrete input [D01], terminal 62
56	Discrete input [D02], terminal 63
57	Discrete input [D03], terminal 64
58	Discrete input [D04], terminal 65



No.	Output
59	Discrete input [D05], terminal 66
60	Discrete input [D06], terminal 67
61	Discrete input [D07], terminal 68
62	Discrete input [D08], terminal 69
63	Discrete input [D09], terminal 70
64	Discrete input [D10], terminal 71
65	Discrete input [D11], terminal 72
66	Discrete input [D12], terminal 73
67	Reply: MCB is closed
68	Reply: GCB is closed
69	Mains parallel operation is desired
70	Power monitoring
71	Mains failure: mains voltage, mains frequency or mains phase/vector shift have been tripped
72	Dependent time-overcurrent
73	Class F1 alarm acknowledged
74	Class F2 or F3 alarm acknowledged
75	Generator undervoltage 2
76	Generator overvoltage 2
77	Generator underfrequency 2
78	Generator overfrequency 2
79	Internal
80	Generator overload 2
81	Interface failure terminals Y1 to Y5
82	Load shedding introduced: closing/synchronization GCB has happen or breaker is closed
83	Closing/synchronization MCB has happen or breaker is closed
84	Power monitoring mains incoming
85	Maintenance call
86	Time limit exceeded: Synchronization MCB
87	Synchronization MCB is happening
88	Lamp test activated
89	Malfunction "Reply: GCB is open" - failure during closing
90	Malfunction "Reply: MCB is open" - failure during closing
91	Malfunction "Reply: GCB is open" - failure during opening
92	Malfunction "Reply: MCB is open" - failure during opening
93	Mains interchange power $\leq 0$
94	Closing time at dead bus start exceeded
95	Internal
96	Engine release
97	Push button "ACK" pressed
98	Class F1, F2 or F3 centralized alarm (pre-assigned to relay [8])
99	Three-position controller: raise n/f/P (external RC wiring required !!!)
100	Three-position controller: lower n/f/P (external RC wiring required !!!)
101	Three-position controller: raise V/Q (external RC wiring required !!!)
102	Three-position controller: lower V/Q (external RC wiring required !!!)
103	Engine running ( $f > 15\text{Hz}$ )
104	Internal
105	Rotation field generator/mains mismatch
106	Left rotation field mains
107	Right rotation field mains
108	Left rotation field generator
109	Right rotation field generator
110	Open GCB
111	Wire break analog input 1
112	Wire break analog input 2
113	Wire break analog input 3
114	Wire break analog input 4
115	Wire break analog input 5
116	Wire break analog input 6
117	Wire break analog input 7



**NOTE**

Rotation field monitoring (relay manager no. 105 through 109) is only active within the synchronization limits (refer to Synchronization on page 91).

# Appendix F. Interface Telegram

## Transmission Telegram



MUX	No.	Content (words)	Unit	Comment
0/1	1	Protocol number		"1300"
0/2	2	Generator frequency f	Hz / 100	
0/3	3	Actual generator real power P	$W \times 10^{P_{genEXPO}}$	
1/1	4	Exponents		High Byte: PgenEXPO Generator power Low Byte: VgenEXPO Generator voltage
1/2	5	Generator real power setpoint value	see on the right	$W \times \frac{PGNWD}{2.800} \times 10^{PGNEXPO}$
1/3	6	Conversion factor steps → kW		PgenWD (intern)
2/1	7	Busbar voltage delta V <sub>12</sub>	$V \times 10^{V_{busEXPO}}$	
2/2	8	Mains voltage delta V <sub>12</sub>	$V \times 10^{V_{mainsEXPO}}$	
2/3	9	Active alarm class		Bit 15 = 1 --Internal-- Bit 14 = 1 --Internal-- Bit 13 = 1 --Internal-- Bit 12 = 1 --Internal-- Bit 11 = 1 --Internal-- Bit 10 = 1 --Internal-- Bit 9 = 1 --Internal-- Bit 8 = 1 --Internal-- Bit 7 = 1 \ \ / Bit 6 = 1 / \ / Class F3 alarm Bit 5 = 1 \ \ / Bit 4 = 1 / \ / Class F2 alarm Bit 3 = 1 \ \ / Bit 2 = 1 / \ / Class F1 alarm Bit 1 = 1 \ \ / Bit 0 = 1 / \ / Class F0 alarm If both bits are set for double bits, the input is activated.
3/1	10	Control register 2		Bit 15 = 1 \ \ / Bit 14 = 1 / \ / Terminal 4, reply: GCB is closed Bit 13 = 1 \ \ / Bit 12 = 1 / \ / Terminal 54, reply: MCB is closed Bit 11 = 1 \ \ / Terminal 3 Bit 10 = 1 / \ / DI "Release GCB" Bit 9 = 1 \ \ / Terminal 53 Bit 8 = 1 / \ / DI "Release MCB" Bit 7 = 1 \ \ / Terminal 5 Bit 6 = 1 / \ / DI "Set point value 1↔2" Bit 5 = 1 \ \ / Bit 4 = 1 / \ / --Internal-- Bit 3 = 1 \ \ / Terminal 6 Bit 2 = 1 / \ / DI "Release monitoring" Bit 1 = 1 \ \ / Bit 0 = 1 / \ / --Internal-- If both bits are set for double bits, the input is activated.
3/2	11	Actual mains interchange (import/export) real power	$W \times 10^{P_{mainsEXPO}}$	
3/3	12	Internal		

MUX	No.	Content (words)	Unit	Comment	
4/1	13	Alarms 8  FS: Control input, not active F0: Class F0 alarm, not active F1: Class F1 alarm, active until acknowledged F2: Class F2 alarm, active until acknowledged F3: Class F3 alarm, active until acknowledged		Bit 15 = 1	F3: Generator overfrequency, level 2
				Bit 14 = 1	F3: Generator underfrequency, level 2
				Bit 13 = 1	F3: Generator overvoltage, level 2
				Bit 12 = 1	F3: Generator undervoltage, level 2
				Bit 11 = 1	F3: Reactive power, inductive
				Bit 10 = 1	F3: Reactive power, capacitive
				Bit 9 = 1	--Internal--
				Bit 8 = 1	--Internal--
				Bit 7 = 1	--Internal--
				Bit 6 = 1	--Internal--
				Bit 5 = 1	--Internal--
				Bit 4 = 1	--Internal--
				Bit 3 = 1	--Internal--
				Bit 2 = 1	--Internal--
				Bit 1 = 1	--Internal--
				Bit 0 = 1	--Internal--
				4/2	14
Bit 14 = 1	--Internal--				
Bit 13 = 1	Dead bus start error, time overrun				
Bit 12 = 1	--Internal--				
Bit 11 = 1	Switch fault "MCB open"				
Bit 10 = 1	Switch fault "GCB open"				
Bit 9 = 1	Synchronization time monitoring MCB				
Bit 8 = 1	Synchronization time monitoring GCB				
Bit 7 = 1	--Internal--				
Bit 6 = 1	--Internal--				
Bit 5 = 1	--Internal--				
Bit 4 = 1	--Internal--				
Bit 3 = 1	--Internal--				
Bit 2 = 1	--Internal--				
Bit 1 = 1	--Internal--				
Bit 0 = 1	Range alarm analog input [T1]				
4/3	15	Generator voltage delta $V_{23}$	$V \times 10^{V_{genEXPO}}$		
5/1	16	Generator voltage delta $V_{31}$	$V \times 10^{V_{genEXPO}}$		
5/2	17	Generator voltage wye $V_{1N}$	$V \times 10^{V_{genEXPO}}$		
5/3	18	Generator voltage wye $V_{2N}$	$V \times 10^{V_{genEXPO}}$		
6/1	19	Generator voltage wye $V_{3N}$	$V \times 10^{V_{genEXPO}}$		
6/2	20	Generator voltage delta $V_{12}$	$V \times 10^{V_{genEXPO}}$		

MUX	No.	Content (words)	Unit	Comment
6/3	21	Internal		
7/1	22	Generator current in L1	$A \times 10^{\text{IgenEXPO}}$	
7/2	23	Generator current in L2	$A \times 10^{\text{IgenEXPO}}$	
7/3	24	Generator current in L3	$A \times 10^{\text{IgenEXPO}}$	
8/1	25	Actual generator reactive power	$\text{var} \times 10^{\text{PgenEXPO}}$	positive = inductive
8/2	26	Generator power factor		Example: FF9EH PF = c 0.98 (capacitive) FF9DH PF = c 0.99 (capacitive) 0064H PF = 1.00 0063H PF = i 0.99 (inductive) 0062H PF = i 0.98 (inductive)
8/3	27	Internal		
9/1	28	Internal		
9/2	29	Number of participants on CAN bus		
9/3	30	H . B . mains status L . B . generator status		FFH Voltage and frequency present 00H Voltage and frequency not present
10/1	31	Exponents		High Byte: IgenEXPO generator current Low Byte: --- free
10/2	32	Busbar frequency	Hz / 100	
10/3	33	H . B . busbar status L . B . internal		FFH Voltage and frequency present 00H Voltage and frequency not present
11/1	34	Mains voltage delta $V_{23}$	$V \times 10^{\text{VmainsEXPO}}$	
11/2	35	Mains voltage delta $V_{31}$	$V \times 10^{\text{VmainsEXPO}}$	
11/3	36	Mains voltage wye $V_{IN}$	$V \times 10^{\text{VmainsEXPO}}$	
12/1	37	Mains voltage wye $V_{2N}$	$V \times 10^{\text{VmainsEXPO}}$	
12/2	38	Mains voltage wye $V_{3N}$	$V \times 10^{\text{VmainsEXPO}}$	
12/3	39	Mains frequency off $V_{N12}/V_{N23}/V_{N31}$	Hz / 100	
13/1	40	Mains current in L1	$A \times 10^{\text{ImainsEXPO}}$	
13/2	41	Mains reactive power	$\text{var} \times 10^{\text{OmainsEXPO}}$	
13/3	42	Mains power factor		Example: FF9EH PF = c 0.98 (capacitive) FF9DH PF = c 0.99 (capacitive) 0064H PF = 1.00 0063H PF = i 0.99 (inductive) 0062H PF = i 0.98 (inductive)
14/1	43	Exponents		High Byte: PmainsEXPO mains power Low Byte: VmainsEXPO mains voltage
14/2	44	Exponents		High Byte: ImainsEXPO mains current Low Byte: VbusEXPO busbar voltage
14/3	45	Engine operating hours ( H . W . )	$h \times 2^{16}$	Double word
15/1	46	Engine operating hours ( L . W . )	h	
15/3	47	Hours until next maintenance	h	
15/3	48	Generator start number		
16/1	49	Internal		

MUX	No.	Content (words)	Unit	Comment
16/2	50	Generator active energy ( H . W . )	kWh × 2 <sup>16</sup>	Double word
16/3	51	Generator active energy ( L . W . )	kWh	
17/1	52	Battery voltage	V / 10	
17/2	53	Internal alarms 1  If both bits are set for double bits, the input is activated.  FS: Control input, not active F0: Class F0 alarm, not active F1: Class F1 alarm, active until acknowledged F2: Class F2 alarm, active until acknowledged F3: Class F3 alarm, active until acknowledged		Bit 15 = 1 \ F3: Generator overfrequency 1 Bit 14 = 1 / Bit 13 = 1 \ F3: Generator underfrequency 1 Bit 12 = 1 / Bit 11 = 1 \ F3: Generator overvoltage 1 Bit 10 = 1 / Bit 9 = 1 \ F3: Generator undervoltage 1 Bit 8 = 1 / Bit 7 = 1 \ --Internal-- Bit 6 = 1 / Bit 5 = 1 \ F1: Battery undervoltage Bit 4 = 1 / Bit 3 = 1 \ F3: Generator overload Bit 2 = 1 / Bit 1 = 1 \ F3: Generator reverse power Bit 0 = 1 /
17/3	54	Internal alarms 2  If both bits are set for double bits, the input is activated.  FS: Control input, not active F0: Class F0 alarm, not active F1: Class F1 alarm, active until acknowledged F2: Class F2 alarm, active until acknowledged F3: Class F3 alarm, active until acknowledged t		Bit 15 = 1 \ F0: Mains overfrequency Bit 14 = 1 / Bit 13 = 1 \ F0: Mains underfrequency Bit 12 = 1 / Bit 11 = 1 \ F0: Mains overvoltage Bit 10 = 1 / Bit 9 = 1 \ F0: Mains undervoltage Bit 8 = 1 / Bit 7 = 1 \ Interface fault X1 to X5 Bit 6 = 1 / Bit 5 = 1 \ --Internal-- Bit 4 = 1 / Bit 3 = 1 \ F0: df/dt fault Bit 2 = 1 / Bit 1 = 1 \ F0: Mains phase/vector jump Bit 0 = 1 /
18/1	55	Internal alarms 3  If both bits are set for double bits, the input is activated.  FS: Control input, not active F0: Alarm class 0, not active F1: Alarm class 1, active until quit F2: Alarm class 2, active until quit F3: Alarm class 3, active until quit		Bit 15 = 1 \ F3: Independent Bit 14 = 1 / time-overcurrent protection, level 2 Bit 13 = 1 \ --Internal-- Bit 12 = 1 / Bit 11 = 1 \ --Internal-- Bit 10 = 1 / Bit 9 = 1 \ F3: Generator load imbalance Bit 8 = 1 / Bit 7 = 1 \ F3: Independent Bit 6 = 1 / time-overcurrent protection, level 1 Bit 5 = 1 \ --Internal-- Bit 4 = 1 / Bit 3 = 1 \ F1: Maintenance call Bit 2 = 1 / Bit 1 = 1 \ --Internal-- Bit 0 = 1 /

MUX	No.	Content (words)	Unit	Content
18/2	56	Internal		
18/3	57	Internal		
19/1	58	External alarms 1  If both bits are set for double bits, the input is activated.		Bit 15 = 1 \ Terminal 34 Bit 14 = 1 / DI "Configuration blocked" Bit 13 = 1 \ Terminal 35 Bit 12 = 1 / DI "Isolated controller ON" Bit 11 = 1 \ Terminal 36 Bit 10 = 1 / DI "External acknowledgement" Bit 9 = 1 \ Terminal 61 Bit 8 = 1 / DI "Block mains protection" Bit 7 = 1 \ Terminal 62 Bit 6 = 1 / Discrete input [D01] Bit 5 = 1 \ Terminal 63 Bit 4 = 1 / Discrete input [D02] Bit 3 = 1 \ Terminal 64 Bit 2 = 1 / Discrete input [D03] Bit 1 = 1 \ Terminal 65 Bit 0 = 1 / Discrete input [D04]
19/2	59	External alarms 2  If both bits are set for double bits, the input is activated.		Bit 15 = 1 \ Terminal 66 Bit 14 = 1 / Discrete input [D05] Bit 13 = 1 \ Terminal 67 Bit 12 = 1 / Discrete input [D06] Bit 11 = 1 \ Terminal 68 Bit 10 = 1 / Discrete input [D07] Bit 9 = 1 \ Terminal 69 Bit 8 = 1 / Discrete input [D08] Bit 7 = 1 \ Terminal 70 Bit 6 = 1 / Discrete input [D09] Bit 5 = 1 \ Terminal 71 Bit 4 = 1 / Discrete input [D10] Bit 3 = 1 \ Terminal 72 Bit 2 = 1 / Discrete input [D11] Bit 1 = 1 \ Terminal 73 Bit 0 = 1 / Discrete input [D12]
19/3	60	Internal alarms 7		Bit 15 = 1 --Internal-- Bit 14 = 1 --Internal-- Bit 13 = 1 Ground current failure Bit 12 = 1 F3: ground current failure Bit 11 = 1 --Internal-- Bit 10 = 1 --Internal-- Bit 9 = 1 --Internal-- Bit 8 = 1 --Internal-- Bit 7 = 1 MCB close malfunction Bit 6 = 1 GCB close malfunction Bit 5 = 1 --Internal-- Bit 4 = 1 --Internal-- Bit 3 = 1 --Internal-- Bit 2 = 1 --Internal-- Bit 1 = 1 --Internal-- Bit 0 = 1 --Internal--
20/1	61	Analog input 1 (terminals 93-95)		
20/2	62	Analog input 2 (terminals 96-98)		
20/3	63	Analog input 3 (terminals 99-101)		
21/1	64	Analog input 4 (terminals 102-104)		
21/2	65	Analog input 5 (terminals 105-107)		
21/3	66	Analog input 6 (terminals 108-110)		
22/1	67	Analog input 7 (terminals 111-113)		
22/2	68	Internal		

MUX	No.	Content (words)	Unit	Comment
-----	-----	-----------------	------	---------

23/3	69	Speed detection		Bit 15 = 1	--Internal--
				Bit 14 = 1	--Internal--
				Bit 13 = 1	--Internal--
				Bit 12 = 1	--Internal--
				Bit 11 = 1	--Internal--
				Bit 10 = 1	--Internal--
				Bit 9 = 1	--Internal--
				Bit 8 = 1	--Internal--
				Bit 7 = 1 \	Firing speed exceeded
				Bit 6 = 1	
				Bit 5 = 1	
				Bit 4 = 1 /	
				Bit 3 = 1 \	Machine is running
				Bit 2 = 1	
Bit 1 = 1					
Bit 0 = 1 /					

- VgenEXPO** Exponent generator voltage
- IgenEXPO** Exponent generator current
- PgenEXPO** Exponent generator power
- VbusEXPO** Exponent busbar voltage
- VmainsEXPO** Exponent mains voltage
- PmainsEXPO** Exponent mains power
- PgenWD** Conversion factor steps → kW

### Receiving Telegram



A Gateway GW 4 may be used for start/stop synchronizing the MFR. The following three data words can be received by the MFR. Refer to the GW 4 manual on how to control several MFR units.

MUX	No.	Contents (words)	Unit	Note
-----	-----	------------------	------	------

1/1	1	Set point value for the generator real power	kW	with control argument; see below
1/2	2	Set point value for the generator power factor cos φ		Example: FF9EH cos φ = c 0.98 (capacitive/lagging) FF9DH cos φ = c 0.99 (capacitive/lagging) 0064H cos φ = 1.00 0063H cos φ = i 0.99 (inductive/leading) 0062H cos φ = i 0.98 (inductive/leading)
1/3	3	Control word		Bit 15 = 1 --Internal-- Bit 14 = 1 --Internal-- Bit 13 = 1 --Internal-- Bit 12 = 1 --Internal-- Bit 11 = 1 --Internal-- Bit 10 = 1 --Internal-- Bit 9 = 1 --Internal-- Bit 8 = 1 --Internal-- Bit 7 = 1 --Internal-- Bit 6 = 1 --Internal-- Bit 5 = 1 --Internal-- Bit 4 = 1 Remote acknowledgement Bit 3 = 1 Always "0" Bit 2 = 1 Always "0" Bit 1 = 1 Remote stop synchronization (high priority) Bit 0 = 1 Remote start synchronization

## CAN Bus Structure



### CAN Bus

#### Transmission Telegram

The data in the following table can be processed using a Gateway GW 4 or a PLC and transmitted to other communication busses. The MFR 3 sends its data via cyclic CAN messages with this.

The transfer rate of this communication is 125 kBaud.

The CAN ID, on which the MFR 3 is sending, is calculated as follows:

$$\text{CAN ID} = \text{d'800} + \text{item number (or H'320 + ID/generator number)}$$

(The ID number is a parameter, which can be set at the MFR 3, which influences the CAN ID directly on which the item sends its visualization messages.)

A visualization message, which is sent by an MFR 3, consists of 8 bytes and is assembled as follows:

Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7
H'DD	MUX number	data word 1 high byte	data word 1 high byte	data word 2 high byte	data word 2 high byte	data word 3 high byte	data word 3 high byte

In a visualization message the byte 0 is always used to show the hexadecimal value DD. This one defines the message as a visualization message. Since the complete transmission telegram of the MFR 3 includes more than three data words, byte 1 sends an additional MUX number starting with 0 in addition. Therefore it is theoretically possible to send  $(256 \times 3 = 768)$  words via the CAN ID. The whole telegram is built up as follows:

- Line 1: MUX number 0, data word 1
- Line 2: MUX number 0, data word 2
- Line 3: MUX number 0, data word 3
- Line 4: MUX number 1, data word 1
- Line 5: MUX number 1, data word 2
- Line 6: MUX number 1, data word 3
- .
- .
- Line (n): MUX number (n-1/3), data word 1
- Line (n+1): MUX number (n-1/2), data word 2
- Line (n+2): MUX number (n-1/1), data word 3

n depends on the total length of the item-specific telegram and cannot be larger than H'FF.

#### Current Direction Message

The current direction can be recognized via the prefix of the power. A positive transmitted value indicates exported power (power supplied to the mains, supply) and a negative transmitted value indicates imported power (power supplied by the mains, consumption).



## Power Set Point Value Message

The following power values may be pre-specified: constant/baseload power (C power), outgoing/export power (E power) and incoming/import power (I power). The real power set point value is transmitted in binary form using bits 0-13. The control argument must be transmitted in the basis of bits 14 and 15. In this case, the following coding applies:

Control argument	Bit 15	Bit 14
C power	0	1
E power	0	0
I power	1	1

### Example:

C power of 150 kW is to be compensated. The value transmitted is then:

01/00 0000 1001 0110 B ⇒ 4096 H

E power of 300 kW is to be compensated. The value transmitted is then:

00/00 0001 0010 1100 B ⇒ 012C H

I power of 600 kW is to be compensated. Negative power is transmitted. The value transmitted is then:

11/11 1101 1010 1000 B ⇒ FDA8 H

## CAN Bus Address Requirements

The IDs given in the following are reserved for the data exchange between MFRs. If third-party devices are connected to the bus, third-party device addresses must not conflict with these addresses.

	CAN-ID in	
	[hex]	[decimal]
<b>MFR sends</b>		
Distribution message to other MFRs	180 + GENNO	384 + GENNO
Visualization	320 + GENNO	800 + GENNO
<b>MFR receives</b>		
Distribution message from other MFR	180 + GENNO	384 + GENNO
Configuration messages from a higher control	33F	831

# Appendix G. List of Parameters

Product number P/N \_\_\_\_\_ Rev \_\_\_\_\_

Version MFR3 \_\_\_\_\_

Project \_\_\_\_\_

Serial number S/N \_\_\_\_\_ Date \_\_\_\_\_

Option	Parameter 100/400V; 5 A	Setting range	Standard setting	Customer settings	Level
<b>CONFIGURE GENERAL</b>					
	Sprache/language	first /second	first		
	Software version	V 3.3xxx			
	Enter code	0 to 9999			
	Load language	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
	Language number	0/1			
	Number of tool	1 to 14			
	Direct para.	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
	Service display	ON/OFF	ON	<input type="checkbox"/> on <input type="checkbox"/> off	<input type="checkbox"/> on <input type="checkbox"/> off
	Check event list	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
<b>CONFIGURE BASIC SETTINGS</b>					
	Configure Measuring	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
	Generator number	1 to 14	01		
	Generator freq. f set	40.0 to 70.0 Hz	50.0 Hz		
	Rated system frequency	50/60 Hz	50.0 Hz		
	Gen.volt.transf. secondary	50 to 125 V; 50 to 480 V	100 V		
	Gen.volt.transf. primary	0.005 to 65.000 / 0.020 to 65.000kV	10.000 kV		
	Bus.volt.transf. secondary	50 to 125 V; 50 to 480 V	100 V		
	Bus.volt.transf. primary	0.005 to 65.000 / 0.020 to 65.000kV	10.000 kV		
	Mains volt.trans secondary	50 to 125 V; 50 to 480 V	100 V		
	Mains volt.trans primary	0.005 to 65.000 / 0.020 to 65.000kV	10.000 kV		
	Gen.voltage U set	25 to 125 V; 50 to 480 V	100 V		
	Rated voltage System	25 to 125 V; 50 to 480 V	100 V		
	Voltage systems	phase to phase/Phase to neutral	phase to phase		
	Voltage measuring Main	threephase / singlephase	threephase		
	Current transf. generator	10 to 7,000/5 A	0100/5		
	Power measuring Gen.	singlephase/threephase	threephase		
	Rated power gen.	5 to 16,000 kW	02000 kW		
	Rated current generator	10 to 7,000 A	0100 A		
	Current transf. mains	5 to 7,000/5 A	0200/5		
	Angle adjustment Mainscurr.	-180 to 0 to 180 °	000 °		
	Define level 1 code	0 to 9999	0001		
	Define level 2 code	0 to 9999	0002		

Option	Parameter 100/400V; 5 A	Setting range	Standard setting	Customer settings	Level
<b>CONFIGURE CONTROLLER</b>					
	Configure Controller	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
	Power controller Pset1	C/E/I 0 to 16,000 kW	C000200kW		
	Power controller Pset2	C/E/I 0 to 16,000 kW	C000100kW		
	Initial state Frequency	0 to 100 %	50 %		
	Freq.controller	ON/OFF	ON	<input type="checkbox"/> on <input type="checkbox"/> off	<input type="checkbox"/> on <input type="checkbox"/> off
	f-contr. active at:	0.0 to 70.0 Hz	30,0 Hz		
	Delay time for f to contr.	0 to 999 s	005 s		
	Freq.controller ramp	1 to 50 Hz/s	05 Hz/s		
	F/P contr.type	THREEST. / ANALOG / PWM	ANALOG		
	Freq.controller dead band	0.02 to 1.00 Hz	0.10 Hz		
	Freq.controller time pulse>	10 to 250 ms	080 ms		
	Freq.controller gains.Kp	0.1 to 99.9	10.0		
	F/P contr.output	see table	+/-10V		
	Level PWM	3.0 to 10.0 V	3.0V		
	Freq.controller gain.Kpr	1 to 240	20		
	Freq.controller reset Tn	0.0 to 60.0 s	1.00 s		
	Freq.controller derivat.Tv	0.00 to 6.00 s	0.00 s		
	Starting point voltage	0 to 100 %	50%		
	Volt.controller	ON/OFF	ON	<input type="checkbox"/> on <input type="checkbox"/> off	<input type="checkbox"/> on <input type="checkbox"/> off
	V/Q contr.type	THREESTEP / ANALOG	ANALOG		
	Volt.controller dead band	0.1 to 15.0 V / 0.5 to 60.0 V	00.5%		
	Volt.controller time pulse>	20 to 250 ms	080 ms		
	Volt.controller gain.Kp	0.1 to 99.9	10.0		
	V/Q contr.output	see table	+/-10V		
	Volt.controller gain.Kpr	1 to 240	20		
	Volt.controller reset Tn	0.0 to 60.0 s	1.00 s		
	Volt.controller derivat.Tv	0.00 to 6.00 s	0.00 s		
	Pow.fact.contr.	ON/OFF	OFF	<input type="checkbox"/> on <input type="checkbox"/> off	<input type="checkbox"/> on <input type="checkbox"/> off
	Pow.fact.contr. setpoint	i0.70 to 1.00 to c0.70	1.00		
	Power factor external	ON/OFF	OFF	<input type="checkbox"/> on <input type="checkbox"/> off	<input type="checkbox"/> on <input type="checkbox"/> off
	Analog input	0 to 20 / 4 to 20 mA	4 to 20 mA		
	Ext. Pow.Factor 0mA	i0.70 to 1.00 to c0.70			
	Ext. Pow.Factor 20mA	i0.70 to 1.00 to c0.70			
	Pow.fact.contr. dead band	0.5 to 25.0 %	01.0 %		
	Pow.fact.contr. gain Kp	0.1 to 99.9	10.0		
	Pow.fact.contr. gains Kpr	1 to 240	20		
	Pow.fact.contr. reset Tn	0.0 to 60.0 s	1.00 s		
	Pow.fact.contr. derivat.Tv	0.00 to 6.00 s	0.00		
	Power controller	ON/OFF	ON	<input type="checkbox"/> on <input type="checkbox"/> off	<input type="checkbox"/> on <input type="checkbox"/> off
	Power controller ramp	0 to 100 %/s	005 %/s		
	Power controller ramp	1 to 100 kW/s	20 %/s		
	Power limit P max.	10 to 120 %	100 %		
	Power limit P min.	0 to 50 %	00 %		
	Power setpoint external	ON/OFF	ON	<input type="checkbox"/> on <input type="checkbox"/> off	<input type="checkbox"/> on <input type="checkbox"/> off
	Analog input	0 to 20 / 4 to 20 mA	4 to 20 mA		
	Ext.setpoint 0mA	C/E/I 0 to 16,000 kW	C00000kW		
	Ext.setpoint 20mA	C/E/I 0 to 16,000 kW	C00200kW		
	Power controller dead band	0.1 to 25.0 %	01.0 %		
	Power controller gain Kp	0.1 to 99.9	20.0		
	Powercontr. dead band ratio	1.0 to 9.9	*2.0		
	Power controller gain Kpr	1 to 240	20		
	Power controller reset Tn	0.0 to 60.0 s	1.00 s		
	Power controller derivat.Tv	0.00 to 6.00 s	0.00		
	Warm up load limit value	5 to 110 %	015 %		
	Warm up load time	0 to 600 s	000 s		
	Active power load share	ON/OFF	ON	<input type="checkbox"/> on <input type="checkbox"/> off	<input type="checkbox"/> on <input type="checkbox"/> off
	Act.load share factor	10 to 99 %	50 %		
	Reactive power load share	ON/OFF	OFF	<input type="checkbox"/> on <input type="checkbox"/> off	<input type="checkbox"/> on <input type="checkbox"/> off
	React.load share factor	10 to 99 %	50 %		

Option	Parameter 100/400V; 5 A	Setting range	Standard setting	Customer settings	Level
	Configure Automatic	NO/YES	NO		
	Control via COM X1X5	ON/OFF	OFF	<input type="checkbox"/> on <input type="checkbox"/> off	<input type="checkbox"/> on <input type="checkbox"/> off
	Control via COM Y1Y5	ON/OFF	OFF	<input type="checkbox"/> on <input type="checkbox"/> off	<input type="checkbox"/> on <input type="checkbox"/> off
	Delay to send MOD to Bus	0.2 to 50.0 ms			
<b>CONFIGURE BREAKER</b>					
	Configure Breaker	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
	Breaker logic:	see table	PARALLEL		
	Add-on/off ramp max.time	0 to 999 s	020 s		
	Open GCB with F2 max.time	0 to 999 s	010 s		
	Signal logic GCB	Continuous/Impulse	Cont		
	Opening GCB	NO to cont./NC to cont.	N.O. to contact		
<b>CONFIGURE SYNCHRONIZATION</b>					
	Synchronize df max	0.02 to 0.49 Hz	0.20 Hz		
	Synchronize df min	0.00 to -0.49 Hz	-0.10 Hz		
	Synchronize dV max	0.1 to 15 %	01.0 %		
	Synchronize time pulse>	0.02 to 0.26 s	0.24 s		
	Closing time GCB	40 to 300 ms	080ms		
	Closing time MCB	40 to 300 ms	080 ms		
	Autom.breaker deblocking	ON/OFF	OFF	<input type="checkbox"/> on <input type="checkbox"/> off	<input type="checkbox"/> on <input type="checkbox"/> off
	Sync.time contr.	ON/OFF	ON	<input type="checkbox"/> on <input type="checkbox"/> off	<input type="checkbox"/> on <input type="checkbox"/> off
	Sync.time contr. Delay	10 to 999 s	180 s		
<b>CONFIGURE DEAD BUSSTART</b>					
	GCB dead bus op.	ON/OFF	ON	<input type="checkbox"/> on <input type="checkbox"/> off	<input type="checkbox"/> on <input type="checkbox"/> off
	GCB dead bus op. df max	0.05 to 5.00 Hz	0.45 Hz		
	GCB dead bus op. dV max	0.1 to 20 %	10.0 %		
	GCB dead bus op. max.time	0 to 999 s	030 s		
	MCB dead bus op.	ON/OFF	ON	<input type="checkbox"/> on <input type="checkbox"/> off	<input type="checkbox"/> on <input type="checkbox"/> off
<b>CONFIGURE BREAKER MONITORING</b>					
	Supervision GCB	ON/OFF	ON	<input type="checkbox"/> on <input type="checkbox"/> off	<input type="checkbox"/> on <input type="checkbox"/> off
	Supervision MCB	ON/OFF	ON	<input type="checkbox"/> on <input type="checkbox"/> off	<input type="checkbox"/> on <input type="checkbox"/> off
	Mains decoupling via	MCB/GCB	GCB		
	Mains settling time	0 to 999 s	010 s		
	Mains decouplingvia term.62	ON/OFF	OFF		
<b>CONFIGURE MONITORING</b>					
	Configure Monitoring	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
	Mains power mon.	ON/OFF	OFF	<input type="checkbox"/> on <input type="checkbox"/> off	<input type="checkbox"/> on <input type="checkbox"/> off
	Mains power mon. res.val.	E/10 to 16.000 kW	E100 kW		
	Mains power mon. hysteresis	0 to 999 kW	10 kW		
	Mains power mon. Delay	0 to 600 s	1 s		
	Rev./red.power monitoring	ON/OFF	OFF	<input type="checkbox"/> on <input type="checkbox"/> off	<input type="checkbox"/> on <input type="checkbox"/> off
	Rev./red.power resp.value	-99 to 0 to 99 %	-10 %		
	Rev./red.power Delay	00.1 to 99.9 s	03.0 s		
	Gen.overload monitoring	ON/OFF	OFF	<input type="checkbox"/> on <input type="checkbox"/> off	<input type="checkbox"/> on <input type="checkbox"/> off
	Gen.overload MOP resp.value	80 to 150 %	120 %		
	Gen.overload MOP Delay	0 to 99 s	20 s		
	Gen.overload IOP resp.value	80 to 150 %	105 %		
	Gen.overload IOP Delay	0 to 99 s	03 s		
	Reactive power Monitoring	ON/OFF	OFF	<input type="checkbox"/> on <input type="checkbox"/> off	<input type="checkbox"/> on <input type="checkbox"/> off
	Reactive pow.ind Limit	5 to 100 %	010 %		
	Reactive pow.ind Delay	0 to 600 s	010 s		
	Reactive pow.cap Limit	5 to 100 %	010 %		
	Reactive pow.cap Delay	0 to 600 s	010 s		

Option	Parameter 100/400V; 5 A	Setting range	Standard setting	Customer settings		Level
	Gen.overcurrent monitoring	ON/OFF	OFF	<input type="checkbox"/> on <input type="checkbox"/> off	<input type="checkbox"/> on <input type="checkbox"/> off	
	Gen.overcurr. 1 resp.value	0 to 300 %	110 %			
	Gen.overcurr. 1 Delay	0.02 to 99.98 s	01.00 s			
	Gen.overcurr. 2 resp.value	0 to 300 %	300 %			
	Gen.overcurr. 2 Delay	0.02 to 99.98 s	00.04 s			
	Inv.time ov.cur. Monitor	ON/OFF	OFF	<input type="checkbox"/> on <input type="checkbox"/> off	<input type="checkbox"/> on <input type="checkbox"/> off	
	Inv.time char.	normal inv/ high inv /extremely inv.	normal inv			
	Inv.time ov.cur. Tp	0.00 to 1.98s	0,10 s			
	Inv.time ov.cur. Ip	0.1 to 3.0*In	1.0*In			
	Inv.time ov.cur. I start	1.00 to 3.00*In	1.00*In			
	Inv.time ov.cur. V-restr	ON/OFF	ON	<input type="checkbox"/> on <input type="checkbox"/> off	<input type="checkbox"/> on <input type="checkbox"/> off	
	Inv.time ov.cur knee crv.U>	10 to 90 %	20 %			
	Inv.time ov.cur1 Delay	0.02 to 99.98 s	1.00 s			
	Inv.time ov.cur2 knee crv	0 to 300 %				
	Inv.time ov.cur2 Delay	0.02 to 99.98 s	1.00 s			
	Load unbalance Monitoring	ON/OFF	OFF	<input type="checkbox"/> on <input type="checkbox"/> off	<input type="checkbox"/> on <input type="checkbox"/> off	
	Load unbalance max.	0 to 100 %	030 %			
	Load unbalance Delay	0.02 to 99.98 s	01.00 s			
	Earth fault Monitoring	ON/OFF	OFF	<input type="checkbox"/> on <input type="checkbox"/> off	<input type="checkbox"/> on <input type="checkbox"/> off	
	Earth fault Response v.	5 to 100 %	015 %			
	Earth fault Delay	0.02 to 99.98 s	1.00 s			
	Gen.overfreq. monitoring	ON/OFF	OFF	<input type="checkbox"/> on <input type="checkbox"/> off	<input type="checkbox"/> on <input type="checkbox"/> off	
	Gen.overfreq. 1 f >	40.00 to 85.00 Hz	55.00 Hz			
	Gen.overfreq. 1 Delay	0.02 to 99.98 s	01.00 s			
	Gen.overfreq. 2 f >	40.00 to 85.00 Hz	58.00 Hz			
	Gen.overfreq. 2 Delay	0.02 to 99.98 s	00.10 s			
	Gen.underfreq. monitoring	ON/OFF	OFF	<input type="checkbox"/> on <input type="checkbox"/> off	<input type="checkbox"/> on <input type="checkbox"/> off	
	Gen.underfreq. 1 f <	40.00 to 85.00 Hz	45.00 Hz			
	Gen.underfreq. 1 Delay	0.02 to 99.98 s	01.00 s			
	Gen.underfreq. 2 f <	40.00 to 85.00 Hz	42.00 Hz			
	Gen.underfreq. 2 Delay	0.02 to 99.98 s	00.10 s			
	Gen.overvoltage monitoring	ON/OFF	OFF	<input type="checkbox"/> on <input type="checkbox"/> off	<input type="checkbox"/> on <input type="checkbox"/> off	
	Gen.overvolt. 1 U >	[1] 20 to 150 V; [4] 20 to 520 V	110 V			
	Gen.overvolt. 1 Delay	0.02 to 99.98 s	01.00 s			
	Gen.overvolt. 2 U >	[1] 20 to 150 V; [4] 20 to 520 V	125 V			
	Gen.overvolt. 2 Delay	0.02 to 99.98 s	00.10 s			
	Gen.undervolt. monitoring	ON/OFF	OFF	<input type="checkbox"/> on <input type="checkbox"/> off	<input type="checkbox"/> on <input type="checkbox"/> off	
	Gen.undervolt. 1 U <	[1] 20 to 150 V; [4] 20 to 520 V	090 V			
	Gen.undervolt. 1 Delay	0.02 to 99.98 s	01.00 s			
	Gen.undervolt. 2 U <	[1] 20 to 150 V; [4] 20 to 520 V	075 V			
	Gen.undervolt. 2 Delay	0.02 to 99.98 s	00.10 s			
	Mains frequency monitoring	ON/OFF	ON	<input type="checkbox"/> on <input type="checkbox"/> off	<input type="checkbox"/> on <input type="checkbox"/> off	
	Mains overfreq. f >	40.00 to 70.00 Hz	50.20 Hz			
	Mains overfreq. Delay	0.02 to 99.98 s	00.06 s			
	Mains underfreq. f <	40.00 to 70.00 Hz	49.80 Hz			
	Mains underfreq. Delay	0.02 to 99.98 s	00.06 s			
	Mains voltage monitoring	ON/OFF	ON	<input type="checkbox"/> on <input type="checkbox"/> off	<input type="checkbox"/> on <input type="checkbox"/> off	
	Mains volt.monit U Ph.-N.	U Ph.-Ph. / U Ph.-N.	U Ph.-Ph.	<input type="checkbox"/> pp <input type="checkbox"/> pn	<input type="checkbox"/> pp <input type="checkbox"/> pn	
	Mains overvolt. U Ph.-N. >	[1] 20 to 150 V; [4] 20 to 520 V	110/440 V			
	Mains overvolt. U Ph.-Ph. >	[1] 20 to 87 V; [4] 20 to 300 V	64/254 V			
	Mains overvolt. Delay	0.02 to 99.98 s	00.06 s			
	Mains undervolt. U Ph.-N. <	[1] 20 to 150 V; [4] 20 to 520 V	90/360 V			
	Mains undervolt. U Ph.-Ph. <	[1] 20 to 87 V; [4] 20 to 300 V	52/208 V			
	Mains undervolt. Delay	0.02 to 99.98 s	00.06 s			

Option	Parameter 100/400V; 5 A	Setting range	Standard setting	Customer settings	Level
	Phase shift monitoring	ON/OFF	ON	<input type="checkbox"/> on <input type="checkbox"/> off	<input type="checkbox"/> on <input type="checkbox"/> off
	Monitoring	one/three-phase three phase only	threephase		
	Phase shift one to phase	3 to 30 °	12 °		
	Phase shift three to phase	3 to 30 °	08 °		
	df/dt to monitoring	ON/OFF	OFF	<input type="checkbox"/> on <input type="checkbox"/> off	<input type="checkbox"/> on <input type="checkbox"/> off
	df/dt to monitoringrelease>	1.0 to 9.9 Hz/s	2.6 Hz/s		
	df/dt to monitoringDelay ti	0.1 to 9.9 s	0.1 s		
	Mainstrip via	Phase shift / df/dt	df/dt		
	Batt.undervolt. U <	9.5 to 30.0 V	10.0 V		
	Batt.undervolt. Delay	0 to 99 s	10 s		
	Mains power mon.	ON/OFF	ON		
	Mains power mon. res.val.	E/I 0 to 16,000 kW	E00100kW		
	Mains power mon. hysteresis		010 kW		
	Mains power mon. Delay	0.02 to 99.98 s	001 s		
<b>CONFIGURE DISCRETE INPUTS</b>					
	Configure Dig.input	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
	Dig.input 1234 function	E/D	DDDD		
	Dig.input 1234 delay	0 to 9	0000		
	Delayed by 1234 eng.speed	Y/N	NNNN		
	Dig.input 1234error class	0 to 3	3210		
	Dig.input 5678 function	E/D	DDDD		
	Dig.input 5678 delay	0 to 9	0000		
	Delayed by 5678 eng.speed	Y/N	NNNN		
	Dig.input 5678 error class	0 to 3	1111		
	Dig.input 9ABC function	E/D	DDDD		
	Dig.input 9ABC delay	0 to 9	0000		
	Delayed by 9ABC eng.speed	Y/N	NNNN		
	Dig.input 9ABC error class	0 to 3	1111		
	Errortxt.term.62Terminal 62	any	Terminal 62		
	Errortxt.term.63Terminal 63	any	Terminal 63		
	Op.mod blocked by Ter.63	ON/OFF	OFF		
	Errortxt.term.64Terminal 64	any	Terminal 64		
	Breaker logic by Ter.64	ON/OFF	OFF		
	Errortxt.term.65Terminal 65	any	Terminal 65		
	Errortxt.term.66Terminal 66	any	Terminal 66		
	Errortxt.term.67Terminal 67	any	Terminal 67		
	Errortxt.term.68Terminal 68	any	Terminal 68		
	Errortxt.term.69Terminal 69	any	Terminal 69		
	Errortxt.term.70Terminal 70	any	Terminal 70		
	Errortxt.term.71Terminal 71	any	Terminal 71		
	Errortxt.term.72Terminal 72	any	Terminal 72		
	Errortxt.term.71Terminal 73	any	Terminal 73		
<b>CONFIGURE ANALOG INPUTS</b>					
	Configure Analg.inp.	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
	Temperature x Pt100	ON/OFF	OFF	<input type="checkbox"/> on <input type="checkbox"/> off	<input type="checkbox"/> on <input type="checkbox"/> off
	***Name****	any	Analog 1		
	Limit warning	0 to 255 °C			
	Limit shutdown	0 to 255 °C			
	Delay limit 1/2	0 to 600 s	1 s		
	Monitoring for	high limit mon./low limit mon.	high limit mon.		
	Analog input x scaleable	ON/OFF	OFF	<input type="checkbox"/> on <input type="checkbox"/> off	<input type="checkbox"/> on <input type="checkbox"/> off
	Name and unit	any	Analog X		
	Analog input x	0 to 20 mA / 4 to 20mA	4 to 20mA		
	Value at 0%	-9,999 to 0 to 9,999			
	Value at 100%	-9,999 to 0 to 9,999			
	Limit warning value	-9,999 to 0 to 9,999			
	Limit shutdown value	-9,999 to 0 to 9,999			
	Delay Limit 1/2	0 to 600 s	1.0 s		
	Monitoring for	high limit mon./low limit mon.	high limit		
	An.input 1234 Superv.del	Y/N	NNNN		
	An.input 5678 Superv.del	Y/N	NNNN		

Option	Parameter 100/400V; 5 A	Setting range	Standard setting	Customer settings	Level
<b>CONFIGURE OUTPUTS</b>					
	Configure Outputs	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
	Analg.out.130131	OFF / 0 to 20 / 4 to 20 mA	OFF		
	Analg.out.130131 parameter	0 to 23	01		
	Analg.out.130131 0%	0 to 9,990	0000		
	Analg.out.130131 100%	0 to 9,990	0200		
	Analg.out.132133	OFF / 0 to 20 / 4 to 20 mA	OFF		
	Analg.out.132133 parameter	0 to 23	01		
	Analg.out.132133 0%	0 to 9,990	0000		
	Analg.out.132133 100%	0 to 9,990	0200		
	Pulse output 1	+kWh / -kWh			
	Pulse output 1 logic	positive/negative	negative		
	Active energy Pulse/kWh	0.1 to 150.0	001.0		
	Pulse output 2	+kvarh / -kvarh			
	Pulse output 2 logic	positive/negative	negative		
	Reactive energy Pulse/kvah	0.1 to 150.0	001.0		
<b>CONFIGURE DRIVE</b>					
	Configure Drive	YES/NO	YES	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
	Automatic idle Running	ON/OFF	OFF	<input type="checkbox"/> on <input type="checkbox"/> off	<input type="checkbox"/> on <input type="checkbox"/> off
	Download and open GCB	ON/OFF	ON	<input type="checkbox"/> on <input type="checkbox"/> off	<input type="checkbox"/> on <input type="checkbox"/> off
	Monitoring on at f gen >	15 to 70 Hz	15 Hz		
	Monitoring on after	0 to 99 s	08 s		
<b>CONFIGURE COUNTER</b>					
	Configure Counters	YES/NO	NO	<input type="checkbox"/> Y <input type="checkbox"/> N	<input type="checkbox"/> Y <input type="checkbox"/> N
	Service interval	ON/OFF	ON	<input type="checkbox"/> on <input type="checkbox"/> off	<input type="checkbox"/> on <input type="checkbox"/> off
	Service interval in	0 to 9,999 h	0300 h		
	Op.hours counter	ON/OFF	ON	<input type="checkbox"/> on <input type="checkbox"/> off	<input type="checkbox"/> on <input type="checkbox"/> off
	Op.hours counter set	0 to 65,000 h	00000 h		
	Start counter	ON/OFF	ON	<input type="checkbox"/> on <input type="checkbox"/> off	<input type="checkbox"/> on <input type="checkbox"/> off
	Start counter set	0 to 32,000	00000		
	Display kWh +- on?	Y/N	YY		
	Display kvarh +- on?	Y/N	YY		
	Time	00:00 to 23:59	00:00		
	Year, month	00 to 99, 1 to 12	00,00		
	Day, weekday	01 to 31, 1 to 7	00,0		

# Appendix H. Service Options



## Product Service Options



The following factory options are available for servicing Woodward equipment, based on the standard Woodward Product and Service Warranty (5-01-1205) that is in effect at the time the product is purchased from Woodward or the service is performed. If you are experiencing problems with installation or unsatisfactory performance of an installed system, the following options are available:

- Consult the troubleshooting guide in the manual.
- Contact Woodward technical assistance (see "How to Contact Woodward" later in this chapter) and discuss your problem. In most cases, your problem can be resolved over the phone. If not, you can select which course of action you wish to pursue based on the available services listed in this section.

## Returning Equipment For Repair



If a control (or any part of an electronic control) is to be returned to Woodward for repair, please contact Woodward in advance to obtain a Return Authorization Number. When shipping the unit(s), attach a tag with the following information:

- name and location where the control is installed;
- name and phone number of contact person;
- complete Woodward part numbers (P/N) and serial number (S/N);
- description of the problem;
- instructions describing the desired repair.



### CAUTION

To prevent damage to electronic components caused by improper handling, read and observe the precautions in Woodward manual 82715, *Guide for Handling and Protection of Electronic Controls, Printed Circuit Boards, and Modules*.



## Packing a Control

Use the following materials when returning a complete control:

- protective caps on any connectors
- antistatic protective bags on all electronic modules
- packing materials that will not damage the surface of the unit
- at least 100 mm (4 inches) of tightly packed, industry-approved packing material
- a packing carton with double walls
- a strong tape around the outside of the carton for increased strength

## Return Authorization Number RAN

When returning equipment to Woodward, please telephone and ask for the Customer Service Department in Stuttgart [+49 (0) 711 789 54-0]. They will help expedite the processing of your order through our distributors or local service facility. To expedite the repair process, contact Woodward in advance to obtain a Return Authorization Number, and arrange for issue of a purchase order for the unit(s) to be repaired. No work can be started until a purchase order is received.



### NOTE

**We highly recommend that you make arrangement in advance for return shipments. Contact a Woodward customer service representative at +49 (0) 711 789 54-0 for instructions and for a Return Authorization Number.**

## Replacement Parts



When ordering replacement parts for controls, include the following information:

- the part numbers P/N (XXXX-XXX) that is on the enclosure nameplate
- the unit serial number S/N, which is also on the nameplate

## How To Contact Woodward



Please contact following address if you have questions or if you want to send a product for repair:

Woodward GmbH  
Handwerkstrasse 29  
70565 Stuttgart - Germany

Phone: +49 (0) 711 789 54-0 (8:00 - 16:30 German time)  
Fax: +49 (0) 711 789 54-100  
eMail: stgt-info@woodward.com

For assistance outside Germany, call one of the following international Woodward facilities to obtain the address and phone number of the facility nearest your location where you will be able to get information and service.

<b>Facility</b>	<b>Phone number</b>
USA	+1 (970) 482 5811
India	+91 (129) 409 7100
Brazil	+55 (19) 3708 4800
Japan	+81 (476) 93 4661
The Netherlands	+31 (23) 566 1111

You can also contact the Woodward Customer Service Department or consult our worldwide directory on Woodward's website ([www.woodward.com](http://www.woodward.com)) for the name of your nearest Woodward distributor or service facility. [For worldwide directory information, go to [www.woodward.com/ic/locations](http://www.woodward.com/ic/locations).]

## Engineering Services



Woodward Industrial Controls Engineering Services offers the following after-sales support for Woodward products. For these services, you can contact us by telephone, by e-mail, or through the Woodward website.

- Technical support
- Product training
- Field service during commissioning

**Technical Support** is available through our many worldwide locations, through our authorized distributors, or through GE Global Controls Services, depending on the product. This service can assist you with technical questions or problem solving during normal business hours. Emergency assistance is also available during non-business hours by phoning our toll-free number and stating the urgency of your problem. For technical engineering support, please contact us via our toll-free or local phone numbers, e-mail us, or use our website and reference technical support.

**Product Training** is available on-site from several of our worldwide facilities, at your location, or from GE Global Controls Services, depending on the product. This training, conducted by experienced personnel, will assure that you will be able to maintain system reliability and availability. For information concerning training, please contact us via our toll-free or local phone numbers, e-mail us, or use our website and reference *customer training*.

**Field Service** engineering on-site support is available, depending on the product and location, from our facility in Colorado, or from one of many worldwide Woodward offices or authorized distributors. Field engineers are experienced on both Woodward products as well as on much of the non-Woodward equipment with which our products interface. For field service engineering assistance, please contact us via our toll-free or local phone numbers, e-mail us, or use our website and reference *field service*.

## Technical Assistance



If you need to telephone for technical assistance, you will need to provide the following information. Please write it down here before phoning:

### Contact

Your company \_\_\_\_\_

Your name \_\_\_\_\_

Phone number \_\_\_\_\_

Fax number \_\_\_\_\_

### Control (see name plate)

Unit no. and revision: P/N: \_\_\_\_\_ REV: \_\_\_\_\_

Unit type MFR 3 \_\_\_\_\_

Serial number S/N \_\_\_\_\_

### Description of your problem

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

Please be sure you have a list of all parameters available. You can print this using LeoPC1. Additionally you can save the complete set of parameters (standard values) and send them to our Service department via e-mail.

We appreciate your comments about the content of our publications.  
Please send comments to: [stgt-documentation@woodward.com](mailto:stgt-documentation@woodward.com)  
Please include the manual number from the front cover of this publication.



**Woodward GmbH**  
Handwerkstrasse 29 - 70565 Stuttgart - Germany  
Phone +49 (0) 711 789 54-0 • Fax +49 (0) 711 789 54-100  
[stgt-info@woodward.com](mailto:stgt-info@woodward.com)

**Homepage**

<http://www.woodward.com/power>

**Woodward has company-owned plants, subsidiaries, and branches, as well as authorized distributors and other authorized service and sales facilities throughout the world.**

**Complete address/phone/fax/e-mail information for all locations is available on our website ([www.woodward.com](http://www.woodward.com)).**

2008/12/Stuttgart